

IDENTIFICATION

PRODUCT CODE: MAINDEC 12-D8CC-D

PRODUCT NAME: KW12A CLOCK TEST

DATE CREATED: JUNE 19, 1970

MAINTAINER: DIAGNOSTIC GROUP

AUTHOR: HAROLD LONG

1 ABSTRACT

1.1 The KW12 Real Time Clock Test is designed to verify the correct operation of the Buffer Preset Register, Clock Counter Register, Clock Control Register, Clock Enable Register, Clock I/O Interface, External Input Channels, and Fast Sample Mode (if the AD12 option is concurrently installed.)

1.2 Program Control is maintained by a monitor resident in Bank Ø. Several options are available to the operator for error handling.

2 REQUIREMENTS:

2.1 Equipment:

- a) A PDP-12 with KW12 installed.
- b) An AD12 Analog-to-Digital Converter if Fast Sample testing is required.
- c) An ASR-33 or equivalent.

2.2 Preliminary Programs

- a) All Central Processor and Memory Diagnostic Programs for a basic PDP-12 must be able to run successfully prior to testing the KW12.

2.3 Storage:

- a) 4K minimum core.
- b) Program occupies locations ØØØØ to 76ØØ.

3 LOADING PROCEDURES

3.1 Method

This program must be loaded with the binary loader. If you are unfamiliar with the proper binary loading procedures refer to "Appendix A" of this program, otherwise proceed with the following:

- a) Set the teletype reader switch to FREE.
- b) Open the teletype reader and insert the program tape so that the arrows on the tape are visible to and pointing toward the operator.
- c) Close the reader and set the reader switch to START.
- d) Set the teletype front panel switch to ON LINE.
- e) Set the LEFT switches to 7777.
- f) Set the RIGHT switches to 4ØØØ.

- g) Set the MODE switch to 8 mode.
- h) Depress I/O preset.
- i) Depress START LS.
- j) When the program tape has been read the ACCUMULATOR must be $\emptyset\emptyset\emptyset$ if it is not, a read-in error has occurred and one might try reloading the binary loader.
- k) Remove the program tape from the reader.

4 STARTING PROCEDURES

4.1 Method

- a) Set the MODE switch to 8 mode.
- b) Set the LEFT switches to $\emptyset\emptyset\emptyset$.
- c) Set the RIGHT switches to the desired options.
- d) Depress I/O preset.
- e) Depress START 2 β .
- f) The program is now running. The teletype bell will ring at the end of each pass. In addition, the contents of the pass counter will be typed out.

4.2 Switch Settings

- a) If Fast Sample testing is to be attempted, set knob \emptyset fully counterclockwise and Knob 1 fully clockwise.
- b) Set the selector switches on the front panel to line frequency.
- c) Set the input level knobs to mid-range.
- d) Select any desired error handler options. With RSW = $\emptyset\emptyset\emptyset$, the following sequence will occur for an error:
(MESSAGE TYPEOUT, "ERROR HALT) the operator selects any further error options and depresses continue... (MONITOR EXECUTES NEXT SEQUENTIAL TEST)

```

RSW 0 $\emptyset$  = 1, INHIBIT ERROR HALT
RSW 01 = 1, INHIBIT ERROR PRINTOUT
RSW 02 = 1, SCOPE LOOP ON ERROR
RSW 03 = 1, SCOPE LOOP ON NON-FAILING TEST
RSW 04 = 1, INHIBIT FAST SAMPLE TESTING
RSW 05 = 1, INHIBIT BELL RINGING
RSW 06 = 1, INHIBIT PASS COUNTER PRINTOUT
      
```

5 ERROR ROUTINE

5.1 Error Printout

- a) The error messages have the following general form:

```

TEST NO. TEST MESSAGE
REG1 REG2 REG3 ...
      
```

- b) TEST NO. refers to the test number as organized in the listing. This is included to aid the operator in finding the test in the listing.
- c) TEST MESSAGE is the body of the text, describing what was tested, and indicating any areas of probable failure.
- d) REG1, REG2, REG3, are specific data words pertaining to the failure.

5.2 Error Messages

TST10 CLAB CHANGED AC

7741 7020

TST11 CLBA FAILED

Ø4Ø2 7020

TST12 CLAB FAILED

Ø4Ø2 7020

TST13 CLAB FAILED

7741 7020

TST14 CLAB FAILED

Ø4Ø2 7020

TST15 CLBA CHANGED BUFFER

Ø4Ø2 7020

TST16 CLAB <> CLBA FAILED

7741 7020

TST17 CLAB <> CLBA FAILED

Ø4Ø2 7020

TST18 CLAB <> CLBA FAILED

Ø4Ø2 7020

TST19 CLEN CHANGED AC

7741 7020

TST20 CLEN CHANGED BUFFER

7741 7020

TST21 CLCA FAILED

Ø4Ø2 7020

TST22 "CLR CNT" FAILED

Ø4Ø2 7020

TST23 CLEN FAILED

7741 7020

TST24 CLEN FAILED

Ø4Ø2 7020

TST25 CLCA CHANGES COUNT

Ø4Ø2 7020

TST26 BUFFER <> COUNTER FAILED

Ø4Ø2 7020

TST27 "LOAD CNT" FAILS TO "OR"

0402 7020 TST28 "LOAD CNT" LOADED IN ERROR
0402 7020 TST29 "LOAD CNT" LOADED IN ERROR
0402 7020 TST30 MODE REG CAUSES "LOAD CNT!"
0402 7020 TST31 MODE REG CAUSES "LOAD CNT" OR "CLR BUF"
0402 7020 0000 TST32 MODE 2: 1>0 CLOCKED CNTR
0402 7020 TST33 MODE 2: >1 CLOCKED C.NTR
0000 7020 TST34 O'FLO FAILED TO SET O'FLO FLOP
TST35 CLSA FAILED TO CLEAR O'FLO FLOP
TST36 CLSK SKIPPED IN ERROR
TST37 ILLEGAL CLOCK INTERRUPT!
TST38 CLSK FAILED TO SKIP
TST39 CLOCK INTERRUPT FAILED
TST40 O'FLO ENABLE WON'T ZERO
TST41 O'FLO FLAG WON'T CLEAR
TST42 CLOCK INTR WON'T CLEAR
TST43 BIT 11 FAILED.
0402 7020 TST44 BIT 10 FAILED.
0402 7020 TST45 BIT 09 FAILED.
0402 7020 TST46 BIT 08 FAILED.
0402 7020 TST47 BIT 07 FAILED.
0402 7020 TST48 BIT 06 FAILED.
0402 7020 TST49 BIT 05 FAILED.
0402 7020 TST50 BIT 04 FAILED.
0402 7020 TST51 BIT 03 FAILED.
0402 7020 TST52 BIT 02 FAILED.
0402 7020 TST53 BIT 01 FAILED.
0402 7020

TST54 BIT $\beta\beta\beta$ FAILED.

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST55 RATE 4 $\beta\beta\beta\beta$ KC FAILS

TST56 RATE 1 $\beta\beta\beta\beta$ KC FAILS

TST57 RATE 1 $\beta\beta\beta\beta$ KC FAILS

TST58 RATE 1 $\beta\beta\beta\beta$ KC FAILS

TST59 RATE 1 $\beta\beta\beta\beta$ CPS FAILS

TST60
CHAN 1 INPUT LOCKED OUT

TST61 CHAN 3 WON'T TOGGLE

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST62 CHAN 2 WON'T TOGGLE

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST63 CHAN 1 WON'T TOGGLE

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST64 CHAN 1 WON'T INTR

TST65 CHAN 1 INTR IN ERROR

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST66 CHAN 2 WON'T INTR.

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST67 CHAN 2 INTR IN ERROR

TST68 CHAN 3 WON'T INTR.

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST69 CHAN 3 INTR IN ERROR

TST70 CHAN 3 INPUT LINE FREQ FAILED

7 $\beta\beta\beta\beta$

TST71 CHAN 2 INPUT LINE FREQ FAILED

7 $\beta\beta\beta\beta$

TST72 CHAN 1 INPUT LINE FREQ FAILED

7 $\beta\beta\beta\beta$

TST73 FAST SAM FAILS

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST74 O'FLO WON'T FAST SAO

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST75 FAST SAM WON'T SET

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST76 MODES 2-1 INHIBIT FAST SAM

$\beta\beta\beta\beta\beta$ 7 $\beta\beta\beta\beta$

TST77 RATE 1 $\beta\beta\beta\beta$ KC FAILS

$\beta\beta\beta\beta\beta$

TST78 I/O PRESET WON'T STOP CLOCK

(RATE BITS 1 & 2)

TST79 1KC FAILS

$\beta\beta\beta\beta\beta$

TST80 I/O PRESET WON'T STOP CLOCK
(RATE BIT 0)

TST81 I/O PRESET WON'T CLEAR O'FLO

TST82 I/O PRESET WON'T CLEAR INTERRUPT ENABLE

TST83 I/O PRESET WON'T CLEAR INPUTS

TST84 I/O PRESET WON'T CLEAR MODE 2

TST85 I/O PRESET WON'T CLEAR MODE 0

TST86 FAST SAM NOT CLEARED

TST87 CHAN 1 WON'T TRANS CNT TO BUF
0200

TST88 CHAN 2 WON'T TRANS CNT TO BUF
0200

TST89 CHAN 3 WON'T TRANS CNT TO BUF
0200

TST90 CHAN 1 WON'T TRANS CNT TO BUF
0300

TST91 CHAN 2 WON'T TRANS CNT TO BUF
0300

TST92 CHAN 3 WON'T TRANS CNT TO BUF
0300

TST93 CHA3 INPUT FAILED TO CLR CNT
7020

TST94 ECO EM-0034 IS EITHER NOT WORKING OR NOT
INSTALLED
KW12 PASS-0000

PDP-8 MODE PERFORATED-TAPE LOADER

READIN MODE LOADER

The readin mode (RIM) loader is a minimum length, basic, perforated-tape program for the 33 ASR. It is initially stored in memory by manual use of the operator console keys and switches. The loader is permanently stored in 18 locations of page 37.

The RIM loader can only be used in conjunction with the 33ASR reader (not the high-speed perforated-tape reader). Because a tape in RIM format is, in effect, twice as long as it need be, it is suggested that the RIM loader be used only to read the binary loader when using the 33 ASR. (NOTE: Some PDP-12 diagnostic program tapes are in RIM format.)

The complete PDP-12 RIM loader ($S_8=7756$) is as follows:

Absolute Address	Octal Content	Tag	Instruction I_Z	Comments
7756	6032	BEG,	KCC	/CLEAR AC AND FLAG
7757	6031		KSF	/SKIP IF FLAG=1
7760	5357		JMP-1	/LOOKING FOR CHARACTER
7761,	6036		KRB	/READ BUFFER
7762,	7106		CLL RTL	
7763,	7006		RTL	/CHANNEL 8 IN ACO
7764,	7510		SPA	/CHECKING FOR LEADER
7765,	5357		JMP BEG+1	/FOUND LEADER
7766,	7006		RTL	/OK, CHANNEL 7 IN LINK
7767,	6031		KSF	
7770,	5367		JMP-1	
7771,	6034		KRS	/READ, DO NOT CLEAR
7772,	7420		SNL	/CHECKING FOR ADDRESS
7773,	3776		DCA 1 TEMP	/STORE CONTENT
7774,	3376		DCA TEMP	/STORE ADDRESS
7775,	5356		JMP BEG	/NEXT WORD
7776,	0	TEMP,	O	/TEMP STORAGE
7777	5XXX		JMP X	/TEMP START OF BIN LOADER

Placing the RIM loader in core memory by way of the operator console keys and switches is accomplished as follows:

- a. Set the starting address 7756 in the LEFT switches.
- b. Set the first instruction (6032) in the RIGHT switches.
- c. Press the FILL switch, then press FILL STEP.
- d. Set the next instruction (6031) in the RIGHT switches.
- e. Press the FILL STEP switch.
- f. Repeat steps d and e until all 16 instructions have been deposited.

To load a tape in RIM format, place the tape in the reader, set the LEFT switches to the starting address 7756 of the RIM loader (not of the program being read), press the START LS key, and start the Teletype reader.

BINARY FORMAT PERFORATED TAPE LOADER

Once the RIM loader is in core, place the binary loader program tape on the teletype reader and turn the reader on. Set the LEFT switches to 7756, depress I/O preset with the mode switch in 8 mode, then depress START LS. The binary tape will read into core. The reader must be turned off manually as the tape reaches the end, since RIM does not stop.

6131 GBSK=6131 /SKIP ON CLOCK INTERRUPT
6132 CLR=6132 /AC TO CLOCK CONTROL REGISTER
6133 CLR=6133 /AC TO BUFFER PRESET REGISTER
6134 CLR=6134 /AC TO LOGIC ENABLE REGISTER
6135 CLR=6135 /LOGIC STATUS TO AC, CLEAR STATUS PLIPFLOPS
6136 CLBAG6136 /BUFFER PRESET REGISTER TO AC
6137 CLCAE6137 /COUNTER TO AC
4444 EXITB94444 /ESTART SWITCH
7777 EXITA97777 /MESSAGE TERMINATOR
0000 EXITA90000 /MESSAGE SWITCH
/SOME LINC PROGRAMMING DEFINITIONS!

6002 POP=0002 /POP=0002
0011 CLR=0041 /CLR=0041
0100 ESF=0004 /ESF=0004
0101 SAM0=0100 /SAM0=0100
1020 LDA1=1020 /LDA1=1020

```

/PAGE 2 KM12A CLOCK TEST, MAINDEC 12=0BCC=6 PAGE 2
    2129  V141  PAL10  22=JUL=78  0001  01  5452  JMP I  RETURN  /INTERRUPT RETURN HANDLER
    0002  0410  #410  PRINT, 0
    0003  0000  #000  JMP  177  /MAJOR START & MODE
    0004  2020  #2020
    0005  5177  #5177

```

/PAGE 0 CONSTANTS

/ PDP-12 KML2A CLOCK TEST, MAINDEC 12-DPCCL

PAL18 V1242 2146UL=78

1111

0071	7770	KPRC,	7770	/	0143	7774	K7774,	7774
0072	0100	KENA,	0100		0142	6000	K6000,	6000
0073	0102	KENA,	0102		0141	5555	K5555,	5555
0074	4100	KRTG,	4100		0140	5252	K5252,	5252
0075	0000	K0000,	0000		0137	5100	K5100,	5100
0076	0001	K0001,	0001		0136	4100	K4100,	4100
0077	0002	K0002,	0002		0135	4100	K4100,	4100
0078	0003	K0003,	0003		0134	3777	K3777,	3777
0079	0004	K0004,	0004		0133	3000	K3000,	3000
0080	0005	K0005,	0005		0132	2000	K2000,	2000
0081	0006	K0006,	0006		0131	1777	K1777,	1777
0082	0007	K0007,	0007		0130	1026	K1026,	1026
0083	0008	K0008,	0008		0129	1000	K1000,	1000
0084	0009	K0009,	0009		0128	0777	K0777,	0777
0085	0010	K0010,	0010		0127	0700	K0700,	0700
0086	0011	K0011,	0011		0126	0600	K0600,	0600
0087	0012	K0012,	0012		0125	0500	K0500,	0500
0088	0013	K0013,	0013		0124	0400	K0400,	0400
0089	0014	K0014,	0014		0123	0377	K0377,	0377
0090	0015	K0015,	0015		0122	0300	K0300,	0300
0091	0016	K0016,	0016		0121	0240	K240,	0240
0092	0017	K0017,	0017		0120	0200	K0200,	0200
0093	0018	K0018,	0018		0119	0277	K0277,	0277
0094	0019	K0019,	0019		0118	0200	K0200,	0200
0095	0020	K0020,	0020		0117	0177	K0177,	0177
0096	0021	K0021,	0021		0116	0100	K0100,	0100
0097	0022	K0022,	0022		0115	0100	K0100,	0100
0098	0023	K0023,	0023		0114	0077	K0077,	0077
0099	0024	K0024,	0024		0113	0060	K0060,	0060
0100	0025	K0025,	0025		0112	0040	K0040,	0040
0101	0026	K0026,	0026		0111	0030	K0030,	0030
0102	0027	K0027,	0027		0110	0020	K0020,	0020
0103	0028	K0028,	0028		0109	0017	K0017,	0017
0104	0029	K0029,	0029		0108	0017	K0017,	0017
0105	0030	K0030,	0030		0107	0017	K0017,	0017
0106	0031	K0031,	0031		0106	0017	K0017,	0017
0107	0032	K0032,	0032		0105	0015	K0015,	0015
0108	0033	K0033,	0033		0104	0014	K0014,	0014
0109	0034	K0034,	0034		0103	0012	K0012,	0012
0110	0035	K0035,	0035		0102	0010	K0010,	0010
0111	0036	K0036,	0036		0101	0007	K0007,	0007
0112	0037	K0037,	0037		0100	0004	K0004,	0004
0113	0038	K0038,	0038		0099	0003	K0003,	0003
0114	0039	K0039,	0039		0098	0003	K0003,	0003
0115	0040	K0040,	0040		0097	0002	K0002,	0002
0116	0041	K0041,	0041		0096	0001	K0001,	0001
0117	0042	K0042,	0042		0095	0001	K0001,	0001
0118	0043	K0043,	0043		0094	0001	K0001,	0001
0119	0044	K0044,	0044		0093	0001	K0001,	0001
0120	0045	K0045,	0045		0092	0001	K0001,	0001
0121	0046	K0046,	0046		0091	0001	K0001,	0001
0122	0047	K0047,	0047		0090	0001	K0001,	0001
0123	0048	K0048,	0048		0089	0001	K0001,	0001
0124	0049	K0049,	0049		0088	0001	K0001,	0001
0125	0050	K0050,	0050		0087	0001	K0001,	0001
0126	0051	K0051,	0051		0086	0001	K0001,	0001
0127	0052	K0052,	0052		0085	0001	K0001,	0001
0128	0053	K0053,	0053		0084	0001	K0001,	0001
0129	0054	K0054,	0054		0083	0001	K0001,	0001
0130	0055	K0055,	0055		0082	0001	K0001,	0001
0131	0056	K0056,	0056		0081	0001	K0001,	0001
0132	0057	K0057,	0057		0080	0001	K0001,	0001
0133	0058	K0058,	0058		0079	0001	K0001,	0001
0134	0059	K0059,	0059		0078	0001	K0001,	0001
0135	0060	K0060,	0060		0077	0001	K0001,	0001
0136	0061	K0061,	0061		0076	0001	K0001,	0001
0137	0062	K0062,	0062		0075	0001	K0001,	0001
0138	0063	K0063,	0063		0074	0001	K0001,	0001
0139	0064	K0064,	0064		0073	0001	K0001,	0001
0140	0065	K0065,	0065		0072	0001	K0001,	0001
0141	0066	K0066,	0066		0071	0001	K0001,	0001
0142	0067	K0067,	0067		0070	0001	K0001,	0001
0143	0068	K0068,	0068		0069	0001	K0001,	0001
0144	0069	K0069,	0069		0068	0001	K0001,	0001
0145	0070	K0070,	0070		0067	0001	K0001,	0001
0146	0071	K0071,	0071		0066	0001	K0001,	0001
0147	0072	K0072,	0072		0065	0001	K0001,	0001
0148	0073	K0073,	0073		0064	0001	K0001,	0001
0149	0074	K0074,	0074		0063	0001	K0001,	0001
0150	0075	K0075,	0075		0062	0001	K0001,	0001
0151	0076	K0076,	0076		0061	0001	K0001,	0001
0152	0077	K0077,	0077		0060	0001	K0001,	0001
0153	0078	K0078,	0078		0059	0001	K0001,	0001
0154	0079	K0079,	0079		0058	0001	K0001,	0001
0155	0080	K0080,	0080		0057	0001	K0001,	0001
0156	0081	K0081,	0081		0056	0001	K0001,	0001
0157	0082	K0082,	0082		0055	0001	K0001,	0001
0158	0083	K0083,	0083		0054	0001	K0001,	0001
0159	0084	K0084,	0084		0053	0001	K0001,	0001
0160	0085	K0085,	0085		0052	0001	K0001,	0001
0161	0086	K0086,	0086		0051	0001	K0001,	0001
0162	0087	K0087,	0087		0050	0001	K0001,	0001
0163	0088	K0088,	0088		0049	0001	K0001,	0001
0164	0089	K0089,	0089		0048	0001	K0001,	0001
0165	0090	K0090,	0090		0047	0001	K0001,	0001
0166	0091	K0091,	0091		0046	0001	K0001,	0001
0167	0092	K0092,	0092		0045	0001	K0001,	0001
0168	0093	K0093,	0093		0044	0001	K0001,	0001
0169	0094	K0094,	0094		0043	0001	K0001,	0001
0170	0095	K0095,	0095		0042	0001	K0001,	0001
0171	0096	K0096,	0096		0041	0001	K0001,	0001
0172	0097	K0097,	0097		0040	0001	K0001,	0001
0173	0098	K0098,	0098		0039	0001	K0001,	0001
0174	0099	K0099,	0099		0038	0001	K0001,	0001
0175	0100	K0100,	0100		0037	0001	K0001,	0001
0176	0101	K0101,	0101		0036	0001	K0001,	0001
0177	0102	K0102,	0102		0035	0001	K0001,	0001
0178	0103	K0103,	0103		0034	0001	K0001,	0001
0179	0104	K0104,	0104		0033	0001	K0001,	0001
0180	0105	K0105,	0105		0032	0001	K0001,	0001
0181	0106	K0106,	0106		0031	0001	K0001,	0001
0182	0107	K0107,	0107		0030	0001	K0001,	0001
0183	0108	K0108,	0108		0029	0001	K0001,	0001
0184	0109	K0109,	0109		0028	0001	K0001,	0001
0185	0110	K0110,	0110		0027	0001	K0001,	0001
0186	0111	K0111,	0111		0026	0001	K0001,	0001
0187	0112	K0112,	0112		0025	0001	K0001,	0001
0188	0113	K0113,	0113		0024	0001	K0001,	0001
0189	0114	K0114,	0114		0023	0001	K0001,	0001
0190	0115	K0115,	0115		0022	0001	K0001,	0001
0191	0116	K0116,	0116		0021	0001	K0001,	0001
0192	0117	K0117,	0117		0020	0001	K0001,	0001
0193	0118	K0118,	0118		0019	0001	K0001,	0001
0194	0119	K0119,	0119		0018	0001	K0001,	0001
0195	0120	K0120,	0120		0017	0001	K0001,	0001
0196	0121	K0121,	0121		0016	0001	K0001,	0001
0197	0122	K0122,	0122		0015	0001	K0001,	0001
0198	0123	K0123,	0123		0014	0001	K0001,	0001
0199	0124	K0124,	0124		0013	0001	K0001,	0001
0200	0125	K0125,	0125		0012	0001	K0001,	0001
0201	0126	K0126,	0126		0011	0001	K0001,	0001
0202	0127	K0127,	0127		0010	0001	K0001,	0001
0203	0128	K0128,	0128		0009	0001	K0001,	0001
0204	0129	K0129,	0129		0008	0001	K0001,	0001
0205	0130	K0130,	0130		0007	0001	K0001,	0001
0206	0131	K0131,	0131		0006	0001	K0001,	0001
0207	0132	K0132,	0132		0005	0001	K0001,	0001
0208	0133	K0133,	0133		0004	0001	K0001,	0001
0209	0134	K0134,	0134		0003	0001	K0001,	0001
0210	0135	K0135,	0135		0002	0001	K0001,	00

/PAGE 0 NEGATIVE CONSTANTS

/PDP-12 KMH2A CLOCK TEST, MAINDC 12=DECC-L PAL18 V14

፭፻፰፯፻፲፷፻

6813

白 3

0217	7300	JMS 1	TS111,	CLB CLL	/CLEAR AC	DGA	SEND	/9 SEND REG	0220	7300	JMS 1	TS110,	CLB CLL	/RING BELL	BELL	REGA	/CLEAR AC	0221	7300	JMS 1	TS110,	CLB CLL	/CLEAR AC	TAD	REGA	/SUBTRACT SEND	0222	7240	CIA	SET BUFFER AND RESET REGISTER TO 00000	CLB CMA	/SET BUFFER AND RESET REGISTER TO 00000	TAD	RXED	/JAM BUFFER PRESET (0000) OVER AC (7777	0223	6133	CIA	/SET BUFFER AND RESET REGISTER TO 00000	CLB CMA	/SET BUFFER AND RESET REGISTER TO 00000	DGA	RXED	/JAM BUFFER PRESET (0000) OVER AC (7777	0224	6133	CIA	/SET BUFFER AND RESET REGISTER TO 00000	CLB CMA	/SET BUFFER AND RESET REGISTER TO 00000	DGA	RXED	/JAM BUFFER PRESET (0000) OVER AC (7777	0225	6136	CIA	/SET BUFFER AND RESET REGISTER TO 00000	CLB CMA	/SET BUFFER AND RESET REGISTER TO 00000	DGA	RXED	/JAM BUFFER PRESET (0000) OVER AC (7777	0226	7240	CIA	/SET BUFFER AND RESET REGISTER TO 00000	CLB CMA	/SET BUFFER AND RESET REGISTER TO 00000	DGA	RXED	/JAM BUFFER PRESET (0000) OVER AC (7777	0227	4430	JMS 1	ERROR	CLBAC	/CHECK MONITOR	SNA CLA	REGD	/OLD AC BECOME (0000)7	0228	4430	JMS 1	ERROR	CLBAC	/CHECK MONITOR	SNA CLA	REGD	/OLD AC BECOME (0000)7	0229	5301	JMS 1	ERROR	CLBAC	/CLEAR AC	TAD	REGD	/RESET FAILED TO JAM THE AC	0230	7402	HLT	/ERROR HALT	CLBAC	/CLEAR AC	TAD	REGD	/RESET FAILED TO JAM THE AC	0231	5301	HLT	/ERROR HALT	CLBAC	/CLEAR AC	TAD	REGD	/RESET FAILED TO JAM THE AC	0232	7610	SKP CLA	/T0 NEXT TEST	CLBAC	/CLEAR AC	TAD	REGD	/RESET FAILED TO JAM THE AC	0233	0217	TS111	/ISZ LOOP! SCOPE LOOP	CLBAC	/CLEAR AC	TAD	REGD	/RESET FAILED TO JAM THE AC
------	------	-------	--------	---------	-----------	-----	------	-------------	------	------	-------	--------	---------	------------	------	------	-----------	------	------	-------	--------	---------	-----------	-----	------	----------------	------	------	-----	--	---------	---	-----	------	---	------	------	-----	---	---------	---	-----	------	---	------	------	-----	---	---------	---	-----	------	---	------	------	-----	---	---------	---	-----	------	---	------	------	-----	---	---------	---	-----	------	---	------	------	-------	-------	-------	----------------	---------	------	------------------------	------	------	-------	-------	-------	----------------	---------	------	------------------------	------	------	-------	-------	-------	-----------	-----	------	-----------------------------	------	------	-----	-------------	-------	-----------	-----	------	-----------------------------	------	------	-----	-------------	-------	-----------	-----	------	-----------------------------	------	------	---------	---------------	-------	-----------	-----	------	-----------------------------	------	------	-------	-----------------------	-------	-----------	-----	------	-----------------------------

/PPG=12 KW12A CLOCK TEST, MAINDING 12-D6CC=6
 /DOES THE AC JAM INTO THE BUFFER
 0233 7240 TST122, CLA CHA /SELECT AC#7797
 0236 6233 CLAB /SELECT BUFFER#7777
 0237 7300 CLA CLB /CLEAR AC
 0240 6233 CLAB SEND /LOAD BUFFER TO ALL ZEROS
 0241 3054 DCA /SAVE AC
 0242 6236 CLBA /READ BUFFER AND PRESET REGISTER
 0243 3053 DCA RXED /SAVE TEST VALUE
 0244 1033 TAD RXED /RESET REGISTER GET CLEARED
 0245 7650 SNA CLA /DIO BUFFER AND PRESET REGISTER GET CLEARED
 0246 4430 JMS I ERROR /CLEAR MONITOR
 0247 5317 TST12M /AC JAM INTO BUFFER FAILED
 0248 7402 HLT /MESSAGE POINTERT
 0249 4426 JMS I ERROR /CLEAR MONITOR
 0250 6233 CLAB /GET TEST NUMBER
 0255 1046 TAD RXED /CLEAR AC
 0256 6233 CLAB /SEND IT
 0257 7200 CLA /CLEAR AC
 0258 6233 CLAB /SEND IT
 0259 6136 CLBA /RETRIEVE IT
 0260 6136 CLA /CLEAR AC
 0261 3053 DCA RXED /SAVE IT
 0262 1253 TAD RXED /RESUME IT
 0263 7041 CIA /COMPLEMENT
 0264 1046 TAD RXED /ADD TEST NUMBER
 0265 7650 SNA CLA /CLEAR MONITOR
 0266 4430 JMS I ERROR /WRITER THEY EQUAL?
 0267 5335 TST12M /MESSAGE POINTERT
 0268 7602 HLT /ERROR HALT
 0270 4426 JMS I ERROR /AG= BUFFER TO AC DATA TRANSFER FAILED
 0271 5345 TST123 /ISZ LOOP1 SCOPE LOOP
 0272 7610 SKP CLA /TO NEXT TEST
 0273 0254 TST123 /ISZ LOOP1 SCOPE LOOP

PAGE 6
 26-JUL-78
 1129
 PAGE 6

/POP-12 KM12A CLOCK TEST, MAINDEC 12-08CC-L
 /PAGE 7
 1129 82-JUL-78 V141 PAL10
 /00 RANDOM NUMBERS TRANSFER BETWEEN AG AND BUFFER PROGRESSIVELY
 /
 0274 4445 TST14, JMS I RANDOM
 /LOAD BUFFER AND RESET REGISTER WITH A RANDOM NUMBER
 0275 3054 DCA SEND
 /SAVE IT
 0276 1054 TAD SEND
 /RESTORE IT
 0277 6133 CLAB SEND
 /SEND IT
 0278 4445 JMS I RANDOM
 /LOAD THE AC WITH A RANDOM NUMBER
 0279 3053 DCA RXED
 /READ BACK RANDOM NUMBER FROM BUFFER RESET REGISTER
 0280 6136 CLBA SEND
 /SAVE TEST RETURN
 0281 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0282 3052 DCA RXED
 /RESTORE IT
 0283 6133 TAD SEND
 /SAVE IT
 0284 4445 CLAB SEND
 /SEND IT
 0285 3053 TAD SEND
 /RESTORE IT
 0286 6136 CLBA SEND
 /SEND IT
 0287 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0288 3052 DCA RXED
 /RESTORE IT
 0289 6133 TAD SEND
 /SAVE IT
 0290 4445 CLAB SEND
 /SEND IT
 0291 3053 TAD SEND
 /RESTORE IT
 0292 6136 CLBA SEND
 /SEND IT
 0293 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0294 3052 DCA RXED
 /RESTORE IT
 0295 6136 CLBA SEND
 /SEND IT
 0296 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0297 3053 DCA RXED
 /RESTORE IT
 0298 6136 CLBA SEND
 /SEND IT
 0299 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0300 3053 DCA RXED
 /RESTORE IT
 0301 6136 CLBA SEND
 /SEND IT
 0302 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0303 3053 DCA RXED
 /RESTORE IT
 0304 6136 CLBA SEND
 /SEND IT
 0305 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0306 3053 DCA RXED
 /RESTORE IT
 0307 6136 CLBA SEND
 /SEND IT
 0308 4445 JMS I ERROR
 /CHECK MONITOR
 0309 3053 TAD SEND
 /SUBTRACT TEST NUMBER
 0310 6136 CLBA SEND
 /SEND IT
 0311 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0312 3053 TAD SEND
 /RESTORE IT
 0313 6136 CLBA SEND
 /SEND IT
 0314 4445 JMS I ERROR
 /CHECK MONITOR
 0315 3053 TAD SEND
 /GET RANDOM NUMBER
 0316 4445 TST13, JMS I RANDOM
 /DOES READING THE BUFFER CHANGE ITS CONTENTS?
 /
 0317 3054 TAD SEND
 /SAVE IT
 0318 4445 CLAB SEND
 /RESTORE IT
 0319 3054 TAD SEND
 /GET RANDOM NUMBER
 0320 4445 TAD SEND
 /RESTORE IT
 0321 3054 TAD SEND
 /RESTORE IT
 0322 6136 CLBA SEND
 /LOAD AC WITH A RANDOM NUMBER
 0323 4445 JMS I RANDOM
 /BRING BACK TEST NUMBER
 0324 3053 TAD SEND
 /RESTORE IT
 0325 6136 CLBA SEND
 /READ BUFFER AGAIN
 0326 4445 JMS I RANDOM
 /LOAD AC WITH A RANDOM NUMBER
 0327 3053 TAD SEND
 /RESTORE IT
 0328 6136 CLBA SEND
 /SAVE VALUE
 0329 4445 JMS I ERROR
 /CHECK MONITOR
 0330 3053 TAD SEND
 /SUBTRACT TEST NUMBER
 0331 6136 CLBA SEND
 /SEND IT
 0332 4445 JMS I ERROR
 /MESSAGE POINTERT
 0333 3053 TAD SEND
 /CLBA CHANGED THE CONTENTS OF THE BUFFER
 0334 6136 CLBA SEND
 /TO NEXT TEST
 0335 4445 JMS I ERROR
 /ERROR HALT
 0336 3053 TAD SEND
 /SKP CLA
 0337 6136 CLBA SEND
 /192 LOOP! SCOPE LOOP

/CAN THE GATES FUNCTION AT HIGH SPEED?

0340	7300	15T16.	CLA C1L	/CLEAR AC		
0341	1046	TAD	REGA	/SET TEST NUMBER		
0342	6233	CLA8		/SEND IT		
0343	6236	CLA8		/GET IT		
0344	6233	CLA8				
0345	6236	CLA8				
0346	6233	CLA8				
0347	6236	CLA8				
0348	6233	CLA8				
0349	6236	CLA8				
0350	6233	CLA8				
0351	6236	CLA8				
0352	6233	CLA8				
0353	6236	CLA8				
0354	6233	CLA8				
0355	6236	CLA8				
0356	6233	CLA8				
0357	6236	CLA8				
0358	6233	CLA8				
0359	6236	CLA8				
0360	6233	CLA8				
0361	6236	CLA8				
0362	6233	CLA8				
0363	6236	CLA8				
0364	6233	CLA8				
0365	6236	CLA8				
0366	6233	CLA8				
0367	6236	CLA8				
0368	2053	DCA	RXED	/SEND IT		
0369	1046	TAD	REGA	/GET IT		
0370	7041	CIA	RXED	/PETCH IT		
0371	1053	TAD	REGA	/COMPLEMENT		
0372	7042	CIA	RXED	/S4VE IT		
0373	1046	DCA	RXED	/GATE IT		
0374	7650	SNA CLA		/EQUAL?		
0375	4430	JMS I	ERROR	/CHECK MONITOR		
0376	4426	JMS I	ERROR	/BUF FAILED TO TGGLE AT HIGH SPEED		
0377	5413	T5T16M		/MESSAGE POINTER		
0378	7402	HLT		/ERROR HALT		
0379	7610	SKP CLA		/TO NEXT TEST		
0401	7610	T5T16		/ISZ LOOP! SCOPE LOOP		
0402	0340					

/CAN TIME BUFFER SURVIVE RANDOM ELEMENT PATTERNING

8 /

CC#6 PA610 V642 26=JULY=70 D663 22

/ DO RANDOM NUMBERS TRANSFER BETWEEN BUFFER AND COUNTER

/DOES READING THE COUNTER CHANGE ITS STATE
 0753 4445 T5T25!, JMS I RANDOM /GET RANDOM TEST NUMBER
 0754 6133 CLAB DGA SEN0 /SEND IT TO BUFFER
 0755 3834 CLAB DGA SEN0 /SAVE IT
 0756 6132 CLB R K0100 /STOP CLOCK, SET ALL MODES=0
 0757 1214 TAD K0100 /SET AC 05#1
 0760 6132 CLB R K0100 /GENERATE CLR CNT#
 0761 6135 CLA /CLEAR CLOCK STATUS
 0762 7208 CLA /CLEAR AC
 0763 1116 TAD K0200 /8#7 AC 04#1
 0764 6134 CLB R K0200 /GENERATE LOAD CNT#
 0765 4445 JMS I RANDOM /GET RANDOM NUMBER
 0766 6133 CLB R K0200 /SEND IT TO BUFFER
 0767 4445 JMS I RANDOM /GET RANDOM NUMBER
 0768 6133 CLB R K0200 /LOAD CNT#
 0769 4445 JMS I RANDOM /GET RANDOM NUMBER
 0770 6133 CLB R K0200 /CLEAR AC
 0771 4445 JMS I RANDOM /READ CLOCK COUNTER
 0772 6133 CLB R K0200 /GET RANDOM NUMBER
 0773 4445 JMS I RANDOM /SEND IT TO BUFFER
 0774 6133 CLA /CLEAR CLOCK COUNTER
 0775 3853 DGA RXE0 /SAVE IT
 0776 1033 TAD RXE0 /RESTORE IT
 0777 7841 CIA /COMPLEMENT
 0778 1034 TAD SEN0 /SUBTRACT TEST NUMBER
 0779 1034 TAD SNA GBA /EQUAL?
 0780 7650 JMS I ERROR /CHECK MONITOR
 0781 4438 JMS I ERROR //GLCA) READ THE COUNTER CHANGES THE COUNTERS STATE
 0782 5632 T8T25M HLT /MESSAGE POINTERS
 0783 7402 HLT /ERROR HALT
 0784 5632 T8T25M HLT /ISZ LOOP! SCOPE LOOP
 0785 8753 SKP CLA TS25 /70 NEXT TEST
 0786 7610 SKP CLA TS25 /82 NEXT TEST
 0787 8753 CLA CLA RE6A /RESET COUNTER FOR NEXT TEST
 0788 7340 CLA CLA RE6A /SET AC#7777

VOCAN THE BUF TO COUNTER AND COUNTBUF TO GUE FUNCTION AT HIGH SPEED

1042	1045	1012	1013	1014	1015	1016	1017	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032	1033	1034	1035	1036	1037	1038	1039	1040
1042	1045	1012	1013	1014	1015	1016	1017	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032	1033	1034	1035	1036	1037	1038	1039	1040
1042	1045	1012	1013	1014	1015	1016	1017	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032	1033	1034	1035	1036	1037	1038	1039	1040
1042	1045	1012	1013	1014	1015	1016	1017	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032	1033	1034	1035	1036	1037	1038	1039	1040
1042	1045	1012	1013	1014	1015	1016	1017	1018	1019	1020	1021	1022	1023	1024	1025	1026	1027	1028	1029	1030	1031	1032	1033	1034	1035	1036	1037	1038	1039	1040

/TEST LOAD CNT GENERATION GATES (CLR CLOCK RATE) MODE 2 (0)

4443	4443	TST29, JMS I	RANDOM	/GET RANDOM NUMBER	/TEST LOAD CNT GENERATION GATES (CLR CLOCK RATE) MODE 1(1)
4443	4443	JMS I	CLAB	SEND	/SEND IT TO BUFFER
4443	4443	DCA	SEND	/SAVE IT	
4443	4443	TAD	K0600	/SET AC 04,05&1	
4443	4443	CLR		/CLEAR CLR CNTn, SET MODE 1 AND 2 &1	
4443	4443	CLSA		/CLEAR CLOGK STATUS	
4443	4443	TAD	K0200	/TRY TO GENERATE "LOAD CNT"	
4443	4443	CLGA		/READ COUNTTER	
4443	4443	DGA	RXED	/SLAVE TEST VALUE	
4443	4443	TAD	RXED	/D TURE IT	
4443	4443	SNA CLA		/MESSAGE POINTER	
4443	4443	JMS I	ERROR	/LOAD CNT GATES FUNCTIONED WITH MODE 1&1 IN ERROR	
4443	4443	TST29M		/CHECK MONITOR	
4443	4443	HLT		/ERROR HALT	
4443	4443	SKP CLA		/IS2 LOOP! SCOPE LOOP	
4443	4443	TST29		/SET AC=7777	
4443	4443	CLA CLR CMA		/PRESET REGA FOR NEXT TEST	
4443	4443	DCA	REGA		

/GLITCH TEST OF LOAD CNT GATES

1156	4445	TST30, JMS I	RANDOM	/GET RANDOM NUMBER				
1157	6133	CLAB		/SEND IT TO BUFFER				
1160	3054	DCA	SEND	/SAVE IT				
1161	1116	TAD	K0200	/SET AC 04,04,05#1				
1162	6132	CLR		/SET MODE 1#1				
1163	7200	CLA		/CLEAR AC				
1164	1120	TAD	K0300	/SET AC 04,04,05#1				
1165	6132	CLR		/SET MODE 2#1				
1166	7200	CLA		/CLEAR AC				
1167	2047	JMP	,#7	/BACK 4096 TIMES				
1168	3053	ISZ	REG8	/DONE#7				
1171	6137	CLCA		/READ COUNTER				
1172	3053	DCA	RXED	/SAVE IT				
1173	1053	TAD	RXED	/RESTORE IT				
1174	7650	SNA CLA		/ERROR				
1175	4430	JMS I	NEEDR	/CHECK MONITOR				
1176	4426	JMS I	ERROR	/THE MODE REGISTER CAUSES ILLEGAL LOAD COUNTER				
1177	5774	TST30H		/MESSAGE POINTER				
1178	2402	HLT		/ERROR HALT				
1179	7200	CLB		/TO NEXT TEST				
1180	1156	T8T30		/182 LOOP SCOPE LOOP				
1181	7200	CLB		/SET AC#7777				
1182	3046	CLB CLB CHA		/RESET REGA FOR NEXT TEST				
1183	7340	DGA	REGA					
1184	3046							

1205 4445 TST31, JMS I RANDDOM /GET RANDOM NUMBER
 1226 6433 CLA8 DCA SEND /SEND IT TO BUFFER
 1207 3854 DCA SEND /SAVE IT
 1210 1D47 TAD REGB /GET TEST CENTER
 1211 7006 RTL RTL /ROTATE TWO LEFT
 1212 7006 RTL RTL /ROTATE TWO LEFT
 1213 7006 RTL RTL /ROTATE TWO LEFT
 1214 C1325 AND K0700 /INSURE THAT MODE 0,1,2,3
 1215 6132 CLR K0700 /SEND RANDOM NUMBER TO CONTROL REGISTER
 1216 7040 CMA K0700 /INSURE THAT MODE 0,1,2,3
 1217 3125 AND K0700 /INSURE THAT MODE 0,1,2,3
 1220 6133 CLR K0700 /SET TO COMPLEMENT OF THE NUMBER
 1221 2047 JMS REGB TST31=3
 1222 5219 JMP TS21=3
 1223 6136 CLR K0700 /DONE?
 1224 3053 DCA RXED /RESTORE IT
 1225 1053 TAD RXED /COMPLEMENT
 1226 7041 CIA SEND /SUBTRACT TEST NUMBER
 1227 1054 TAD S2A CLA /EQUAL?
 1228 7640 CIA SEND /SUBTRACT TEST NUMBER
 1229 5237 JMP .#6 /JMP
 1230 7640 S2A CLA /BUF CHANGED IN ERROR
 1231 5237 CLCA REGB /READ CENTER
 1232 3047 DCA REGB /BUFP CHANGED IN ERROR
 1233 6437 CLCA REGB /BUFP CHANGED IN ERROR
 1234 1047 TAD REGB /RESTORE IT
 1235 7650 CIA CLA /STILL ERROR
 1236 4430 JMS I ERROR /CHECK MONITOR
 1237 4426 JMS I ERROR //MESSAGE POINTER CHANGED IN ERROR
 1240 6021 TST31M HLT //ERROR HALT
 1241 7902 TS21=3 CLA //TO NEXT TEST
 1242 7800 TS21=3 CLA //ISZ LOOP SCOPE LOOP
 1243 1205 TS21=3 CLA //CLEAR FOR NEXT ISZ LOOP
 1244 3047 DCA REGB

1245 4445	1114	T5T32, JMS I	RANDOM	/GET RANDOM NUMBER	/DOES MODE 2 4=0 CLK CNT?
1246 6133	6132	CLRA	SEND	/SEND IT TO BUFFER	
1247 3054	3052	CLRA	SEND	/SAVE IT	
1248 6133	6132	CLRA	SEND	/ZERO MODE 2	
1249 4445	1114	TAD	K0200	/AC 0941	
1250 6132	6132	CLRA	SEND	/CLEAR AC	
1251 1114	1114	TAD	K0200	/AC 0941	
1252 6132	6132	CLRA	SEND	/CLEAR STATUS	
1253 6133	6133	CLSA	SEND	/GENERATE HCLR CNT?	
1254 7200	7200	CLSA	SEND	/CLEAR RATE LOAD CNT?	
1255 1116	1116	TAD	K0200	/SET AC 0481	
1256 6134	6134	CLSA	SEND	/CLEAR AC	
1257 7200	7200	CLSA	SEND	/CLEAR RATE LOAD CNT?	
1258 6132	6132	CLRA	SEND	/CLEAR STATUS	
1259 1114	1114	TAD	K0200	/AC 0941	
1260 6133	6133	CLSA	SEND	/CLEAR RATE LOAD CNT?	
1261 6132	6132	CLRA	SEND	/CLEAR STATUS	
1262 3053	3053	CLAB	RXED	/SAVE IT	
1263 6133	6133	CLAB	RXED	/CLEAR BUF OR OVERFLOW WILL RELOAD CNT	
1264 11053	11053	TAD	RXED	/RESTORE IT	
1265 7041	7041	TAD	RXED	/CLEARBUF	
1266 2666	2666	CLAB	RXED	/CLEARBUF	
1267 7650	7650	TAD	SEND	/SUBTRACT TEST NUMBER	
1268 6056	6056	TAD	SEND	/CLEARBUF	
1269 4426	4426	JMS I	ERROR	/CHECK MONITOR	
1270 7402	7402	TAD	RXED	/MESSAGE POINTER	
1271 1245	1245	JMS I	ERROR	/MODE 2 1=0 DID IT	
1272 7402	7402	TAD	RXED	/MESSAGE POINTER	
1273 7410	7410	JMS I	ERROR	/MODE 2 1=0 DID IT	
1274 7410	7410	JMS I	ERROR	/CLEAR HALT	
1275 1245	1245	TAD	RXED	/IS2 LOOP1 SCOPE LOOP	
1276 1114	1114	TAD	K0200	/SET AC 0541	
1277 6132	6132	CLLR	SEND	/GENRATE HCLR CNT?	
1278 6132	6132	CLLR	SEND	/CLEAR COUNT	
1279 7402	7402	TAD	RXED	/CLEAR RATE LOAD CNT?	
1280 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1281 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1282 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1283 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1284 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1285 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1286 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1287 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1288 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1289 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1290 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1291 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1292 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1293 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1294 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1295 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1296 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1297 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1298 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1299 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1300 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1301 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1302 7402	7402	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1303 7650	7650	SNA CLA	SEND	/IS2 LOOP1 SCOPE LOOP	
1304 4430	4430	TAD	RXED	/RESTORE IT	
1305 4426	4426	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1306 6102	6102	HLT	SEND	/CLEAR RATE LOAD CNT?	
1307 7402	7402	TST33M	SEND	/CLEAR RATE LOAD CNT?	
1308 7402	7402	SKP	SEND	/CLEAR RATE LOAD CNT?	
1309 7410	7410	TAD	RXED	/CLEAR RATE LOAD CNT?	
1310 7410	7410	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1311 7410	7410	JMS I	ERROR	/CLEAR RATE LOAD CNT?	
1312 1276	1276	TST33	SEND	/CLEAR RATE LOAD CNT?	

/PDP KML2A CLOCK TEST, MAINDEC 12-08CC-6 PAGE 25
 21-JUL-70 V242 PAL10
 21-JUL-70 V242 PAL10
 /
 /DOES COUNTER OVERFLOW SET OVERFLOW FLOOR?
 /
 1312 7300 TST34, CLA CLL
 /CLEAR AC
 1313 6132 CLLR TA0 K0100
 /CLEAR STATUS
 /SET AC 0591
 1314 1114 TA0 K0100
 /CLEAR STATUS
 /SET AC 0591
 1315 6132 CLLR TA0 K0100
 /CLEAR STATUS
 /SET AC 0591
 1316 6135 CLSA CLA CLL CHL RAR
 /CLEAR CLOCK STATUS
 /SET AC 0400
 1317 7330 CLSA CLA CLL
 /CLEAR AC
 1318 6133 CLAB CLA CLL
 /CLEAR AC
 1319 6134 CLEN TA0 K0200
 /LOAD CNT (00)@111 TO OVERFLOW
 1320 7300 CLA CLL
 /CLEAR AC
 1321 6135 CLAB CLA CLL
 /CLEAR AC
 1322 1116 TA0 K0200
 /CLEAR AC
 1323 6134 CLEN TA0 K0200
 /CLEAR AC
 1324 7300 CLA CLL
 /CLEAR AC
 1325 6135 CLAB CLA CLL
 /CLEAR AC
 1326 6132 CLLR TA0 K0100
 /CLEAR STATUS
 /SET AC 0400
 1327 1114 TA0 K0100
 /CLEAR AC
 1328 6133 CLAB CLA CLL
 /CLEAR AC
 1329 6134 CLA CLL
 /CLEAR AC
 1330 7300 CLA CLL
 /CLEAR AC
 1331 6135 CLAB CLA CLL
 /CLEAR AC
 1332 1114 TA0 K0100
 /CLEAR AC
 1333 4435 SPA CLA
 /OVERFLOW SET
 /CLEAR MONITOR
 /OVERFLOW NOT SET
 1334 4426 JMS 1 ERROR
 /CLEAR POINTER
 /MESSAGING POINT
 /TEST
 1335 6126 7402 HLT
 /ERROR HALT
 1336 7402 SKP
 /TEST
 1337 7410 TST34
 /SET AC 7777
 /RESET COUNT FOR NEXT TEST
 1338 7412 CLA CLL
 /ISZ LOOP! SCOPE LOOP
 1339 7400 DCA SEND
 /RESET SEND
 1340 7410 CLA CLL
 /SET AC 7777
 1341 7400 DCA SEND
 /RESET SEND
 1342 7400 DCA CLL
 /CLA CLL
 1343 7340 CLA CLL CHA
 /SET AC 7777
 1344 3046 DCA REGA
 /RESET ISZ COUNTER FOR NEXT TEST


```

1421 7300 TSTS6, CLA CLR      /TEST OVERFLOW SKIP
1422 6132 CLBR      /CLEAR ALL MODES
1403 1114 TAD      K0200      /CLEAR AC
1404 6132 CLBR      /CLEAR AC 0954
1405 6135 CLSA      /CLEAR LOCK STATUS
1406 7335 CLA CLR CHL RAR  /SET AC 094000 OCTAL
1407 6135 CLAB      /SET BUFFER 0C84000
1408 7336 CLA CLR      /CLEAR GNT
1411 1116 TAD      K0200      /CLEAR AC
1412 6134 CLEN      /GEN CLR GNT
1413 7300 CLA CLR      /CLEAR GNT
1414 6133 CLA CLR      /CLEAR GUF
1415 6132 CLBR      /CLEAR ALL MODES
1416 1114 TAD      K0200      /CLEAR AC
1417 6132 CLBR      /CLEAR AC 09341
1420 7300 CLA CLR      /GEN LOAD GNT
1421 6131 CLSK      /CLEAR AC
1422 4535 JMS I ERROR    /CLEAR MONITOR
1423 6131 CLSK      /OVERFLOW SET
1424 6177 T9173CH    /LOGON PRESSET DIDN'T 0 OVERFLOW ENABLE
1425 7402 HLT       /ERROR HALT
1426 7410 SKP       /NEXT TEST
1427 4401 TS736     /IISZ LOGP1 SCOPE LOOP
1428 7540 CLA CLR CHL CMA  /SET AC 7777
1429 3846 DCA       /RESET REGA FOR NEXT TEST
1430 7540 CLA CLR CHL CMA  /SET AC 7777
1431 3846 DCA       /RESET REGA FOR NEXT TEST
1432 1033 TSTS7, TAD  PNTA      /GET RETURN POINTER TO LOCA
1433 2052 DCA       RETURN    //PUT IT IN INTERRUPT HANDLER
1434 6001 ION       NOP        //ENABLE INTERRUPTS
1435 7000 IOB       /WAIT
1436 6002 NOP       /DISABLE INTERRUPTS
1437 4450 JMS I ERROR    //CHECK MONITOR
1438 7402 HLT       //MESSAGE POINT
1439 6217 LOGA, JMS I ERROR    //LEGAL INTERRUPT OVERFLOW AVERAGE OF ENABLED
1440 4426 JMS I ERROR    /IISZ LOGP1 SCOPE LOOP
1441 6217 LOGA, JMS I ERROR    /MESSAG
1442 7402 HLT       /NEXT TEST
1443 7410 SKP       /TO NEXT TEST
1444 1432 TS737    /IISZ LOGP1 SCOPE LOOP
1445 7340 CLA CLR CHL CMA  /SET AC 7777
1446 3246 DCA       /RESET REGA FOR NEXT TEST

```

1447 1114 TST38, TAD K2420 /SET INT ENABLE
 1450 6134 7300 CLEN CLA CLR /TURN ON CLOCK OVERFLOW INT
 1452 6131 7410 CLSK SKP /INTERRUPT SET
 1453 7410 4430 SKP JMS I ERROR /CHECK MONITOR
 1454 7410 4426 JMS I ERROR /TO HERE IF INTERRUPT NOT SET
 1455 6240 4426 JMS I ERROR /CLK FAILLED TO SKIP OVERFLOW IN INT
 1456 7402 9402 HLT TST38 /MESSAGE POINTER
 1457 7402 9402 HLT TST38 /ERROR HALT
 1458 6240 4426 JMS I ERROR /CLK FAILLED TO SKIP OVERFLOW IN INT
 1459 7410 4447 HLT TST38 /MESSAGE POINTER
 1460 7410 4447 HLT TST38 /ERROR HALT
 1461 7410 4447 HLT TST38 /SET AC 0531
 1462 7340 4426 JMS I ERROR /CLEAR AC
 1463 7340 4426 JMS I ERROR /CLEAR AG
 1464 7302 3032 TAD PNTB /GET RETURN POINTER TO LOGIC
 1465 6002 3032 TAD PNTB /PUT IT IN INTERRUPT HANDLER
 1466 6000 7000 IOB NOP /ENABLE INTERRUPTS
 1467 7000 6000 IOB NOP /WAIT
 1468 6002 7000 IOB NOP /DISABLE INTERRUPTS
 1469 7410 4430 SKP JMS I ERROR /CHECK WITH MONITOR
 1470 7410 4430 SKP JMS I ERROR /TO HERE IF NO INTERRUPT
 1471 7410 4430 SKP JMS I ERROR /LOGIC INT FAILED TO INTERRUPT
 1472 7410 4430 SKP JMS I ERROR /MESSAGE POINTER
 1473 4426 7426 LOGB, JMS I ERROR /LOGIC INT FAILED TO INTERRUPT
 1474 6257 7402 HLT TST39 /ERROR HALT
 1475 7402 7402 HLT TST39 /IS SCOPE LOOP
 1476 7410 2147 SKP JMS I ERROR /NEXT TEST
 1477 2147 7410 HLT TST39 /SET AC 07777
 1478 7410 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1479 7410 2147 HLT TST39 /SET AC 07777
 1480 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1481 3046 2147 HLT TST39 /SET AC 07777
 1482 7402 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1483 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1484 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1485 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1486 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1487 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1488 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1489 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1490 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1491 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1492 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1493 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1494 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1495 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1496 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1497 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1498 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1499 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1500 7340 2147 HLT TST39 /PRESET REGA FOR NEXT TEST
 1501 3046 2147 HLT TST39 /PRESET REGA FOR NEXT TEST

/COUNTINER CARRY TESTTING
 /COUNTINER PRESET SUCH THAT CLOCK CNTR RAISES BIT IN DUEBTION
 /DOES BIT 11 SET UP?
 /
 1553 7200 TSTA3, CLA
 /CLEAR AC
 1554 6132 CLR
 /CLEAR ALL MODES
 1555 6133 CLR
 /CLEAR BUF
 1556 6134 TAD
 /CLEAR AC 03&1
 1557 6135 CLR
 /GEN "CLR GNT"
 1558 6136 CLR
 /CLEAR STATUS
 1559 6137 CLR
 /CLEAR CNTR
 1560 6138 CLR
 /CLEAR SEND
 1561 7200 CLA
 /CLEAR AC
 1562 3025 DCA
 /CLEAR COUNTER
 1563 3094 DCA
 /CLEAR SEND
 1564 6133 CLA
 /CLEAR BUFFER
 1565 3116 TAD
 /HOLD 8
 1566 5134 CLEN
 /ENABLE MODE
 1567 7300 CLA CLL
 /CLEAR AC
 1568 2137 TAD K3108
 /SELECT 100 Hz RATE TO BE USED IN 457 43 70 VST 54
 1569 3053 DCA RXED
 /SAVE IT
 1570 2144 TAD RXED
 /PETCH IT
 1571 3144 TAD M8801
 /IP NOT, WAIT A WHILE
 1572 6132 CLR
 /ENABLE RATE
 1573 3053 DCA RXED
 /SAVE IT
 1574 3093 TAD M8801
 /IP NOT, WAIT A WHILE
 1575 7358 SNA CLA
 /SET1 GO CHECK MONITOR (1,4)
 1576 5135 JHP 1 UP43
 /THICK DONE?
 1577 5066 SNA CLA
 /SET1 GO CHECK MONITOR (1,4)
 1578 1144 TAD RXED
 /PETCH IT
 1579 1144 TAD M8801
 /BIT 11 AND ONLY BIT 11 SET?
 1580 2145 JHP 1 DN43
 /NO, GO BACK (1,7)
 1581 5422 CLR
 /HERE IF BAD B17
 1582 7416 FD43,
 JMS 1 ERROR
 /CHECK MONITOR
 1583 5360 TSTA3H
 /MESSAGE POINTER
 1584 4426 FD43,
 JMS 1 ERROR
 /BIT 11 FAILED TO GET SET BY A CLOCK PULSE
 1585 7416 CLR
 /TO NEXT TEST
 1586 7416 CLR
 /ERROR HALT
 1587 7416 CLR
 /NEXT SCOPE LOOP
 1588 7416 CLR
 /SET AG9777
 1589 7416 CLR
 /PRESENT REGA FOR NEXT TEST
 1590 7416 CLR
 /CLL CBL CMA
 1591 3046 DCA
 1592 7340 CLR
 1593 1553 CLR
 1594 7416 CLR
 1595 7416 CLR
 1596 7416 CLR
 1597 7416 CLR
 1598 7416 CLR
 1599 7416 CLR
 1600 7416 CLR
 1601 7416 CLR
 1602 7416 CLR
 1603 5360 CLR
 1604 4426 CLR
 1605 7416 CLR
 1606 7416 CLR
 1607 7416 CLR
 1608 7416 CLR
 1609 7416 CLR
 1610 7416 CLR
 1611 3046 CLR
 1612 3046 CLR

1653 7200 TSTA5, CLA
 /
 1654 6132 TSTA5, CLLR
 1655 6133 CLAB
 1656 1114 TAD
 1657 6132 CLLR
 1658 6133 CLAB
 1659 7200 CLA
 1660 6132 CLRA
 1661 7200 CLA
 1662 3025 CNTR
 1663 1077 TAD
 1664 6133 CLAB
 1665 3054 SEND
 1666 1116 TAD
 1667 6134 CLRN
 1668 7300 CLA
 1669 1116 K0200
 1670 7300 CLRN
 1671 1137 TAD
 1672 6132 CLLR
 1673 6137 CLCA
 1674 3033 RXED
 1675 1053 TAD
 1676 3146 TAD
 1677 7630 SNA CLA
 1678 1116 JMP
 1679 2025 ISZ
 1680 5304 JMP
 1681 7410 SKP
 1682 6416 JMS I
 1683 7410 ERROR
 1684 4430 CHECK MONITOR
 1685 3033 /BIT 09, AND ONLY BIT 09, SETT
 1686 1116 /BIT 09, AND ONLY BIT 09, SETT
 1687 3054 /RESET FOR BIT 09
 1688 1116 TAD
 1689 6133 CLAB
 1690 1116 K0003
 1691 7200 CLA
 1692 3025 CNTR
 1693 1077 TAD
 1694 6133 CLAB
 1695 3054 SEND
 1696 1116 TAD
 1697 6134 CLRN
 1698 7300 CLA
 1699 1116 K0200
 1700 7402 CLP
 1701 6416 JMS I
 1702 2025 EROR
 1703 7410 HLT
 1704 4430 /MESSAGE POINTGR
 1705 4426 /BIT 09 FAILED TO GET SET BY COUNTING
 1706 6416 /T0 NEXT TEST
 1707 7402 /ISZ LOOP SCOPE LOOP
 1708 1116 /SET ACB777
 1709 7410 /PRESET REGA FOR NEXT TEST
 1710 7410 CLA CLL CMA
 1711 1653 TS145
 1712 7340 TS145
 1713 3046 REGA

/DOES BIT 8 SET UP?

2714	7200	TST46,	CLA	
2715	6132	CLR	CLAB	
2716	6133	CLR	CLBR	
2717	1114	TAD	K0100	
2720	6132	CLR	CLSA	
2721	6135	CLA	CLSA	
2722	7200		CLA	
2723	3054	DCA	CNTR	
2724	1101	TAD	K0007	
2725	6133	CLA	GBAB	
2726	3054	DCA	SEND	
2727	1116	TAD	K0200	
2728	6134	CLA	CLBN	
2729	7327	TAD	K3100	
2730	6135	CLR	CLB	
2731	7300	DCA	CLB	
2732	1131	TAD	K0007	
2733	6132	CLR	GBAB	
2734	3053	DCA	SEND	
2735	6135	TAD	K0200	
2736	1053	CLA	RXED	
2737	1147	TAD	M0010	
2738	7058	JMP	44	
2739	5345	JMP	157	
2740	7410	SNA	CLA	
2741	5334	JMP	152	
2742	2625	ISZ	CNTR	
2743	5345	JMP	154	
2744	7424	SNA	CLA	
2745	4430	JMS	1	ERROR
2746	4426	JMS	1	ERROR
2747	6435	TST46M		
2748	7402	HLT		
2749	7414	SKP		
2750	7340	TST46		
2751	1714	ISZ	SCOPE LOOP	
2752	7410	TTO	NEXT TEST	
2753	7340	/SET AG=7777		
2754	3046	/RESET REGA FOR NEXT TEST		

1753	7200	CBA	TS1747.	CBA	DCA	REGA	2015	3046
1756	6432	CBLR	/D0CE3 BIT 7 SET UP7	CBLR	DCA	CTR	2014	7340
1757	6433	CBLR		CBLR	CBA	REGA	2014	7340
1760	2114	CBA		CBA	CTR	TS1747	2013	1935
1761	6432	CBLR		CBLR	CBA	REGA	2012	7410
1762	6433	CBLR		CBLR	SKP	TS1747	2012	7410
1765	2116	TAD		TAD	SKP	/193 LOOP1 SCOPE LOOP	2011	7402
1766	6433	CBA	/RESET FOR BIT 07	CBA	HLT	/TO NEXT TEST	2011	7402
1767	3054	DCA		DCA	REGA	/ERROR HALT	2011	7402
1770	1126	TAD		TAD	REGA	/MESSAGE POINTER	2010	6434
1771	1033	RXED		RXED	JMS	/BIT 7 FAILED TO GET SET BY COUNTING	2009	4426
1772	6434	CLEN	/S1T 07, AND ONLY S1T 07, SET7	CLEN	JMS	/PRESET REGA FOR NEXT TEST	2008	4430
1773	2137	CBLR		CBLR	JMS	/SET AG87777	2007	4426
1774	6432	TAD		TAD	JMS	/SET AG87777	2006	4430
1775	6432	BK47,		BK47,	JMS	/PRESET REGA FOR NEXT TEST	2005	7410
1776	3053	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	2004	5423
1777	1033	RXED		RXED	JMS	/PRESET REGA FOR NEXT TEST	2003	2025
1778	1126	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	2002	5206
1779	1126	K0200		K0200	JMS	/PRESET REGA FOR NEXT TEST	2001	7350
1780	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	2000	1139
1781	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1977	1033
1782	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1977	1033
1783	7300	CLEN		CLEN	JMS	/PRESET REGA FOR NEXT TEST	1976	3053
1784	6434	CLEN		CLEN	JMS	/PRESET REGA FOR NEXT TEST	1976	1126
1785	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1975	6432
1786	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1975	6432
1787	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1975	1126
1788	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1975	1126
1789	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1974	6432
1790	6434	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1974	7300
1791	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1973	7300
1792	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1973	1126
1793	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1973	6432
1794	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1973	1126
1795	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1972	6434
1796	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1972	1126
1797	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1972	6432
1798	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1972	1126
1799	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1971	6432
1800	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1971	1126
1801	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1971	6432
1802	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1971	1126
1803	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1970	6432
1804	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1970	1126
1805	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1970	6432
1806	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1970	1126
1807	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1969	6432
1808	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1969	1126
1809	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1969	6432
1810	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1969	1126
1811	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1968	6432
1812	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1968	1126
1813	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1968	6432
1814	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1968	1126
1815	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1967	6432
1816	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1967	1126
1817	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1967	6432
1818	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1967	1126
1819	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1966	6432
1820	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1966	1126
1821	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1966	6432
1822	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1966	1126
1823	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1965	6432
1824	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1965	1126
1825	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1965	6432
1826	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1965	1126
1827	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1964	6432
1828	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1964	1126
1829	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1964	6432
1830	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1964	1126
1831	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1963	6432
1832	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1963	1126
1833	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1963	6432
1834	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1963	1126
1835	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1962	6432
1836	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1962	1126
1837	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1962	6432
1838	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1962	1126
1839	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1961	6432
1840	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1961	1126
1841	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1961	6432
1842	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1961	1126
1843	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1960	6432
1844	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1960	1126
1845	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1960	6432
1846	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1960	1126
1847	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1959	6432
1848	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1959	1126
1849	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1959	6432
1850	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1959	1126
1851	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1958	6432
1852	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1958	1126
1853	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1958	6432
1854	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1958	1126
1855	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1957	6432
1856	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1957	1126
1857	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1957	6432
1858	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1957	1126
1859	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1956	6432
1860	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1956	1126
1861	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1956	6432
1862	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1956	1126
1863	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1955	6432
1864	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1955	1126
1865	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1955	6432
1866	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1955	1126
1867	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1954	6432
1868	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1954	1126
1869	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1954	6432
1870	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1954	1126
1871	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1953	6432
1872	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1953	1126
1873	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1953	6432
1874	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1953	1126
1875	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1952	6432
1876	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1952	1126
1877	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1952	6432
1878	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1952	1126
1879	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1951	6432
1880	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1951	1126
1881	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1951	6432
1882	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1951	1126
1883	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1950	6432
1884	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1950	1126
1885	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1950	6432
1886	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1950	1126
1887	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1949	6432
1888	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1949	1126
1889	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1949	6432
1890	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1949	1126
1891	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1948	6432
1892	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1948	1126
1893	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1948	6432
1894	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1948	1126
1895	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1947	6432
1896	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1947	1126
1897	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1947	6432
1898	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1947	1126
1899	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1946	6432
1900	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1946	1126
1901	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1946	6432
1902	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1946	1126
1903	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1945	6432
1904	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1945	1126
1905	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1945	6432
1906	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1945	1126
1907	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1944	6432
1908	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1944	1126
1909	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1944	6432
1910	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1944	1126
1911	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1943	6432
1912	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1943	1126
1913	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1943	6432
1914	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1943	1126
1915	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1942	6432
1916	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1942	1126
1917	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1942	6432
1918	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1942	1126
1919	2137	CBLR		CBLR	JMS	/PRESET REGA FOR NEXT TEST	1941	6432
1920	6432	TAD		TAD	JMS	/PRESET REGA FOR NEXT TEST	1941	1126
1921	3054	DCA		DCA	JMS	/PRESET REGA FOR NEXT TEST	1941	6432
1922	1126	SEND		SEND	JMS	/PRESET REGA FOR NEXT TEST	1941	1126

/DOES BIT 5 SET UP?

2057 7280 TSTA9, CLA
/DOES BIT 5 SET UP?
2060 6132 CLR
2061 6133 CLAB
2062 6134 TAD K0180
2063 6135 CLSA
2064 6136 CLR
2065 7280 CLA
2066 3025 DCA
2067 1113 TAD K0077
2068 6133 CLAB
2069 3054 DCA SEND
2070 6134 TAD K0280
2071 3054 DCA
2072 1116 TAD K0280
2073 6134 CLBN CLR
2074 7380 CLA CLR
2075 1137 TAD K5180
2076 6132 CLR
2077 6137 CLCA
2078 1116 TAD K0280
2079 3054 DCA
2080 6133 TAD K0077
2081 3025 DCA
2082 1114 TAD K0180
2083 6132 CLR
2084 6133 CLAB
2085 7280 CLA
2086 3025 DCA
2087 1113 TAD K0077
2088 6133 CLAB
2089 3054 DCA SEND
2090 6134 TAD K0280
2091 3054 DCA
2092 1116 CLBN CLR
2093 6134 CLA CLR
2094 7380 CLB CLR
2095 1137 TAD K5180
2096 3025 DCA
2097 1113 TAD K0077
2098 6133 CLAB
2099 3054 DCA
2100 6134 TAD K0280
2101 3053 TAD RXED
2102 1135 TAD RXED
2103 5310 SNA CLA
2104 5310 JMP .#4
2105 2025 ISZ CNTR
2106 5277 JMP .#7
2107 7410 SKP
2108 4430 JMS I ERROR
2109 7402 HLT
2110 6912 TS149M
2111 4226 /MESSAG POINTER
2112 7412 /BIT 3 FAILED TO GET SET BY COUNTING
2113 6912 /ERROR HALT
2114 7410 TS149
2115 2057 /TO NEXT TEST
2116 7340 CLA CLR CHA
2117 3046 /RESET REGA FOR NEXT TEST
2118 7340 SET AC=7777

/DOES BIT 4 SET UP?

/RESET FOR BIT 04

TAD K0477

TAD K0200

TAD K5100

TAD M0200

TAD RAXE0

TAD RAXE0

TAD RSER

TAD TS150M

TAD TS150

TAD TS150

JMS I ERROR

SKP

SKP

SKP

/MESSAGE CENTER

/BIT 4 FAILED TO GET SET BY COUNTING

/BIT 4 NEXT TEST

/PRESET REGA FOR NEXT TEST

/ERROR HALT

/SET AC=7777

/IS2 LOOP! SCOPE LOOP

/PRESSET REGA FOR NEXT TEST

/SET AC=7777

/SET AC=7777

/CHECK MONITOR

/SET AC=7777

/SET AC=7777

/BIT 04, AND ONLY BIT 04, SET?

DCB REGA
CLL CLL CMA
TS150

/ DOES BIT 3 SET UP?

2161 7200 TST51, CLA
2162 6132 CLR
2163 6133 CLA8
2164 1114 TAD K0100
2165 6132 CLR
2166 6135 CLSA
2167 7200 CLA
2170 3025 CNTR
2171 1121 TAD K0377
2172 6133 CLA8
2173 3054 SEND
2174 1116 TAD K0200
2175 6134 CLEN
2176 7300 CLA CLL
2177 1137 TAD K5100
2200 6132 CLR
2201 6137 CLCA
2202 3053 RXE0
2203 1053 TAD RXE0
2204 1135 TAD M0400
2205 7650 SNA CLA
2206 5212 JMP .44
2207 2025 ISZ CNTR
2210 7410 SKP ,47
2211 7411 SKP
2212 4430 JMS I ERROR
2213 4426 /BIT 3 FAILED TO GET SET BY COUNTING
2214 6550 /MESSAGE POINTER
2215 7402 /ERROR HALT
2216 7410 TST51
2217 2161 SKP
2218 6132 /16 LOOP SCOPE LOOP
2219 7340 /TO NEXT TEST
2220 7340 /SET AC=7777
2221 3046 CLA CLL CMA
2222 3046 REGA
/PRESSET REGA FOR NEXT TEST

/DOES BIT 1 SET UP?

2263 7200 TST33, CLA
2264 6132 CLRA
2265 6133 CLSA
2266 1314 TAD K0100
2267 6132 CLLR
2270 6135 CLSA
2271 7200 CLA
2272 3025 CNTR
2273 1313 TAD K1777
2274 6133 CLAB
2275 3054 DCA SEND
2276 1316 TAD K0200
2277 6134 CLRN
2278 7300 CLA CBL
2279 1317 TAD K5100
2280 1137 CLLR
2281 6132 CLA
2282 1133 RXED
2283 1053 TAD M2800
2284 6137 CLGA
2285 1160 RXED
2286 1160 TAD
2287 7650 SNA CLA
2288 5314 JMP .=6
2289 5314 ISZ CNTR
2290 2025 JMP .=7
2291 5303 JMP .=7
2292 7410 JMS I ERROR
2293 4426 /BIT 1 FAILED TO GET SET BY COUNTING
2294 7410 /CHECK MONITOR
2295 4430 /MESSAGE POINTERR
2296 6606 /TO NEXT TEST
2297 7402 SKP HLT
2298 7410 TS153 TS153M
2299 2263 T1S2
2300 7340 CLA CBL OMA
2301 3046 DCA REGA
2302 7340 /SET AC=7777
2303 7340 /IS2 LOOP1 SCOPE LOOP
2304 7410 /NEXT TEST
2305 4430 /ERROR HALT
2306 6606 TS153M
2307 7650 JMS I ERROR
2308 5314 /BIT 01, AND ONLY BIT 01, SET?
2309 5314 TS153
2310 2025 ISZ
2311 5314 JMS I
2312 5303 JMS I
2313 7410 SKP
2314 4430 JMS I ERROR
2315 4426 /BIT 1 FAILED TO GET SET BY COUNTING
2316 6606 /MESSAGE POINTERR
2317 7402 SKP HLT
2318 7410 TS153 TS153M
2319 5303 JMS I ERROR
2320 7410 /CHECK MONITOR
2321 7410 /NEXT TEST
2322 7340 CLA CBL OMA
2323 3046 DCA REGA
2324 7340 /PRESET REGA FOR NEXT TEST

/DOES COUNTERT NORMALITY AND AT ALL RATESE7
/CHECK 400 KHz RATE

/CHECK 100 GPS RATE
 /
 2520 7300 T500 CLA CLR
 /CLEAR AC
 2521 3047 T500 DCA REGB
 /CLEAR REGB
 2522 1133 TAD M0100
 /SET PRESET
 2523 3038 TAD REGC
 /SET FOR X100
 2524 1155 TAD M0400
 /SET PRESET
 2525 6133 CLAB
 /RESET BUFFER
 2526 7300 CLA CLR
 /CLEAR AC
 2527 1116 TAD K0200
 /SET AC 0541
 2528 6134 CLEN
 /ENABLE PRESET
 2529 7300 CLA CLR
 /CLEAR AC
 2530 6132 TAD K3100
 /SET 100 GPS RATES
 2531 1132 CLAB
 /CLEAR AC
 2532 7300 CLA CLR
 /CLEAR AC
 2533 6132 TAD K3100
 /SET 100 GPS RATES
 2534 7300 CLAB
 /CLEAR AC
 2535 7300 CLA CLR
 /CLEAR AC
 2536 7410 TAD K3100
 /INCREDIMENT TIME
 2537 2030 CLAB
 /INCREDIMENT MULTIPPLIER
 2538 7410 TAD K3100
 /TIME OK
 2539 5347 SKP +6
 /TIME NOT OK! RATE FAILED
 2540 7416 CLSA
 /GET STATUS
 2541 6135 JMP
 /WAITS
 2542 7416 CLSA
 /WAITS
 2543 7000 NOF
 /OVERFLOW?
 2544 5335 SMA CLA
 /TRY AGAIN
 2545 5335 JHP ,=10
 /CHECK MONITOR
 2546 4430 JMS I ERROR
 /RATE 100 HS FAILED
 2547 4426 JMS I ERROR
 /CLEAR REGB
 2548 7700 T5159M
 /CLEAR REGB
 2549 7610 HLT
 /CLEAR REGB
 2550 6727 T5159
 /CLEAR REGB
 2551 7402 SKP CLA
 /CLEAR REGB
 2552 2520 T5159
 /CLEAR REGB
 2553 1153 T5159
 /CLEAR REGB
 2554 1153 TAD M0100
 /CLEAR REGB
 2555 3046 DCA REGA
 /CLEAR REGB
 2556 3047 DCA REGB
 /CLEAR REGB

/PDP=12 KMH2A CLOCK TEST, MAINDEC 42-B8CC-6 PAL10 V1A1 21-JUL-96

/ SIM INPUT TESTS CHAN 2

/SET AC 09#1

/CLR

/CLEAR AC

/CLEAR ENABLES

/CLEAR STATUS

/CLEAR FILED

/CLEAR IT

/CLEAR IT

/CLEAR CHANNEL 8

/CLEAR CHANNEL 2

/CLEAR STATUS

/CLEAR IT

/SIM INPUT TESTS CHAN 3
 /
 2666 1107 TST63, TAD K0020 /SET AC 0741
 2667 6134 CLRN /SET ENABLE
 2670 6132 CLR /SET EVENT FLOW
 2671 6132 CLR /SET PREVENT FLOW
 2672 7300 CLR AG /CLEAR
 2673 6134 CLRN /CLEAR ENABLES
 2674 6134 AND K3777 /IGNORE DIFL0
 2675 0134 AND K0060 /SAVE IT
 2676 3094 CLSA SEND /GET STATUS
 2677 0135 CLSA AND K3777 /IGNORE DIFL0
 2678 3094 CLSA SEND /SAVE IT
 2679 0135 CLRN /CLEAR
 2680 0122 AND K0060 /SAVE CHANNEL 1
 2681 1053 TAD RXED /FETCH IT
 2682 1054 TAD RXED /SUBTRACT SET
 2683 1112 TAD K0060 /GET FIRST STATES
 2684 5312 JMP .#6 SNA CLA /SUBTRACT SET
 2685 1054 CIA SEND SNA CLA /ERROR
 2686 7041 JMS I ERROR /SOFT PRE-EVENT AND EVENT NOT SET
 2687 4426 JMS I ERROR /MESSAGE POINTERR
 2688 7630 SNA CLA /SOFT MONITOR
 2689 7632 TAD K0060 /SUBTRACT SET
 2690 7632 TAD K0060 /SOFT MONITOR
 2691 7632 TAD K0060 /SUBTRACT SET
 2692 7632 TAD K0060 /SOFT MONITOR
 2693 7632 TAD K0060 /SUBTRACT SET
 2694 7632 TAD K0060 /SOFT MONITOR
 2695 7632 TAD K0060 /SUBTRACT SET
 2696 7632 TAD K0060 /SOFT MONITOR
 2697 7632 TAD K0060 /SUBTRACT SET
 2698 7632 TAD K0060 /SOFT MONITOR
 2699 7632 TAD K0060 /SUBTRACT SET
 2700 7632 TAD K0060 /SOFT MONITOR
 2701 7632 TAD K0060 /SUBTRACT SET
 2702 7632 TAD K0060 /SOFT MONITOR
 2703 7640 SCA CLA /SUBTRACT SET
 2704 5312 JMP .#6 SCA CLA /SUBTRACT SET
 2705 1054 CIA SEND SCA CLA /SUBTRACT SET
 2706 7041 TAD RXED CIA SEND SCA CLA /SUBTRACT SET
 2707 1112 TAD RXED CIA SEND SCA CLA /SUBTRACT SET
 2708 4426 JMS I ERRO SCA CLA /SUBTRACT SET
 2709 7630 SNA CLA /SOFT MONITOR
 2710 7632 TAD K0060 /SOFT MONITOR
 2711 4430 JMS I ERRO SNA CLA /SOFT MONITOR
 2712 4426 JMS I ERRO SNA CLA /SOFT MONITOR
 2713 7032 TAD K0060 /SOFT MONITOR
 2714 7402 HLT /ERROR HALT
 2715 7410 SKP /TO NEXT TEST
 2716 2666 TS163 /IS2 LOOP SCOPE LOOP
 2717 7340 CLA CLR CHA /SET AC 7777
 2718 3046 OCA REGA /PRESET REGA

2741	1147	TST65,	TAD	K0020	/CLEAR INTERRUPT ENABLE SET SIMULATES INPUT
2742	1036	TST64,	TAD	PNTD	/TEST INPUT CHANNEL INTERRUPT CHAN 1
2743	3052	1112	DCA	RETURN	/SET UP INTERRUPT RETURN
2744	6134	6132	TAD	K0060	/ENABLE INPUT AND INTERRUPT
2745	6132	6001	CLLR	I0N	/SIMULATE INPUT CHANNEL ONE
2746	7027	7000	I0P	NOOP	/ENABLE INTERRUPTS
2747	7410	7426	SKP	LOGD,	/NO INTERRUPT ERROR
2748	7410	7430	SKP	I0S	/NO INTERRUPT
2749	7432	7333	CLEN	LOGD,	/CLEAR MONITOR
2750	7432	7331	CLEN	I0S	/CLEAR INTERRUPT
2751	7435	7337	CLEN	I0P	/ENABLE INTERRUPTS
2752	3052	1037	TAD	PNTD	/PUT IT IN INTERRUPT D_POINTER
2753	7402	7402	DCA	RETURN	/GET RETURN D_POINTER TO LOGC
2754	7072	7072	I0N	LOGC,	/PUT IT IN INTERRUPT HANDLER
2755	4426	4426	I0P	NOOP	/ENABLE INTERRUPTS
2756	7610	7610	SKP	CLL	/CLEAR HALT
2757	2757	2757	HLT	CLL	/TEST AC=7777
2758	2754	2754	CLLA	CLL	/ISZ LOOP! SCOPE LOOP
2759	2761	2761	REGA	REGB	/RESET REGA
2760	2762	2762	REGA	REGB	/DO THE PAIR OF TESTS 4096 TIMES
2761	2046	2046	REGA	REGB	/PRESSET REGA
2762	2047	2047	REGA	REGB	/PRESSET REGA
2763	5321	5321	REGA	REGB	/TEST AC=7777

/TEST INPUT CHANNEL INTERRUPT CHAN 2
 /TEST INPUT CHANNEL INTERRUPT CHAN 2
 2764 1204 1204 TAD PNTF
 /SET RETURN POINTER TO LOGIC
 2765 3052 3052 TAD RETURN
 /SET UP INTERRUPT RETURN
 2766 1204 1204 TAD K0824
 /SET AC 0B, 09A1
 2767 6134 6134 CLRN
 /ENABLE CHANNEL 2
 2768 6132 6132 CLR
 /ENABLE RATES
 2771 6001 6001 ION
 /ENABLE INTERRUPTS
 2772 7000 7000 NOP
 /WAIT
 2773 7410 7410 SKP
 /TO HERE IF NO INTERRUPT
 2774 4430 4430 LOGF, JMS 1 ERROR
 /NO INTERRUPT
 /CHECK MONITOR
 2775 4426 4426 LOGF, JMS 1 ERROR
 /NO INTERRUPT
 /MESSAGE POINTER
 2776 7122 7122 TST66H
 /TEST WITH INTERRUPTS DISABLED
 2777 7402 7402 HLT
 /ERROR HALT
 2778 2764 2764 TST66
 /TEST
 2779 7410 7410 SKP
 /TO NEXT TEST
 2780 6002 6002 ION
 /ENABLE INTERRUPTS
 2781 6001 6001 NOP
 /WAIT
 2782 7300 7300 CLRN
 /CLEAR AC
 2783 7300 7300 TAD PNTG
 /SET RETURN POINTER TO LOGIC
 2784 1200 1200 TAD K0804
 /SET AC 09A1
 2785 6134 6134 CLRN
 /ENABLE CHANNEL 2
 2786 1204 1204 TAD K0824
 /SET UP INTERRUPT RETURN
 2787 6134 6134 CLRN
 /ENABLE CHANNEL 2
 2788 6132 6132 CLR
 /ENABLE RATES
 2791 6001 6001 ION
 /ENABLE INTERRUPTS
 2792 7000 7000 NOP
 /WAIT
 2793 7410 7410 SKP
 /TO HERE IF NO INTERRUPT
 2794 4430 4430 LOGF, JMS 1 ERROR
 /NO INTERRUPT
 /CHECK MONITOR
 2795 4426 4426 LOGF, JMS 1 ERROR
 /NO INTERRUPT
 /MESSAGE POINTER
 2796 7122 7122 TST66H
 /TEST WITH INTERRUPTS DISABLED
 2797 7402 7402 HLT
 /ERROR HALT
 2798 2764 2764 TST66
 /TEST
 2799 7410 7410 SKP
 /TO NEXT TEST
 2800 6002 6002 ION
 /ENABLE INTERRUPTS
 2801 6001 6001 NOP
 /WAIT
 2802 7300 7300 CLRN
 /CLEAR AC
 2803 7300 7300 TAD PNTG
 /SET RETURN POINTER TO LOGIC
 2804 1200 1200 TAD K0804
 /SET AC 09A1
 2805 6134 6134 CLRN
 /ENABLE CHANNEL 2
 2806 1204 1204 TAD K0824
 /SET UP INTERRUPT RETURN
 2807 7041 7041 TAD PNTG
 /SET RETURN POINTER TO LOGIC
 2808 3052 3052 TAD RETURN
 /SET UP INTERRUPT RETURN
 2809 1204 1204 TAD K0824
 /SET AC 0B, 09A1
 2810 6134 6134 CLRN
 /ENABLE CHANNEL 2
 2811 6001 6001 ION
 /ENABLE INTERRUPTS
 2812 7000 7000 NOP
 /WAIT
 2813 6002 6002 IOP
 /DIAGNOSIS
 2814 6135 6135 CLSA
 /CLEAR CLOCK STATUS
 2815 4430 4430 JMS 1 ERROR
 /CHECK MONITOR
 2816 4426 4426 LOGF, JMS 1 ERROR
 /INTERUPT IN ERROR=GLEA ON EVENT 2 INT BAD
 2817 7133 7133 T8767M
 /MESSAGE POINTER
 2818 7402 7402 HLT
 /ERROR HALT
 2819 7410 7410 SKP
 /TO NEXT TEST
 2820 7402 7402 T8767
 /TEST
 2821 7410 7410 HLT
 /ERROR HALT
 2822 3004 3004 T8767
 /IS LOOP SCOPE LOOP
 2823 7340 7340 CLA CLL CMA
 /SET AC=7777
 2824 3024 3024 CLA CLL CMA
 /PRESET REGA
 2825 2047 2047 ISZ REGA
 /DO THIS PAIR OF TESTS 4096 TIMES
 2826 5460 5460 JMP 1 T8766N
 /BACK

/TEST INPUT CHANNEL INTERRUPT CHAN 3
 3027 1042 TSD8, TAD PNTI
 3030 3052 DCA RETURN K0003
 3031 1077 TAD K0003
 /SET UP INTERRUPT RETURN
 /SET AD16,11#1
 3033 6434 CLEN
 /ENABLE CHANNEL 3
 3035 6432 CLR
 /ENABLE CHANNEL 3
 3034 6431 ION
 /ENABLE CHANNEL 3
 3036 6430 NOP
 /HAI
 3037 7410 IOF
 /DISABLE INTERRUPTS
 3038 7402 SKP
 /NO INTERRUPT
 3039 4430 LOGH, JMS 1 ERROR
 /CHECK MONITOR
 /NO INTERRUPT
 3040 4426 SKP
 /NO INTERRUPT
 3041 7410 IOF
 /NO INTERRUPT
 3042 7402 SKP
 /NO INTERRUPT
 3043 7410 IOF
 /MESSAGE HOLDING
 3044 7410 HLT
 /ERROR HALT
 3045 7427 SKP
 /TO NEXT TEST
 3046 7346 CLEN CLL CMA
 /SET AC 11#1
 3047 3046 DCA REGA
 /RESET REGA
 3048 7346 CLEN CLL CMA
 /SET AC 11#1
 3049 7346 CLEN CLL CMA
 /SET AC 11#1
 3050 6001 ION
 /GENERAL INTERRUPTS
 3051 7500 NOP
 /GENERAL INTERRUPTS
 3052 3052 TAC PNTI
 /CLEAR RETURN POINT TO LOGI
 3053 1043 DCA RETURN
 /CLEAR RETURN POINT TO LOGI
 3054 7500 IOP
 /GENERAL INTERRUPTS
 3055 6001 ION
 /GENERAL INTERRUPTS
 3056 7000 NOP
 /GENERAL INTERRUPTS
 3057 6002 IOP
 /GENERAL INTERRUPTS
 3058 7000 IOP
 /GENERAL INTERRUPTS
 3059 6001 AND K0003
 3060 6434 CLEN
 /ENABLE CHANNEL 3
 3061 6434 CLEN
 /ENABLE CHANNEL 3
 3062 3052 TAC PNTI
 /CLEAR RETURN POINT TO LOGI
 3063 1043 DCA RETURN
 /CLEAR RETURN POINT TO LOGI
 3064 7500 IOP
 /GENERAL INTERRUPTS
 3065 6001 ION
 /GENERAL INTERRUPTS
 3066 7430 HLT
 /ERROR HALT
 3067 3050 CLEN CLL CMA
 /SET AC 11#1
 3068 7346 CLEN CLL CMA
 /SET AC 11#1
 3069 7346 CLEN CLL CMA
 /SET AC 11#1
 3070 3046 DCA REGA
 /RESET REGA
 3071 2047 DCA REGA
 /RESET REGA
 3072 5227 JMP TS168
 /DO THIS PAIR OF TESTS 4896 TIMES
 3073 1151 TAD M0040
 /PRESET REGA
 3074 3046 DCA REGA
 /RESET REGA
 3075 3046 DCA REGA
 /RESET REGA
 3076 7346 CLEN CMA
 /SET AC 11#1
 3077 5227 JMP TS168
 /DO THIS PAIR OF TESTS 4896 TIMES
 3078 3046 DCA REGA
 /RESET REGA
 3079 3046 DCA REGA
 /RESET REGA
 3080 7430 HLT
 /TO NEXT TEST
 3081 3050 CLEN CMA
 /SET AC 11#1
 3082 7430 HLT
 /TO NEXT TEST
 3083 4426 LOGI, JMS 1 ERROR
 /INTERRUPT IN ERROR
 3084 7402 HLT
 /MESSAGE POINTER
 3085 6435 CLSA
 /CLEAR LOCK STATUS
 3086 6002 IOP
 /DISABLE INTERRUPTS
 3087 6002 IOP
 /CLEAR LOCK STATUS
 3088 7000 IOP
 /CLEAR LOCK STATUS
 3089 7000 IOP
 /CLEAR LOCK STATUS
 3090 6001 ION
 /GENERAL INTERRUPTS
 3091 7000 IOP
 /GENERAL INTERRUPTS
 3092 4430 LOGI, JMS 1 ERROR
 /CHECK MONITOR
 /INTERRUPT
 3093 7000 IOP
 /GENERAL INTERRUPTS
 3094 4430 LOGI, JMS 1 ERROR
 /CHECK MONITOR
 /NO INTERRUPT
 3095 6001 ION
 /GENERAL INTERRUPTS
 3096 7000 IOP
 /GENERAL INTERRUPTS
 3097 4426 LOGI, JMS 1 ERROR
 /CHECK MONITOR
 /INTERRUPT
 3098 7000 IOP
 /GENERAL INTERRUPTS
 3099 6001 ION
 /GENERAL INTERRUPTS
 3100 7000 IOP
 /GENERAL INTERRUPTS
 3101 6001 ION
 /GENERAL INTERRUPTS
 3102 7000 IOP
 /GENERAL INTERRUPTS
 3103 6001 ION
 /GENERAL INTERRUPTS
 3104 7000 IOP
 /GENERAL INTERRUPTS
 3105 6001 ION
 /GENERAL INTERRUPTS
 3106 7000 IOP
 /GENERAL INTERRUPTS
 3107 6001 ION
 /GENERAL INTERRUPTS
 3108 7000 IOP
 /GENERAL INTERRUPTS
 3109 6001 ION
 /GENERAL INTERRUPTS
 3110 7000 IOP
 /GENERAL INTERRUPTS
 3111 6001 ION
 /GENERAL INTERRUPTS
 3112 7000 IOP
 /GENERAL INTERRUPTS
 3113 6001 ION
 /GENERAL INTERRUPTS
 3114 7000 IOP
 /GENERAL INTERRUPTS
 3115 6001 ION
 /GENERAL INTERRUPTS
 3116 7000 IOP
 /GENERAL INTERRUPTS
 3117 6001 ION
 /GENERAL INTERRUPTS
 3118 7000 IOP
 /GENERAL INTERRUPTS
 3119 6001 ION
 /GENERAL INTERRUPTS
 3120 7000 IOP
 /GENERAL INTERRUPTS
 3121 6001 ION
 /GENERAL INTERRUPTS
 3122 7000 IOP
 /GENERAL INTERRUPTS
 3123 6001 ION
 /GENERAL INTERRUPTS
 3124 7000 IOP
 /GENERAL INTERRUPTS
 3125 6001 ION
 /GENERAL INTERRUPTS
 3126 7000 IOP
 /GENERAL INTERRUPTS
 3127 6001 ION
 /GENERAL INTERRUPTS
 3128 7000 IOP
 /GENERAL INTERRUPTS
 3129 6001 ION
 /GENERAL INTERRUPTS
 3130 7000 IOP
 /GENERAL INTERRUPTS
 3131 6001 ION
 /GENERAL INTERRUPTS
 3132 7000 IOP
 /GENERAL INTERRUPTS
 3133 6001 ION
 /GENERAL INTERRUPTS
 3134 7000 IOP
 /GENERAL INTERRUPTS
 3135 6001 ION
 /GENERAL INTERRUPTS
 3136 7000 IOP
 /GENERAL INTERRUPTS
 3137 6001 ION
 /GENERAL INTERRUPTS
 3138 7000 IOP
 /GENERAL INTERRUPTS
 3139 6001 ION
 /GENERAL INTERRUPTS
 3140 7000 IOP
 /GENERAL INTERRUPTS
 3141 6001 ION
 /GENERAL INTERRUPTS
 3142 7000 IOP
 /GENERAL INTERRUPTS
 3143 6001 ION
 /GENERAL INTERRUPTS
 3144 7000 IOP
 /GENERAL INTERRUPTS
 3145 6001 ION
 /GENERAL INTERRUPTS
 3146 7000 IOP
 /GENERAL INTERRUPTS
 3147 6001 ION
 /GENERAL INTERRUPTS
 3148 7000 IOP
 /GENERAL INTERRUPTS
 3149 6001 ION
 /GENERAL INTERRUPTS
 3150 7000 IOP
 /GENERAL INTERRUPTS
 3151 6001 ION
 /GENERAL INTERRUPTS
 3152 7000 IOP
 /GENERAL INTERRUPTS
 3153 6001 ION
 /GENERAL INTERRUPTS
 3154 7000 IOP
 /GENERAL INTERRUPTS
 3155 6001 ION
 /GENERAL INTERRUPTS
 3156 7000 IOP
 /GENERAL INTERRUPTS
 3157 6001 ION
 /GENERAL INTERRUPTS
 3158 7000 IOP
 /GENERAL INTERRUPTS
 3159 6001 ION
 /GENERAL INTERRUPTS
 3160 7000 IOP
 /GENERAL INTERRUPTS
 3161 6001 ION
 /GENERAL INTERRUPTS
 3162 7000 IOP
 /GENERAL INTERRUPTS
 3163 6001 ION
 /GENERAL INTERRUPTS
 3164 7000 IOP
 /GENERAL INTERRUPTS
 3165 6001 ION
 /GENERAL INTERRUPTS
 3166 7000 IOP
 /GENERAL INTERRUPTS
 3167 6001 ION
 /GENERAL INTERRUPTS
 3168 7000 IOP
 /GENERAL INTERRUPTS
 3169 6001 ION
 /GENERAL INTERRUPTS
 3170 7000 IOP
 /GENERAL INTERRUPTS
 3171 6001 ION
 /GENERAL INTERRUPTS
 3172 7000 IOP
 /GENERAL INTERRUPTS
 3173 6001 ION
 /GENERAL INTERRUPTS
 3174 7000 IOP
 /GENERAL INTERRUPTS
 3175 6001 ION
 /GENERAL INTERRUPTS
 3176 7000 IOP
 /GENERAL INTERRUPTS
 3177 6001 ION
 /GENERAL INTERRUPTS
 3178 7000 IOP
 /GENERAL INTERRUPTS
 3179 6001 ION
 /GENERAL INTERRUPTS
 3180 7000 IOP
 /GENERAL INTERRUPTS
 3181 6001 ION
 /GENERAL INTERRUPTS
 3182 7000 IOP
 /GENERAL INTERRUPTS
 3183 6001 ION
 /GENERAL INTERRUPTS
 3184 7000 IOP
 /GENERAL INTERRUPTS
 3185 6001 ION
 /GENERAL INTERRUPTS
 3186 7000 IOP
 /GENERAL INTERRUPTS
 3187 6001 ION
 /GENERAL INTERRUPTS
 3188 7000 IOP
 /GENERAL INTERRUPTS
 3189 6001 ION
 /GENERAL INTERRUPTS
 3190 7000 IOP
 /GENERAL INTERRUPTS
 3191 6001 ION
 /GENERAL INTERRUPTS
 3192 7000 IOP
 /GENERAL INTERRUPTS
 3193 6001 ION
 /GENERAL INTERRUPTS
 3194 7000 IOP
 /GENERAL INTERRUPTS
 3195 6001 ION
 /GENERAL INTERRUPTS
 3196 7000 IOP
 /GENERAL INTERRUPTS
 3197 6001 ION
 /GENERAL INTERRUPTS
 3198 7000 IOP
 /GENERAL INTERRUPTS
 3199 6001 ION
 /GENERAL INTERRUPTS
 3200 7000 IOP
 /GENERAL INTERRUPTS
 3201 6001 ION
 /GENERAL INTERRUPTS
 3202 7000 IOP
 /GENERAL INTERRUPTS
 3203 6001 ION
 /GENERAL INTERRUPTS
 3204 7000 IOP
 /GENERAL INTERRUPTS
 3205 6001 ION
 /GENERAL INTERRUPTS
 3206 7000 IOP
 /GENERAL INTERRUPTS
 3207 6001 ION
 /GENERAL INTERRUPTS
 3208 7000 IOP
 /GENERAL INTERRUPTS
 3209 6001 ION
 /GENERAL INTERRUPTS
 3210 7000 IOP
 /GENERAL INTERRUPTS
 3211 6001 ION
 /GENERAL INTERRUPTS
 3212 7000 IOP
 /GENERAL INTERRUPTS
 3213 6001 ION
 /GENERAL INTERRUPTS
 3214 7000 IOP
 /GENERAL INTERRUPTS
 3215 6001 ION
 /GENERAL INTERRUPTS
 3216 7000 IOP
 /GENERAL INTERRUPTS
 3217 6001 ION
 /GENERAL INTERRUPTS
 3218 7000 IOP
 /GENERAL INTERRUPTS
 3219 6001 ION
 /GENERAL INTERRUPTS
 3220 7000 IOP
 /GENERAL INTERRUPTS
 3221 6001 ION
 /GENERAL INTERRUPTS
 3222 7000 IOP
 /GENERAL INTERRUPTS
 3223 6001 ION
 /GENERAL INTERRUPTS
 3224 7000 IOP
 /GENERAL INTERRUPTS
 3225 6001 ION
 /GENERAL INTERRUPTS
 3226 7000 IOP
 /GENERAL INTERRUPTS
 3227 6001 ION
 /GENERAL INTERRUPTS
 3228 7000 IOP
 /GENERAL INTERRUPTS
 3229 6001 ION
 /GENERAL INTERRUPTS
 3230 7000 IOP
 /GENERAL INTERRUPTS
 3231 6001 ION
 /GENERAL INTERRUPTS
 3232 7000 IOP
 /GENERAL INTERRUPTS
 3233 6001 ION
 /GENERAL INTERRUPTS
 3234 7000 IOP
 /GENERAL INTERRUPTS
 3235 6001 ION
 /GENERAL INTERRUPTS
 3236 7000 IOP
 /GENERAL INTERRUPTS
 3237 6001 ION
 /GENERAL INTERRUPTS
 3238 7000 IOP
 /GENERAL INTERRUPTS
 3239 6001 ION
 /GENERAL INTERRUPTS
 3240 7000 IOP
 /GENERAL INTERRUPTS
 3241 6001 ION
 /GENERAL INTERRUPTS
 3242 7000 IOP
 /GENERAL INTERRUPTS
 3243 6001 ION
 /GENERAL INTERRUPTS
 3244 7410 HLT
 /ERROR HALT
 3245 7427 SKP
 /TO NEXT TEST
 3246 7346 CLEN CLL CMA
 /SET AC 11#1
 3247 3046 DCA REGA
 /RESET REGA
 3248 7346 CLEN CLL CMA
 /SET AC 11#1
 3249 7346 CLEN CLL CMA
 /SET AC 11#1
 3250 6001 ION
 /PRESET REGA IF NEXT TEST IS TO BE EXECUTED

3127	6135	TST71, CLSA	/TEST OF INPUT CHANNEL 2
3128	6132	CLLR	/CLEAR STATUS
3129	6134	TA0	K0014
3130	7300	CLSA	/CLEAR STATUS
3131	6132	CLLR	/CLEAR AC
3132	2104	TA0	K0014
3133	6134	TA0	/CLEAR ALL MODES
3134	7200	CLSA	/ENABLE
3135	6135	CLEN	/INPUT AND INTERRUPT FLOPS
3136	7410	IS2	REGB
3137	5342	SKP	/NOT DONE YET
3138	7410	IS2	/INCREMENT TIMER
3139	6131	JMP	/TIMER OUT1 ERROR CONDITION
3140	5340	CLSK	/CHECK FOR CLOCK INTER.
3141	6135	JHS	/WAIT
3142	6135	CLSA	/GET STATUS
3143	3053	DCA	/CLEAR COUNT
3144	3047	RXED	/SAVE IT
3145	1053	DCA	/RESTORE IT
3146	7041	TA0	RXED
3147	1102	DIA	/CLEAR GCOUNT
3148	7650	TA0	/ADD EVENT 2
3149	7650	SNA	/EQUAL?
3150	4435	CLA	/CHECK MONITOR
3151	4426	JHS	/CHAN 2 EVENT NOT SET, OR PRE-EVENT WAS SET, OR OTHG. CH .. UP
3152	4426	JHS	/PRESET REGA
3153	7410	TS721H	/IS2 LOOP! SCOPE LOGIC
3154	7410	SKP	/TO NEXT TEST
3155	7410	MLT	/ERROR HALT
3156	3127	TS721L	/MESSAGE POINTER
3157	1151	TA0	M0040
3158	3046	DCA	REGA

/POP=12 KMH2A CLOCK TEST, MAINDEC 12-D8CC-A
 3161 6235 T5722, CLSA
 /TEST OF INPUT CHAN 1
 /CLEAR STATUS
 3162 7500 CLA CLR
 /CLEAR AC
 3163 6232 CLR
 /CLEAR ALL MODES
 3164 1112 TAD K0060
 /SET AG6,781
 /ENABLE CHAN 3 INPUT AND INTERRUPT
 3165 6234 CLEN
 3166 7200 CLA
 /CLEAR AC
 3167 2047 I92 REG8
 /INCREDIMENT TIMER
 3168 7410 SKP
 /NOT DONE YET
 3169 5374 JMP
 /WAIT
 3170 7410 SKP
 /TIMER OUT! ERROR CONDITION
 3171 5374 JMP
 /CHECK FOR CLOCK INTERFER.
 3172 6131 CLSK
 3173 5367 JMP
 ,=4
 3174 6135 CLSA
 /GET CLOCK STATUS
 3175 3053 DCA RXED
 /SAVE IT
 3176 3047 DCA RXED
 /CLEAR COUNT
 3177 3053 CIA
 /COMPLEMENT
 3178 7041 TAD K0040
 /ADD INPUT 1
 3179 7650 SNA CIA
 /EOUAL?

3200 4426 JMS I ERROR
 /CHAN 1 EVENT NOT SET, OR PREVENT WAS SET, OR OTHER CHAN UP
 3201 3133 TAD K0040
 /ADD INPUT 1
 3202 7650 SNA CIA
 /MESSAGE POINTER
 3203 4430 JMS I ERROR
 /CHECK MONITOR
 3204 4426 HLT
 /ERROR HALT
 3205 7266 TS72M
 /IS2 LOOP! SCOPE LOOP
 3206 7402 SKP
 /TO NEXT TEST
 3207 7410 CLA CLR CMA
 /SET AG6777
 3211 7340 DCA REGA
 /RESET REGA
 3212 3046 DCA REGA
 /PRESET REGA

3213	7404	TST73,	OSR	/TEST FAST SAMPLER MODE IF BIT 04=0
3214	7006	R7L	/IF 010HT SM BIT 2(1)	
3215	7006	R7L	/SKIP FAST SAM TEST?	
3216	7004	RAL	/RSW 04=1?	
3217	7710	SPA CLA	JMP I TST77N	
3220	5462	LINC	/INDIRECT REF TO TST77	
3221	6141	CLR	/ENTER LINC MODE	
3222	0011	CLR	/CLEAR AC	
3223	0004	ESF	/CLEAR SPEC, IN REG.	
3224	0100	SAM	/READ KNOB ZERO	
3225	2002	PDP	/BACK TO 0 MODE	
3226	3054	DCU	/TU PAGE 0	
3227	6141	LINC	/BACK TO 0 MODE	
3228	0101	SAM	/READ KNOB 1	
3229	0011	CLR	/CLEAR AC	
3230	2002	PDP	/BACK 90 MODE	
3231	0011	SAM	/TU PAGE 0	
3232	1020	DCU	/PICK UP AC BIT 03	
3233	0100	ESF	/CLEAR STATUS	
3234	0004	PDP	/ENABLE SAM	
3235	0002	ESF	/ENTER PDP=8 MODE	
3236	6135	CLSA	CLS A	
3237	7500	CLA	K0408	
3240	1122	CLA	TAD	
3241	6132	CLR	ENTER LINC MODE	
3242	6141	ESF	/ENABLE COUNT	
3243	0002	PDP	/FAST SAM SET THEREFORE READ IN KNOB 1	
3244	0100	SAM	/SHOULD STILL READ KNOB 1	
3245	2002	PDP	/ENTER PDP=8 MODE	
3246	6143	ESF	/CLEAR AC	
3247	1053	DCA	RXED	
3248	7543	TAD	/RESTORE IT	
3249	7544	CLA	/SAVE VALUE	
3250	7545	TAD	/COMPILE IT	
3251	7546	CLA	/215 COMPLETION	
3252	7547	CLA	/CHECK MONITOR	
3253	7548	DSR	/MESSAGE POINT SAN CONVENTION	
3254	4426	JMS I	ERROR	
3255	7324	TST73M	/SET AGT777	
3256	7402	HLT	/TO NEXT TEST	
3257	7410	SKP	/ISZ LOOP SCOPE LOOP	
3258	3233	T5773	/PRESENT REGA FOR NEXT TEST	
3259	7340	CLA CLR CMA	CGA REGA	
3260	7341	T5773		
3261	7346			
3262	3046			

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

/TEST FAST SAMPLE WITH MODE 2(1) TO CHECK THAT KNOBS 8 & 1 ARE SET PROPERLY

3324	7200	TST75, CLA	/CHECK THAT MODE (10), (11), (21) DO NOT AFFECT SAMPLE
3325	6125	CLLR	/CLEAR AC
3326	1120	TAD	K0300
3327	6132	CLLR	/ZERO ALL MODES
3328	6134	LINC	/MODE (11), (21), (0)
3329	0011	CLR	/CLEAR AC
3330	0004	ESR	/ZERO SPEC, IN, REG.
3331	0008	SAM0	/SAMPLE KNOB 0
3332	0004	DOA	SEND
3333	0100	ESR	/SAVE KNOB 0
3334	0002	PDP	/TO MODE
3335	0102	SAM0	/SAMPLE KNOB 1
3336	0102	DOA	SEND
3337	0102	SAM0	/SAVE KNOB 1
3338	0100	DOA	SEND
3339	0100	ESR	/TO MODE
3340	0100	DOA	SEND
3341	0100	ESR	/SAVE KNOB 0
3342	0004	ESF	/PICH UP AC 05
3343	0100	CAM0	/GET WOB 1 SETTING
3344	0002	PDP	/ENTER PDP MODE
3345	0053	DCA	RXED
3346	1053	TAD	RXED
3347	7041	DOA	RXED
3348	1054	DOA	SEND
3349	7042	DOA	RXED
3350	1055	DOA	SEND
3351	7640	DOA	RXED
3352	4430	JMS	I ERROR
3353	7410	HLT	
3354	7355	T5175M	
3355	7402	SKP	
3356	7356	TST75	
3357	7324	CLA	CBL CHA
3358	7340	CLA	REGA
3359	3046	CLA	REGA
3360	3361	CLA	REGA

V442 PA110 MAINDEC 12-0600-6 TEST LOG CLK 12A KH12A/PDP-12

UNO CHECK FOR INHIBITION OF FAST SAM

Page 321

3515	7200	TST81, CLA	/CLEAR WITH IO RESET
3516	6232	TAD	/CLEAR ALL MODES
3517	1114	K0108	/CLEAR AC
3518	6232	TAD	/CLEAR ALL MODES
3519	6235	CLSA	/SET MODE (1)
3520	6232	CLLR	/CLEAR STATUS
3521	6235	CLSA	
3522	7200	CLA	
3523	1115	TAD	K4000
3524	6233	CLAB	
3525	7200	CLA	K0200
3526	1116	TAD	
3527	6234	CLAB	
3528	7200	CLA	
3529	6233	TAD	
3530	6232	CLLR	
3531	6235	CLAB	
3532	7200	CLA	
3533	1114	K0108	
3534	6232	CLLR	
3535	6235	CLAB	
3536	1020	CLA	
3537	0020	L0A1	
3538	0020	ESP	
3539	0020	PDP	
3540	6135	CLSA	
3541	0002	0000	
3542	0002	PDPA	
3543	7700	SMA CLA	
3544	4426	JMS I	NEEDER
3545	7511	TST81M	
3546	7402	HLT	
3547	7410	SKB	
3548	7410	TST81	
3549	7410	SKB	
3550	7410	SKB	
3551	3515		

3552	7200	T5T82,	CLA	T5T82	/TEST OVFL0 INT ENABL
3553	1114	TAD	K0100	T5T82	/CLEAR AC
3554	6132	CLLR	K0100	3555	/SET MODE (21)
3555	6135	CLSA	K4000	3556	/CLEAR STATUS
3556	7200	CLA	TAD	3557	/SET BUF PRESET REG.
3557	1135	CLAB	K0200	3558	/LOAD CNT WITH 4000
3558	7200	CLA	TAD	3559	/SET INT.
3559	6141	CLEN	K0100	3560	/ENTER LINE MODE
3560	1020	LDAI	00020	3561	/DO IO PRESSET
3561	0020	ESF	PDPP	3562	/ENTER PDP MODE
3562	7200	CLA	0004	3563	/DO IO PRESSET
3563	6132	CLRA	00004	3564	/ENTER PDP MODE
3564	7200	CLA	0020	3565	/CLEAR ALL MODES
3565	1114	CLLR	K0100	3566	/GEN.
3566	6131	TAD	K0100	3567	/CHECK MONITOR
3567	6131	CLSA	JMS 1	3568	/MESSAGE POINTER
3568	7202	HLT	ERROR	3569	/ERROR HALT
3569	7402	SKP CLA	JMS 1	3570	/TO NEXT TEST
3570	7610	T5T82M	ERRO	3571	/ISZ LOOP1 SCOPE LOOP
3571	7610	T5T82	ERRO	3572	
3572	7610	T5T82	ERRO	3573	
3573	7200	CLA	ESF	3574	
3574	7200	CLA	PDPP	3575	
3575	6132	CLRA	PDPP	3576	
3576	7200	CLA	PDPP	3577	
3577	6131	CLLR	PDPP	3578	
3578	7200	CLA	PDPP	3579	
3579	7200	CLA	PDPP	3580	
3580	7200	CLA	PDPP	3581	
3581	7200	CLA	PDPP	3582	
3582	7200	CLA	PDPP	3583	
3583	7200	CLA	PDPP	3584	
3584	7200	CLA	PDPP	3585	
3585	7200	CLA	PDPP	3586	
3586	7200	CLA	PDPP	3587	
3587	7200	CLA	PDPP	3588	
3588	7200	CLA	PDPP	3589	
3589	7200	CLA	PDPP	3590	
3590	7200	CLA	PDPP	3591	
3591	7200	CLA	PDPP	3592	
3592	7200	CLA	PDPP	3593	
3593	7200	CLA	PDPP	3594	
3594	7200	CLA	PDPP	3595	
3595	7200	CLA	PDPP	3596	
3596	7200	CLA	PDPP	3597	
3597	7200	CLA	PDPP	3598	
3598	7200	CLA	PDPP	3599	
3599	7200	CLA	PDPP	3600	
3600	7200	CLA	PDPP	3601	
3601	7200	CLA	PDPP	3602	
3602	7200	CLA	PDPP	3603	
3603	7200	CLA	PDPP	3604	
3604	7200	CLA	PDPP	3605	
3605	7200	CLA	PDPP	3606	

3607 7200 TST83, CLA
 /DOES IO RESET CLEAR INPUT ENABLE PLOPS
 3610 6132 CLR
 3611 6133 TA0 K0077
 /CLEAR ALL MODES
 3612 6141 CLEN
 /ENABLE INPUTS TO ALL CHAN
 3613 6142 LDIAI
 /ENTER LINC MODE
 3614 6143 LINC
 /ENTER LINC MODE
 3615 0020 0020
 3616 0004 E9F
 /DO IO RESET
 3617 0002 PDP
 /ENTER POP MODE
 3618 6135 CLA
 /CLEAR STATUS
 3619 1113 TA0 K0077
 /SIMULATE INPUTS ON ALL CHAN
 3620 6132 CLA
 /CLEAR STATUS
 3621 7200 CLA
 /CLEAR STATUS
 3622 1113 TA0 K0077
 /CLEAR STATUS
 3623 6132 CLA
 /CLEAR STATUS
 3624 7200 CLA
 /CLEAR STATUS
 3625 6135 CLA
 /CLEAR STATUS
 3626 6134 CLA
 /CLEAR STATUS
 3627 7200 SNA CLA
 /IGNORE DIFLO
 3628 4430 JMS I ERROR
 /MESSAGE POINTER
 3629 4426 JMS I ERROR
 /STATUS NOT ZERO I/O PRESET FAILED
 3630 4430 JMS I ERROR
 /CHECK MONITOR
 3631 4426 HLT
 /ERROR HALT
 3632 4332 TST83M
 /TO NEXT TEST
 3633 7402 SKP CLA
 /ISZ LOOP; SCOPE LOOP
 3634 7610 TST83
 /ISZ LOOP; SCOPE LOOP
 3635 3607

/DOES IO PRESET CLEAR MODE 2
 3636 6133 TSTA4, CLAB
 /CLEAR MODES
 3637 6132 CLR
 3640 1114 TAD K0100
 /CLEAR MODES
 3641 6141 CLR
 /SET MODE 2(1) = CLR CNT
 3642 1020 LDAL
 /ENTER LINC MODE
 3643 0020 0002
 3644 0002 0002
 3645 0004 E8F
 /ENTER PDP MODE
 3647 7200 CLA
 3650 1141 TAD K5555
 /LOAD BUF WITH 3335
 3651 6133 CLAB
 3652 7200 CLA
 3653 1116 TAD K0200
 /GEN LOAD CNT
 3654 6134 CLBN
 3655 6137 CLCA
 /LOAD CNT TO AC
 3656 7700 SMA CLA
 3657 4430 JMS I NERROR
 /CHECK MONITOR
 3658 4432 JMS I ERROR
 /MESSAGE POINTERR
 3659 4433 JMS I ERROR
 /MODE 2 NOT CLEARED BY I/O PRESET
 3660 4434 JMS I ERROR
 /ERROR HALT
 3661 4435 TSTA4M
 /IISZ LOOP! SCOPE LOOP
 3662 7616 SKP CLA
 /TO NEXT TEST
 3663 7618 HLT
 /RESET TEST
 3664 3636 TSTA4
 /SET AC = 7777
 3665 7340 CLA CLR CMA
 /RESET REGA
 3666 3046 DCA REGA

3667	7604	TST85, LAS	/DOES IO PRESET CLEAR MODE 0
3670	7006	RTL	/IP RIGHT SW BIT 4(1)
3671	7718	RTL	/SKIP FAST SAM TEST
3672	7006	SPL	CLEAR ALL MODES
3673	7718	JMP	/READ KNOB 0
3674	7200	CLA	/ENTER LINC MODE
3675	6132	CLA	CLEAR ALL MODES
3676	6141	LINC	SAM1
3677	6100	LINC	SAM0
3678	0002	PDP	/READ KNOB 1
3679	0004	PDP	/ENTER PDP MODE
3680	0020	LDAI	ENABLE FAST SAM
3681	0040	ESF	DO IO PRESET
3682	0060	ESF	/SET MODE 0(1)
3683	0100	LDIA	READ KNOB 1
3684	0115	ESF	/ENTER PDP MODE
3685	0130	ESF	READ KNOB 1-PAST 0
3686	0141	ESF	READ KNOB 1-PAST 1
3687	0142	ESF	READ KNOB 1-PAST 2
3688	0143	ESF	READ KNOB 1-PAST 3
3689	0144	ESF	READ KNOB 1-PAST 4
3690	0145	ESF	READ KNOB 1-PAST 5
3691	0146	ESF	READ KNOB 1-PAST 6
3692	0147	ESF	READ KNOB 1-PAST 7
3693	0148	ESF	READ KNOB 1-PAST 8
3694	0149	ESF	READ KNOB 1-PAST 9
3695	0150	ESF	READ KNOB 1-PAST 10
3696	0151	ESF	READ KNOB 1-PAST 11
3697	0152	ESF	READ KNOB 1-PAST 12
3698	0153	ESF	READ KNOB 1-PAST 13
3699	0154	ESF	READ KNOB 1-PAST 14
3700	0155	ESF	READ KNOB 1-PAST 15
3701	0156	ESF	READ KNOB 1-PAST 16
3702	0157	ESF	READ KNOB 1-PAST 17
3703	0158	ESF	READ KNOB 1-PAST 18
3704	0159	ESF	READ KNOB 1-PAST 19
3705	0160	ESF	READ KNOB 1-PAST 20
3706	0161	ESF	READ KNOB 1-PAST 21
3707	0162	ESF	READ KNOB 1-PAST 22
3708	0163	ESF	READ KNOB 1-PAST 23
3709	0164	ESF	READ KNOB 1-PAST 24
3710	0165	ESF	READ KNOB 1-PAST 25
3711	0166	ESF	READ KNOB 1-PAST 26
3712	0167	ESF	READ KNOB 1-PAST 27
3713	0168	ESF	READ KNOB 1-PAST 28
3714	0169	ESF	READ KNOB 1-PAST 29
3715	0170	ESF	READ KNOB 1-PAST 30
3716	0171	ESF	READ KNOB 1-PAST 31
3717	0172	ESF	READ KNOB 1-PAST 32
3718	0173	ESF	READ KNOB 1-PAST 33
3719	0174	ESF	READ KNOB 1-PAST 34
3720	0175	ESF	READ KNOB 1-PAST 35
3721	0176	ESF	READ KNOB 1-PAST 36
3722	0177	ESF	READ KNOB 1-PAST 37
3723	0178	ESF	READ KNOB 1-PAST 38
3724	0179	ESF	READ KNOB 1-PAST 39
3725	0180	ESF	READ KNOB 1-PAST 40
3726	0181	ESF	READ KNOB 1-PAST 41
3727	0182	ESF	READ KNOB 1-PAST 42
3728	0183	ESF	READ KNOB 1-PAST 43
3729	0184	ESF	READ KNOB 1-PAST 44
3730	0185	ESF	READ KNOB 1-PAST 45
3731	0186	ESF	READ KNOB 1-PAST 46
3732	0187	ESF	READ KNOB 1-PAST 47
3733	0188	ESF	READ KNOB 1-PAST 48
3734	0189	ESF	READ KNOB 1-PAST 49
3735	0190	ESF	READ KNOB 1-PAST 50
3736	0191	ESF	READ KNOB 1-PAST 51
3737	0192	ESF	READ KNOB 1-PAST 52
3738	0193	ESF	READ KNOB 1-PAST 53
3739	0194	ESF	READ KNOB 1-PAST 54
3740	0195	ESF	READ KNOB 1-PAST 55
3741	0196	ESF	READ KNOB 1-PAST 56
3742	0197	ESF	READ KNOB 1-PAST 57
3743	0198	ESF	READ KNOB 1-PAST 58
3744	0199	ESF	READ KNOB 1-PAST 59
3745	0200	ESF	READ KNOB 1-PAST 60
3746	0201	ESF	READ KNOB 1-PAST 61
3747	0202	ESF	READ KNOB 1-PAST 62
3748	0203	ESF	READ KNOB 1-PAST 63
3749	0204	ESF	READ KNOB 1-PAST 64
3750	0205	ESF	READ KNOB 1-PAST 65
3751	0206	ESF	READ KNOB 1-PAST 66
3752	0207	ESF	READ KNOB 1-PAST 67
3753	0208	ESF	READ KNOB 1-PAST 68
3754	0209	ESF	READ KNOB 1-PAST 69
3755	0210	ESF	READ KNOB 1-PAST 70
3756	0211	ESF	READ KNOB 1-PAST 71
3757	0212	ESF	READ KNOB 1-PAST 72
3758	0213	ESF	READ KNOB 1-PAST 73
3759	0214	ESF	READ KNOB 1-PAST 74
3760	0215	ESF	READ KNOB 1-PAST 75
3761	0216	ESF	READ KNOB 1-PAST 76
3762	0217	ESF	READ KNOB 1-PAST 77
3763	0218	ESF	READ KNOB 1-PAST 78
3764	0219	ESF	READ KNOB 1-PAST 79
3765	0220	ESF	READ KNOB 1-PAST 80
3766	0221	ESF	READ KNOB 1-PAST 81
3767	0222	ESF	READ KNOB 1-PAST 82
3768	0223	ESF	READ KNOB 1-PAST 83
3769	0224	ESF	READ KNOB 1-PAST 84
3770	0225	ESF	READ KNOB 1-PAST 85
3771	0226	ESF	READ KNOB 1-PAST 86
3772	0227	ESF	READ KNOB 1-PAST 87
3773	0228	ESF	READ KNOB 1-PAST 88
3774	0229	ESF	READ KNOB 1-PAST 89
3775	0230	ESF	READ KNOB 1-PAST 90
3776	0231	ESF	READ KNOB 1-PAST 91
3777	0232	ESF	READ KNOB 1-PAST 92
3778	0233	ESF	READ KNOB 1-PAST 93
3779	0234	ESF	READ KNOB 1-PAST 94
3780	0235	ESF	READ KNOB 1-PAST 95
3781	0236	ESF	READ KNOB 1-PAST 96
3782	0237	ESF	READ KNOB 1-PAST 97
3783	0238	ESF	READ KNOB 1-PAST 98
3784	0239	ESF	READ KNOB 1-PAST 99
3785	0240	ESF	READ KNOB 1-PAST 100
3786	0241	ESF	READ KNOB 1-PAST 101
3787	0242	ESF	READ KNOB 1-PAST 102
3788	0243	ESF	READ KNOB 1-PAST 103
3789	0244	ESF	READ KNOB 1-PAST 104
3790	0245	ESF	READ KNOB 1-PAST 105
3791	0246	ESF	READ KNOB 1-PAST 106
3792	0247	ESF	READ KNOB 1-PAST 107
3793	0248	ESF	READ KNOB 1-PAST 108
3794	0249	ESF	READ KNOB 1-PAST 109
3795	0250	ESF	READ KNOB 1-PAST 110
3796	0251	ESF	READ KNOB 1-PAST 111
3797	0252	ESF	READ KNOB 1-PAST 112
3798	0253	ESF	READ KNOB 1-PAST 113
3799	0254	ESF	READ KNOB 1-PAST 114
3800	0255	ESF	READ KNOB 1-PAST 115
3801	0256	ESF	READ KNOB 1-PAST 116
3802	0257	ESF	READ KNOB 1-PAST 117
3803	0258	ESF	READ KNOB 1-PAST 118
3804	0259	ESF	READ KNOB 1-PAST 119
3805	0260	ESF	READ KNOB 1-PAST 120
3806	0261	ESF	READ KNOB 1-PAST 121
3807	0262	ESF	READ KNOB 1-PAST 122
3808	0263	ESF	READ KNOB 1-PAST 123
3809	0264	ESF	READ KNOB 1-PAST 124
3810	0265	ESF	READ KNOB 1-PAST 125
3811	0266	ESF	READ KNOB 1-PAST 126
3812	0267	ESF	READ KNOB 1-PAST 127
3813	0268	ESF	READ KNOB 1-PAST 128
3814	0269	ESF	READ KNOB 1-PAST 129
3815	0270	ESF	READ KNOB 1-PAST 130
3816	0271	ESF	READ KNOB 1-PAST 131
3817	0272	ESF	READ KNOB 1-PAST 132
3818	0273	ESF	READ KNOB 1-PAST 133
3819	0274	ESF	READ KNOB 1-PAST 134
3820	0275	ESF	READ KNOB 1-PAST 135
3821	0276	ESF	READ KNOB 1-PAST 136
3822	0277	ESF	READ KNOB 1-PAST 137
3823	0278	ESF	READ KNOB 1-PAST 138
3824	0279	ESF	READ KNOB 1-PAST 139
3825	0280	ESF	READ KNOB 1-PAST 140
3826	0281	ESF	READ KNOB 1-PAST 141
3827	0282	ESF	READ KNOB 1-PAST 142
3828	0283	ESF	READ KNOB 1-PAST 143
3829	0284	ESF	READ KNOB 1-PAST 144
3830	0285	ESF	READ KNOB 1-PAST 145
3831	0286	ESF	READ KNOB 1-PAST 146
3832	0287	ESF	READ KNOB 1-PAST 147
3833	0288	ESF	READ KNOB 1-PAST 148
3834	0289	ESF	READ KNOB 1-PAST 149
3835	0290	ESF	READ KNOB 1-PAST 150
3836	0291	ESF	READ KNOB 1-PAST 151
3837	0292	ESF	READ KNOB 1-PAST 152
3838	0293	ESF	READ KNOB 1-PAST 153
3839	0294	ESF	READ KNOB 1-PAST 154
3840	0295	ESF	READ KNOB 1-PAST 155
3841	0296	ESF	READ KNOB 1-PAST 156
3842	0297	ESF	READ KNOB 1-PAST 157
3843	0298	ESF	READ KNOB 1-PAST 158
3844	0299	ESF	READ KNOB 1-PAST 159
3845	0300	ESF	READ KNOB 1-PAST 160
3846	0301	ESF	READ KNOB 1-PAST 161
3847	0302	ESF	READ KNOB 1-PAST 162
3848	0303	ESF	READ KNOB 1-PAST 163
3849	0304	ESF	READ KNOB 1-PAST 164
3850	0305	ESF	READ KNOB 1-PAST 165
3851	0306	ESF	READ KNOB 1-PAST 166
3852	0307	ESF	READ KNOB 1-PAST 167
3853	0308	ESF	READ KNOB 1-PAST 168
3854	0309	ESF	READ KNOB 1-PAST 169
3855	0310	ESF	READ KNOB 1-PAST 170
3856	0311	ESF	READ KNOB 1-PAST 171
3857	0312	ESF	READ KNOB 1-PAST 172
3858	0313	ESF	READ KNOB 1-PAST 173
3859	0314	ESF	READ KNOB 1-PAST 174
3860	0315	ESF	READ KNOB 1-PAST 175
3861	0316	ESF	READ KNOB 1-PAST 176
3862	0317	ESF	READ KNOB 1-PAST 177
3863	0318	ESF	READ KNOB 1-PAST 178
3864	0319	ESF	READ KNOB 1-PAST 179
3865	0320	ESF	READ KNOB 1-PAST 180
3866	0321	ESF	READ KNOB 1-PAST 181
3867	0322	ESF	READ KNOB 1-PAST 182
3868	0323	ESF	READ KNOB 1-PAST 183
3869	0324	ESF	READ KNOB 1-PAST 184
3870	0325	ESF	READ KNOB 1-PAST 185
3871	0326	ESF	READ KNOB 1-PAST 186
3872	0327	ESF	READ KNOB 1-PAST 187
3873	0328	ESF	READ KNOB 1-PAST 188
3874	0329	ESF	READ KNOB 1-PAST 189
3875	0330	ESF	READ KNOB 1-PAST 190
3876	0331	ESF	READ KNOB 1-PAST 191
3877	0332	ESF	READ KNOB 1-PAST 192
3878	0333	ESF	READ KNOB 1-PAST 193
3879	0334	ESF	READ KNOB 1-PAST 194
3880	0335	ESF	READ KNOB 1-PAST 195
3881	0336	ESF	READ KNOB 1-PAST 196
3882	0337	ESF	READ KNOB 1-PAST 197
3883	0338	ESF	READ KNOB 1-PAST 198
3884	0339	ESF	READ KNOB 1-PAST 199
3885	0340	ESF	READ KNOB 1-PAST 200
3886	0341	ESF	READ KNOB 1-PAST 201
3887	0342	ESF	READ KNOB 1-PAST 202
3888	0343	ESF	READ KNOB 1-PAST 203
3889	0344	ESF	READ KNOB 1-PAST 204
3890	0345	ESF	READ KNOB 1-PAST 205
3891	0346	ESF	READ KNOB 1-PAST 206
3892	0347	ESF	READ KNOB 1-PAST 207
3893	0348	ESF	READ KNOB 1-PAST 208
3894	0349	ESF	READ KNOB 1-PAST 209
3895	0350	ESF	READ KNOB 1-PAST 210
3896	0351	ESF	READ KNOB 1-PAST 211
3897	0352	ESF	READ KNOB 1-PAST 212
3898	0353	ESF	READ KNOB 1-PAST 213
3899	0354	ESF	READ KNOB 1-PAST 214
3900	0355	ESF	READ KNOB 1-PAST 215
3901	0356	ESF	READ KNOB 1-PAST 216
3902	0357	ESF	READ KNOB 1-PAST 217
3903	0358	ESF	READ KNOB 1-PAST 218
3904	0359	ESF	READ KNOB 1-PAST 219
3905	0360	ESF	READ KNOB 1-PAST 220
3906	0361	ESF	READ KNOB 1-PAST 221
3907	0362	ESF	READ KNOB 1-PAST 222
3908	0363	ESF	READ KNOB 1-PAST 223
3909	0364	ESF	READ KNOB 1-PAST 224
3910	0365	ESF	READ KNOB 1-PAST 225
3911	0366	ESF	READ KNOB 1-PAST 226
3912	0367	ESF	READ KNOB 1-PAST 227
3913			

3734	6141	TST86,	LINC	/		
3735	0100	SAM0	POP			
3736	0002	/READ KNOB 0				
3737	7041	CIA	SEND			
3740	1054	TAD				
3741	7658	SNA CIA				
3742	4430	JMS I	ERROR			
3743	4426	JMS I	ERROR			
3744	4430	TST86H				
3745	7402	HLT				
3746	7410	SKP				
3747	3734	TST86				
3748	7410	/TO NEXT TEST				
3749	7402	/ERROR HALT				
3750	7340	CIA CBL CMA				
3751	3046	DCA REGA				
3752	2047	ISZ REGB				
3753	5267	JMP TS165				
3754	1107	RESET, TAD K0020				
3755	6141	LINC /PIICK UP AC B1T 07				
3756	0002	ESF /10 PRESET				
3757	0004	POP /00 10 MODE				
3758	7200	CLB /TO MODE				
3759	7200	TAD /CLEAR THE AC				
3760	7200	REGA /RESET REGA PRIOR TO NEXT TEST				

3763	7200	T5T87,	CLA	T5T87,	CLA																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
3764	6132	CLR	CLR	3764	JMS I	RANDOM	/DOES MODE 1(3) WORK CHAN 1																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
3765	6133	CLR	CLR	3765	JMS I	SEND	/CLEAR ALL MODES																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
3766	4445	JMS	JMS	3766	DCA	SEND	/GET RANDOM NUM																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
3767	3054	TAD	TAD	3767	DCA	SEND	/SEND RANDOM NUM TO BUF																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
3770	1054	CLA	CLA	3770	6133	CLA	3772	7200	CLA	3773	1114	CLA	3774	6132	CLR	3775	6135	CLA	3776	7200	CLA	3777	1116	CLA	3778	1116	CLA	3779	6132	CLR	3780	6132	CLR	3781	6132	CLR	3782	6132	CLR	3783	6132	CLR	3784	6132	CLR	3785	6132	CLR	3786	6132	CLR	3787	6132	CLR	3788	6132	CLR	3789	6132	CLR	3790	6132	CLR	3791	6132	CLR	3792	6132	CLR	3793	6132	CLR	3794	6132	CLR	3795	6132	CLR	3796	6132	CLR	3797	6132	CLR	3798	6132	CLR	3799	6132	CLR	3800	6132	CLR	3801	6132	CLR	3802	6132	CLR	3803	6132	CLR	3804	6132	CLR	3805	6132	CLR	3806	6132	CLR	3807	6132	CLR	3808	6132	CLR	3809	6132	CLR	3810	6132	CLR	3811	6132	CLR	3812	6132	CLR	3813	6132	CLR	3814	6132	CLR	3815	6132	CLR	3816	6132	CLR	3817	6132	CLR	3818	6132	CLR	3819	6132	CLR	3820	6132	CLR	3821	6132	CLR	3822	6132	CLR	3823	6132	CLR	3824	6132	CLR	3825	6132	CLR	3826	6132	CLR	3827	6132	CLR	3828	6132	CLR	3829	6132	CLR	3830	6132	CLR	3831	6132	CLR	3832	6132	CLR	3833	6132	CLR	3834	6132	CLR	3835	6132	CLR	3836	6132	CLR	3837	6132	CLR	3838	6132	CLR	3839	6132	CLR	3840	6132	CLR	3841	6132	CLR	3842	6132	CLR	3843	6132	CLR	3844	6132	CLR	3845	6132	CLR	3846	6132	CLR	3847	6132	CLR	3848	6132	CLR	3849	6132	CLR	3850	6132	CLR	3851	6132	CLR	3852	6132	CLR	3853	6132	CLR	3854	6132	CLR	3855	6132	CLR	3856	6132	CLR	3857	6132	CLR	3858	6132	CLR	3859	6132	CLR	3860	6132	CLR	3861	6132	CLR	3862	6132	CLR	3863	6132	CLR	3864	6132	CLR	3865	6132	CLR	3866	6132	CLR	3867	6132	CLR	3868	6132	CLR	3869	6132	CLR	3870	6132	CLR	3871	6132	CLR	3872	6132	CLR	3873	6132	CLR	3874	6132	CLR	3875	6132	CLR	3876	6132	CLR	3877	6132	CLR	3878	6132	CLR	3879	6132	CLR	3880	6132	CLR	3881	6132	CLR	3882	6132	CLR	3883	6132	CLR	3884	6132	CLR	3885	6132	CLR	3886	6132	CLR	3887	6132	CLR	3888	6132	CLR	3889	6132	CLR	3890	6132	CLR	3891	6132	CLR	3892	6132	CLR	3893	6132	CLR	3894	6132	CLR	3895	6132	CLR	3896	6132	CLR	3897	6132	CLR	3898	6132	CLR	3899	6132	CLR	3900	6132	CLR	3901	6132	CLR	3902	6132	CLR	3903	6132	CLR	3904	6132	CLR	3905	6132	CLR	3906	6132	CLR	3907	6132	CLR	3908	6132	CLR	3909	6132	CLR	3910	6132	CLR	3911	6132	CLR	3912	6132	CLR	3913	6132	CLR	3914	6132	CLR	3915	6132	CLR	3916	6132	CLR	3917	6132	CLR	3918	6132	CLR	3919	6132	CLR	3920	6132	CLR	3921	6132	CLR	3922	6132	CLR	3923	6132	CLR	3924	6132	CLR	3925	6132	CLR	3926	6132	CLR	3927	6132	CLR	3928	6132	CLR	3929	6132	CLR	3930	6132	CLR	3931	6132	CLR	3932	6132	CLR	3933	6132	CLR	3934	6132	CLR	3935	6132	CLR	3936	6132	CLR	3937	6132	CLR	3938	6132	CLR	3939	6132	CLR	3940	6132	CLR	3941	6132	CLR	3942	6132	CLR	3943	6132	CLR	3944	6132	CLR	3945	6132	CLR	3946	6132	CLR	3947	6132	CLR	3948	6132	CLR	3949	6132	CLR	3950	6132	CLR	3951	6132	CLR	3952	6132	CLR	3953	6132	CLR	3954	6132	CLR	3955	6132	CLR	3956	6132	CLR	3957	6132	CLR	3958	6132	CLR	3959	6132	CLR	3960	6132	CLR	3961	6132	CLR	3962	6132	CLR	3963	6132	CLR	3964	6132	CLR	3965	6132	CLR	3966	6132	CLR	3967	6132	CLR	3968	6132	CLR	3969	6132	CLR	3970	6132	CLR	3971	6132	CLR	3972	6132	CLR	3973	6132	CLR	3974	6132	CLR	3975	6132	CLR	3976	6132	CLR	3977	6132	CLR	3978	6132	CLR	3979	6132	CLR	3980	6132	CLR	3981	6132	CLR	3982	6132	CLR	3983	6132	CLR	3984	6132	CLR	3985	6132	CLR	3986	6132	CLR	3987	6132	CLR	3988	6132	CLR	3989	6132	CLR	3990	6132	CLR	3991	6132	CLR	3992	6132	CLR	3993	6132	CLR	3994	6132	CLR	3995	6132	CLR	3996	6132	CLR	3997	6132	CLR	3998	6132	CLR	3999	6132	CLR	4000	6132	CLR	4001	6132	CLR	4002	6132	CLR	4003	6132	CLR	4004	6132	CLR	4005	6132	CLR	4006	6132	CLR	4007	6132	CLR	4008	6132	CLR	4009	6132	CLR	4010	6132	CLR	4011	6132	CLR	4012	6132	CLR	4013	6132	CLR	4014	6132	CLR	4015	6132	CLR	4016	6132	CLR	4017	6132	CLR	4018	6132	CLR	4019	6132	CLR	4020	6132	CLR	4021	6132	CLR	4022	6132	CLR	4023	6132	CLR	4024	6132	CLR	4025	6132	CLR	4026	6132	CLR	4027	6132	CLR	4028	6132	CLR	4029	6132	CLR	4030	6132	CLR	4031	6132	CLR

4032	6134	TST88, CLEN	CLSA	/CLEAR ENABLES	4033	6135	TST88, CLEN	CLSA	/CLEAR CLEAR CLKCK STATUS	4034	7200	CLSA	CLSA	/CLEAR CLKCK STATUS	4035	6133	CLAB	CLAB	/CLEAR BUFFER	4036	1104	TAD	K0814		4037	6134	CLEN	CLEN	/ENABLE CHAN 2 INPUT AND INT	4038	2040	I132	REG8	/INCREMENT TIMER	4039	7410	SKP	JMP	/TIME OUT	4040	52445	CL8K	JMP	,#4	4041	6135	CL8A	CL8A	/CLEAR STATUS	4042	52440	JHP	JMP	,#4	4043	6131	CL8A	CL8A	/CLEAR STATUS	4044	3047	REG8	REG8	/CLEAR REG8	4045	6136	CIA	CIA	/GET BUFFER	4046	7200	TAD	SEND	/COMPARE	4047	6136	REG8	REG8	/CLEAR REG8	4048	2041	TAD	SMS	/CHECK MONITOR	4049	7410	SKP	HLT	/CLEAR HALT	4050	4476	TST88M	JMS	/CLEAR MONTOR	4051	6136	REG8	REG8	/CLEAR MONTOR	4052	7054	TAD	ERROR	/CHAN INPUT FAILED TO CAUSE CNT TO BUF TRANSFER	4053	7650	JMS	JMS	/CLEAR MONTOR	4054	4426	TAD	ERROR	/CHAN INPUT FAILED TO CAUSE CNT TO BUF TRANSFER	4055	4426	JMS	JMS	/CLEAR MONTOR	4056	4476	TST88M	JMS	/CLEAR MONTOR	4057	7402	SKP	HLT	/CLEAR HALT	4058	4476	TST88M	JMS	/CLEAR HALT	4059	1151	TAD	M8840	/CLEAR HALT	4060	4032	TAD	REGA	/CLEAR HALT	4061	4032	TAD	REGA	/CLEAR HALT	4062	3046	DCA	REGA	/CLEAR HALT
------	------	-------------	------	----------------	------	------	-------------	------	---------------------------	------	------	------	------	---------------------	------	------	------	------	---------------	------	------	-----	-------	--	------	------	------	------	------------------------------	------	------	------	------	------------------	------	------	-----	-----	-----------	------	-------	------	-----	-----	------	------	------	------	---------------	------	-------	-----	-----	-----	------	------	------	------	---------------	------	------	------	------	-------------	------	------	-----	-----	-------------	------	------	-----	------	----------	------	------	------	------	-------------	------	------	-----	-----	----------------	------	------	-----	-----	-------------	------	------	--------	-----	---------------	------	------	------	------	---------------	------	------	-----	-------	---	------	------	-----	-----	---------------	------	------	-----	-------	---	------	------	-----	-----	---------------	------	------	--------	-----	---------------	------	------	-----	-----	-------------	------	------	--------	-----	-------------	------	------	-----	-------	-------------	------	------	-----	------	-------------	------	------	-----	------	-------------	------	------	-----	------	-------------

4864 6134 TST89, CLEN /00E5 MODE 1 (1) WORK CHAN 3
4865 6135 CLSA /CLEAR STATUS
4866 7200 CLA /CLEAR ENABLE
4867 6133 CLAB /CLEAR BUFFER
4070 2077 TA0 K2003
4071 6134 CLEN /CLEAR ENABLE
4072 2047 IS2 REG8
4073 7410 SKP /NOT DONE yet
4074 5277 JMP /TIME OUT
4075 6131 CLSK ,#3
4076 5272 JMP ,#4
4077 6135 GLSA /CLEAR STATUS
4078 7200 CLA /CLEAR
4079 2047 CLCA REG8
4080 7410 IS2 REG8
4081 5277 JMP /CLEAR INT
4082 6136 CLSK ,#3
4083 5272 JMP ,#4
4084 7200 CLA /CLEAR
4085 6136 CLCA REG8
4086 7200 CLA /CLEAR STATUS
4087 2047 CLEN K2003
4088 7410 IS2 REG8
4089 5277 JMP /CLEAR INT
4090 6134 CLCA REG8
4091 5272 JMP ,#4
4092 2047 CLEN K2003
4093 7410 IS2 REG8
4094 5277 JMP /CLEAR INT
4095 6134 CLCA REG8
4096 7200 CLA /CLEAR STATUS
4097 2047 CLAB K2003
4098 7410 IS2 REG8
4099 5277 JMP /CLEAR INT
4100 7200 CLA /CLEAR
4101 5047 DCA REG8
4102 7410 HLT /CLEAR HALT
4103 6136 CLCA REG8
4104 7042 SNA CLA SEND
4105 7650 JMS I ERROR
4106 4426 JMS I ERROR
4107 7410 TSP89M /CLEAR POINTER
4108 7410 HLT /CLEAR POINT
4109 7410 SKP /CLEAR POINT
4110 7410 TS89M /CLEAR POINT
4111 7410 HLT /CLEAR POINT
4112 7410 SNA CLA /CLEAR POINT
4113 7410 TS89 /CLEAR POINT
4114 7540 CLA CLR GMA /CLEAR POINT
4115 3046 DCA REGA /CLEAR POINT
4116 1151 TAD M0040 /CLEAR POINT
4117 3047 DCA REGB /CLEAR POINT
4118 7410 CLA CLR GMA /CLEAR POINT
4119 7410 TS89 /CLEAR POINT
4120 7410 TS89 /CLEAR POINT
4121 7410 TS89 /CLEAR POINT
4122 7410 TS89 /CLEAR POINT
4123 7410 TS89 /CLEAR POINT
4124 7410 TS89 /CLEAR POINT
4125 7410 TS89 /CLEAR POINT
4126 7410 TS89 /CLEAR POINT
4127 3047 TS89 /CLEAR POINT

/TEST MODE (1) AND MODE (2) CHAN 2
 4120 6134 TSTA0, CLRN /CLEAR ENABLES
 4121 1120 TA0 K0300 /CLEAR
 4122 1127 TA0 K1000 /START CNT RATE@400KHZ = MODE (1) AND (2)
 4123 6132 CLR /STOP CNT = MODE (1) AND (2)
 4124 7200 CLA /CLEAR
 4125 1120 TA0 K0300 CLR /CLEAR
 4126 6132 CLR TA0 K0300 /CLEAR
 4127 6137 CLCA DCA SEND /GET CNT
 4128 3054 CLSA DCA SEND /STORE
 4129 6133 CLA /CLEAR
 4130 7200 CLA /CLEAR
 4131 6135 CLSA DCA SEND /CLEAR
 4132 1122 TA0 K0060 /CLEAR BUF
 4133 6134 CLRN /ENABLE CHANNELS INPUT AND EN
 4134 2051 CLRN ISZ REGT /INCREMENT TIMER
 4135 6134 CLRN ISZ REGT /NOT DONE yet
 4136 7410 SKP JHP /TIME OUT
 4137 2051 CLRN ISZ REGT /INCREMENT TIMER
 4138 6134 CLRN ISZ REGT /NOT DONE yet
 4139 6134 CLRN ISZ REGT /INCREMENT TIMER
 4140 2343 SKP JHP /SKP ON CLOCK INT
 4141 6131 CLSK JHP ,=4 /CLEAR CLOCK INT
 4142 5356 JHP ,=4 /CLEAR CLOCK INT
 4143 6135 CLSA DCA SEND /CLEAR CLOCK STATUS
 4144 7200 DCA REGT /CLEAR TIMER
 4145 3051 CLA DCA SEND /CLEAR BUF
 4146 6136 CLBA DCA REGT /CLEAR
 4147 7041 CLIA TA0 SEND /CLEAR
 4148 6136 CLBA DCA SEND /COMPARE
 4149 7041 CLIA TA0 SEND /CLEAR
 4150 7650 SNA CLA DCA CLR CMRA /CLEAR
 4151 1054 CLA DCA SEND /CLEAR
 4152 4426 JMS I ERROR TS190M /CHECK MONITOR
 4153 4430 JMS I ERROR TS190M /CHANNEL FAILED TO CAUSE CNT TO BUF TRANSFER
 4154 4552 HLT TS190M /MESSAGE POINTER
 4155 7402 /ERROR HALT
 4156 7410 SKP TS190M /TO NEXT TEST
 4157 4320 TS190M /ISZ LOOP! SCOPE LOOP
 4158 7410 CLA DCA CLR CMRA /CLEAR
 4159 7402 CLA DCA CLR CMRA /CLEAR
 4160 7340 CLA DCA CLR CMRA /CLEAR
 4161 3046 CLA DCA CLR CMRA /CLEAR

/TEST MODE 1 (1) AND MODE 2 (2) CHAN 2
 4162 6134 T5T91, CLEN
 4163 6135 CLSA
 4164 7200 CLA
 4165 6133 /CLEAR STATUS
 4166 1104 CLAB
 4167 6134 K0014
 4168 /CLEAR BUF
 4169 6133 CLEN
 4170 2051 REGT
 4171 7410 SKB
 4172 5375 JMP
 4173 6131 CLSK
 4174 5370 JHP
 4175 6135 ,=4
 4176 7200 CLA
 4177 3051 DCA
 4178 7000 NOP
 4179 6136 CLBA
 4180 7041 GJA
 4181 2054 TAD
 4182 7650 SNA CLA
 4183 4436 JMS 1 ERROR
 4184 7402 T5T91H
 4185 4430 HLT
 4186 7610 SKP CLA
 4187 9162 T5T91
 4188 7340 CLA CLR CMA
 4189 3046 REGA
 4210 7402 /CLEAR MONITOR
 4211 7610 /CHAN 2 INPUT FAILED TO CAUSE GNT TO BUF TRANSFER
 4212 9162 T5T91H
 4213 7340 CLA CLR CMA
 4214 3046 REGA
 4215 4430 HLT
 4216 7610 SKP CLA
 4217 9162 T5T91
 4218 7610 CLA CLR CMA
 4219 3046 REGA

/TEST MODE 1 (1) AND MODE 2 (2) CHAN 3
 4215 6134 TST92, CLEN /CLEAR ENABLES
 4216 6135 CLSA
 4217 7200 CLA
 4220 6133 CLAB
 4221 2077 TA0 K0003 /CLEAR BUF
 4222 6134 CLEN /ENABLES CHAN3 INPUT AND INT
 4223 2051 IS2 REGT /INCREMENT TIMER
 4224 7410 SKP .#3 /TIME OUT
 4225 9230 JMP .#4 /NOT DONE YET
 4226 6131 CLSK /SKP ON CLOCK INT
 4227 5223 JMP .#4
 4228 6135 CLSA /CLEAR CLOCK STATUS
 4229 7200 CLA
 4230 3051 DCA REGT /CLEAR REG
 4231 2000 NOP
 4232 6136 CLBA /C2T BUF
 4233 7041 CIA
 4234 6136 SEND TAD /COMPARE
 4235 7042 TS192M JMS I ERROR
 4236 4426 TS192M JMS I NERROR
 4237 7630 SNA CLA
 4238 4538 DCA REGT /CHAN 3 INPUT FAILED TO CAUSE GNT TO BUF TRANSFER
 4240 7540 CLA CBL CMA /SET AC = 7777
 4241 4426 TS192 SKE /TO NEXT TEST
 4242 7410 HLT /ERROR HALT
 4243 4626 TS192M JMS I ERRO
 4244 7410 SKB /MESSAGE POINTER
 4245 4215 TS192 /ISE LOOP! SCOPE LOOP
 4246 7540 DCA REGA /RESET REGA
 4247 3046 DCA REGA

/CHECK THAT CHAN 3 CLEARED COUNTER FROM TEST 92
 4250 6237 TSTA3 CLCA /GET CNT
 4251 3053 DCA RXED TAD RXED
 4252 1053 SNA CLA /SER07
 4253 7650 JMS I ERROR /CHECK MONITOR
 4254 4430 JMS I ERROR /CHAN INPUT FAILED TO CLEAR CNT
 4255 4435 TSTA3 CLCA /SER07
 4256 4654 HLT /MESSAGE POINT
 4257 7402 HLT /ERROR HALT
 4260 7410 SKP /TO NEXT TEST
 4261 4258 TSTA3 CLC GMA /ISZ LOOP! SCOPE LOOP
 4262 7340 DCA REGA /SET AC = 7777
 4263 3046 DCA REGA /RESET REGA
 4264 2047 ISZ REGA /RESET REGA
 4265 5464 JMP I TSTA90N /DO TESTS 90-93 40 TIMES
 4266 1151 TAD M0040 /TO TEST 90
 4267 3046 DCA REGA /RESET REGA
 4268 2047 ISZ REGA /RESET REGA
 4270 1071 TAD KRE /GET PRESET
 4271 6233 CLA8 /PRESET BUFFER
 4272 7200 CLA /
 4273 1073 CLA /GET RATE
 4274 6132 CLLR /START CLOCK
 4275 7200 CLA //
 4276 1072 TAD KEN /GET ENABLES
 4277 6234 CLSK //
 4278 1072 TAD KEN /WAIT FOR INTERRUPT
 4279 6131 CLSK //
 4280 7200 CLA /WAIT FOR OVERFLOW
 4281 5300 JMP ,=1 /
 4282 2051 ISZ REGT /WAIT FOR ANOTHER OVERFLOW
 4283 5302 JMP ,=2 /
 4284 7200 ISZ REGT /22 SEC DELAY
 4285 5303 CLSK //
 4286 6232 CLA /
 4287 6134 CLER //
 4288 6235 CLSA //
 4289 6236 CLER //
 4290 6237 CLCA //
 4291 6238 CLSA //
 4292 7402 CLCA /GET THE COUNTER
 4293 6239 CLA /COUNTER SHOULD NEVER GO POSITIVE
 4294 7440 S2A //
 4295 6240 CLCA //
 4296 4426 JMS I ERROR //ECO E42-00033 IS EITHER NOT INSTALLED OR NOT WORKING
 4297 7410 HLT //
 4298 4270 TSTA94 //
 4299 7422 SKP //
 4300 4435 JMS I ERROR //
 4301 7730 SPA CLA //
 4302 4702 JMS I ERROR //ECO E42-00033 IS EITHER NOT INSTALLED OR NOT WORKING
 4303 5302 ISZ REGT //
 4304 7200 ISZ REGT //
 4305 6232 CLA //
 4306 6234 CLER //
 4307 6235 CLSA //
 4308 6236 CLER //
 4309 6237 CLCA //
 4310 6238 CLSA //
 4311 7440 CLCA //
 4312 7730 CLER //
 4313 4435 SPA CLA //
 4314 4426 JMS I ERROR //
 4315 4702 TSTA94M //
 4316 7422 HLT //
 4317 7410 SKP //
 4318 4270 TSTA94 //
 4319 7422 CLSK //
 4320 6237 CLCA //
 4321 6238 CLSA //
 4322 7730 CLER //
 4323 4435 SPA CLA //
 4324 4426 JMS I ERROR //
 4325 4702 TSTA94M //
 4326 7440 CLCA //
 4327 6238 CLSA //
 4328 6239 CLER //
 4329 6240 CLCA //
 4330 6241 CLSA //
 4331 7440 CLCA //
 4332 6242 CLER //
 4333 6243 CLSA //
 4334 6244 CLER //
 4335 6245 CLCA //
 4336 6246 CLER //
 4337 6247 CLCA //
 4338 6248 CLSA //
 4339 6249 CLER //
 4340 6250 CLCA //
 4341 6251 ISZ REGT //
 4342 6252 CLSK //
 4343 6253 CLA //
 4344 6254 CLER //
 4345 6255 CLSA //
 4346 6256 CLER //
 4347 6257 CLCA //
 4348 6258 CLER //
 4349 6259 CLSA //
 4350 6260 CLER //
 4351 6261 CLCA //
 4352 6262 CLER //
 4353 6263 CLSA //
 4354 6264 CLER //
 4355 6265 CLCA //
 4356 6266 CLER //
 4357 6267 CLSA //
 4358 6268 CLER //
 4359 6269 CLCA //
 4360 6270 CLER //
 4361 6271 CLSA //
 4362 6272 CLER //
 4363 6273 CLCA //
 4364 6274 CLER //
 4365 6275 CLSA //
 4366 6276 CLER //
 4367 6277 CLCA //
 4368 6278 CLER //
 4369 6279 CLSA //
 4370 6280 CLER //
 4371 6281 CLCA //
 4372 6282 CLER //
 4373 6283 CLSA //
 4374 6284 CLER //
 4375 6285 CLCA //
 4376 6286 CLER //
 4377 6287 CLSA //
 4378 6288 CLER //
 4379 6289 CLCA //
 4380 6290 CLER //
 4381 6291 CLSA //
 4382 6292 CLER //
 4383 6293 CLCA //
 4384 6294 CLER //
 4385 6295 CLSA //
 4386 6296 CLER //
 4387 6297 CLCA //
 4388 6298 CLER //
 4389 6299 CLSA //
 4390 6300 CLER //
 4391 6301 CLCA //
 4392 6302 CLER //
 4393 6303 CLSA //
 4394 6304 CLER //
 4395 6305 CLCA //
 4396 6306 CLER //
 4397 6307 CLSA //
 4398 6308 CLER //
 4399 6309 CLCA //
 4400 6310 CLER //
 4401 6311 CLSA //
 4402 6312 CLER //
 4403 6313 CLCA //
 4404 6314 CLER //
 4405 6315 CLSA //
 4406 6316 CLER //
 4407 6317 CLCA //
 4408 6318 CLER //
 4409 6319 CLSA //
 4410 6320 CLER //
 4411 6321 CLCA //
 4412 6322 CLER //
 4413 6323 CLSA //
 4414 6324 CLER //
 4415 6325 CLCA //
 4416 6326 CLER //
 4417 6327 CLSA //
 4418 6328 CLER //
 4419 6329 CLCA //
 4420 6330 CLER //
 4421 6331 CLSA //
 4422 6332 CLER //
 4423 6333 CLCA //
 4424 6334 CLER //
 4425 6335 CLSA //
 4426 6336 CLER //
 4427 6337 CLCA //
 4428 6338 CLER //
 4429 6339 CLSA //
 4430 6340 CLER //
 4431 6341 CLCA //
 4432 6342 CLER //
 4433 6343 CLSA //
 4434 6344 CLER //
 4435 6345 CLCA //
 4436 6346 CLER //
 4437 6347 CLSA //
 4438 6348 CLER //
 4439 6349 CLCA //
 4440 6350 CLER //
 4441 6351 CLSA //
 4442 6352 CLER //
 4443 6353 CLCA //
 4444 6354 CLER //
 4445 6355 CLSA //
 4446 6356 CLER //
 4447 6357 CLCA //
 4448 6358 CLER //
 4449 6359 CLSA //
 4450 6360 CLER //
 4451 6361 CLCA //
 4452 6362 CLER //
 4453 6363 CLSA //
 4454 6364 CLER //
 4455 6365 CLCA //
 4456 6366 CLER //
 4457 6367 CLSA //
 4458 6368 CLER //
 4459 6369 CLCA //
 4460 6370 CLER //
 4461 6371 CLSA //
 4462 6372 CLER //
 4463 6373 CLCA //
 4464 6374 CLER //
 4465 6375 CLSA //
 4466 6376 CLER //
 4467 6377 CLCA //
 4468 6378 CLER //
 4469 6379 CLSA //
 4470 6380 CLER //
 4471 6381 CLCA //
 4472 6382 CLER //
 4473 6383 CLSA //
 4474 6384 CLER //
 4475 6385 CLCA //
 4476 6386 CLER //
 4477 6387 CLSA //
 4478 6388 CLER //
 4479 6389 CLCA //
 4480 6390 CLER //
 4481 6391 CLSA //
 4482 6392 CLER //
 4483 6393 CLCA //
 4484 6394 CLER //
 4485 6395 CLSA //
 4486 6396 CLER //
 4487 6397 CLCA //
 4488 6398 CLER //
 4489 6399 CLSA //
 4490 6400 CLER //
 4491 6401 CLCA //
 4492 6402 CLER //
 4493 6403 CLSA //
 4494 6404 CLER //
 4495 6405 CLCA //
 4496 6406 CLER //
 4497 6407 CLSA //
 4498 6408 CLER //
 4499 6409 CLCA //
 4500 6410 CLER //
 4501 6411 CLSA //
 4502 6412 CLER //
 4503 6413 CLCA //
 4504 6414 CLER //
 4505 6415 CLSA //
 4506 6416 CLER //
 4507 6417 CLCA //
 4508 6418 CLER //
 4509 6419 CLSA //
 4510 6420 CLER //
 4511 6421 CLCA //
 4512 6422 CLER //
 4513 6423 CLSA //
 4514 6424 CLER //
 4515 6425 CLCA //
 4516 6426 CLER //
 4517 6427 CLSA //
 4518 6428 CLER //
 4519 6429 CLCA //
 4520 6430 CLER //
 4521 6431 CLSA //
 4522 6432 CLER //
 4523 6433 CLCA //
 4524 6434 CLER //
 4525 6435 CLSA //
 4526 6436 CLER //
 4527 6437 CLCA //
 4528 6438 CLER //
 4529 6439 CLSA //
 4530 6440 CLER //
 4531 6441 CLCA //
 4532 6442 CLER //
 4533 6443 CLSA //
 4534 6444 CLER //
 4535 6445 CLCA //
 4536 6446 CLER //
 4537 6447 CLSA //
 4538 6448 CLER //
 4539 6449 CLCA //
 4540 6450 CLER //
 4541 6451 CLSA //
 4542 6452 CLER //
 4543 6453 CLCA //
 4544 6454 CLER //
 4545 6455 CLSA //
 4546 6456 CLER //
 4547 6457 CLCA //
 4548 6458 CLER //
 4549 6459 CLSA //
 4550 6460 CLER //
 4551 6461 CLCA //
 4552 6462 CLER //
 4553 6463 CLSA //
 4554 6464 CLER //
 4555 6465 CLCA //
 4556 6466 CLER //
 4557 6467 CLSA //
 4558 6468 CLER //
 4559 6469 CLCA //
 4560 6470 CLER //
 4561 6471 CLSA //
 4562 6472 CLER //
 4563 6473 CLCA //
 4564 6474 CLER //
 4565 6475 CLSA //
 4566 6476 CLER //
 4567 6477 CLCA //
 4568 6478 CLER //
 4569 6479 CLSA //
 4570 6480 CLER //
 4571 6481 CLCA //
 4572 6482 CLER //
 4573 6483 CLSA //
 4574 6484 CLER //
 4575 6485 CLCA //
 4576 6486 CLER //
 4577 6487 CLSA //
 4578 6488 CLER //
 4579 6489 CLCA //
 4580 6490 CLER //
 4581 6491 CLSA //
 4582 6492 CLER //
 4583 6493 CLCA //
 4584 6494 CLER //
 4585 6495 CLSA //
 4586 6496 CLER //
 4587 6497 CLCA //
 4588 6498 CLER //
 4589 6499 CLSA //
 4590 6500 CLER //
 4591 6501 CLCA //
 4592 6502 CLER //
 4593 6503 CLSA //
 4594 6504 CLER //
 4595 6505 CLCA //
 4596 6506 CLER //
 4597 6507 CLSA //
 4598 6508 CLER //
 4599 6509 CLCA //
 4600 6510 CLER //
 4601 6511 CLSA //
 4602 6512 CLER //
 4603 6513 CLCA //
 4604 6514 CLER //
 4605 6515 CLSA //
 4606 6516 CLER //
 4607 6517 CLCA //
 4608 6518 CLER //
 4609 6519 CLSA //
 4610 6520 CLER //
 4611 6521 CLCA //
 4612 6522 CLER //
 4613 6523 CLSA //
 4614 6524 CLER //
 4615 6525 CLCA //
 4616 6526 CLER //
 4617 6527 CLSA //
 4618 6528 CLER //
 4619 6529 CLCA //
 4620 6530 CLER //
 4621 6531 CLSA //
 4622 6532 CLER //
 4623 6533 CLCA //
 4624 6534 CLER //
 4625 6535 CLSA //
 4626 6536 CLER //
 4627 6537 CLCA //
 4628 6538 CLER //
 4629 6539 CLSA //
 4630 6540 CLER //
 4631 6541 CLCA //
 4632 6542 CLER //
 4633 6543 CLSA //
 4634 6544 CLER //
 4635 6545 CLCA //
 4636 6546 CLER //
 4637 6547 CLSA //
 4638 6548 CLER //
 4639 6549 CLCA //
 4640 6550 CLER //
 4641 6551 CLSA //
 4642 6552 CLER //
 4643 6553 CLCA //
 4644 6554 CLER //
 4645 6555 CLSA //
 4646 6556 CLER //
 4647 6557 CLCA //
 4648 6558 CLER //
 4649 6559 CLSA //
 4650 6560 CLER //
 4651 6561 CLCA //
 4652 6562 CLER //
 4653 6563 CLSA //
 4654 6564 CLER //
 4655 6565 CLCA //
 4656 6566 CLER //
 4657 6567 CLSA //
 4658 6568 CLER //
 4659 6569 CLCA //
 4660 6570 CLER //
 4661 6571 CLSA //
 4662 6572 CLER //
 4663 6573 CLCA //
 4664 6574 CLER //
 4665 6575 CLSA //
 4666 6576 CLER //
 4667 6577 CLCA //
 4668 6578 CLER //
 4669 6579 CLSA //
 4670 6580 CLER //
 4671 6581 CLCA //
 4672 6582 CLER //
 4673 6583 CLSA //
 4674 6584 CLER //
 4675 6585 CLCA //
 4676 6586 CLER //
 4677 6587 CLSA //
 4678 6588 CLER //
 4679 6589 CLCA //
 4680 6590 CLER //
 4681 6591 CLSA //
 4682 6592 CLER //
 4683 6593 CLCA //
 4684 6594 CLER //
 4685 6595 CLSA //
 4686 6596 CLER //
 4687 6597 CLCA //
 4688 6598 CLER //
 4689 6599 CLSA //
 4690 6600 CLER //
 4691 6601 CLCA //
 4692 6602 CLER //
 4693 6603 CLSA //
 4694 6604 CLER //
 4695 6605 CLCA //
 4696 6606 CLER //
 4697 6607 CLSA //
 4698 6608 CLER //
 4699 6609 CLCA //
 4700 6610 CLER //
 4701 6611 CLSA //
 4702 6612 CLER //
 4703 6613 CLCA //
 4704 6614 CLER //
 4705 6615 CLSA //
 4706 6616 CLER //
 4707 6617 CLCA //
 4708 6618 CLER //
 4709 6619 CLSA //
 4710 6620 CLER //
 4711 6621 CLCA //
 4712 6622 CLER //
 4713 6623 CLSA //
 4714 6624 CLER //
 4715 6625 CLCA //
 4716 6626 CLER //
 4717 6627 CLSA //
 4718 6628 CLER //
 4719 6629 CLCA //
 4720 6630 CLER //
 4721 6631 CLSA //
 4722 6632 CLER //
 4723 6633 CLCA //
 4724 6634 CLER //
 4725 6635 CLSA //
 4726 6636 CLER //
 4727 6637 CLCA //
 4728 6638 CLER //
 4729 6639 CLSA //
 4730 6640 CLER //
 4731 6641 CLCA //
 4732 6642 CLER //
 4733 6643 CLSA //
 4734 6644 CLER //
 4735 6645 CLCA //
 4736 6646 CLER //
 4737 6647 CLSA //
 4738 6648 CLER //
 4739 6649 CLCA //
 4740 6650 CLER //
 4741 6651 CLSA //
 4742 6652 CLER //
 4743 6653 CLCA //
 4744 6654 CLER //
 4745 6655 CLSA //
 4746 6656 CLER //
 4747 6657 CLCA //
 4748 6658 CLER //
 4749 6659 CLSA //
 4750 6660 CLER //
 4751 6661 CLCA //
 4752 6662 CLER //
 4753 6663 CLSA //
 4754 6664 CLER //
 4755 6665 CLCA //
 4756 6666 CLER //
 4757 6667 CLSA //
 4758 6668 CLER //
 4759 6669 CLCA //
 4760 6670 CLER //
 4761 6671 CLSA //
 4762 6672 CLER //
 4763 6673 CLCA //
 4764 6674 CLER //
 4765 6675 CLSA //
 4766 6676 CLER //
 4767 6677 CLCA //
 4768 6678 CLER //
 4769 6679 CLSA //
 4770 6680 CLER //
 4771 6681 CLCA //
 4772 6682 CLER //
 4773 6683 CLSA //
 4774 6684 CLER //
 4775 6685 CLCA //
 4776 6686 CLER //
 4777 6687 CLSA //
 4778 6688 CLER //
 4779 6689 CLCA //
 4780 6690 CLER //
 4781 6691 CLSA //
 4782 6692 CLER //
 4783 6693 CLCA //
 4784 6694 CLER //
 4785 6695 CLSA //
 4786 6696 CLER //
 4787 6697 CLCA //
 4788 6698 CLER //
 4789 6699 CLSA //
 4790 6700 CLER //
 4791 6701 CLCA //
 4792 6702 CLER //
 4793 6703 CLSA //
 4794 6704 CLER //
 4795 6705 CLCA //
 4796 6706 CLER //
 4797 6707 CLSA //
 4798 6708 CLER //
 4799 6709 CLCA //
 4800 6710 CLER //
 4801 6711 CLSA //
 4802 6712 CLER //
 4803 6713 CLCA //
 4804 6714 CLER //
 4805 6715 CLSA //
 4806 6716 CLER //
 4807 6717 CLCA //
 4808 6718 CLER //
 4809 6719 CLSA //
 4810 6720 CLER //
 4811 6721 CLCA //
 4812 6722 CLER //
 4813 6723 CLSA //
 4814 6724 CLER //
 4815 6725 CLCA //
 4816 6726 CLER //
 4817 6727 CLSA //
 4818 6728 CLER //
 4819 6729 CLCA //
 4820 6730 CLER //
 4821 6731 CLSA //
 4822 6732 CLER //
 4823 6733 CLCA //
 4824 6734 CLER //
 4825 6735 CLSA //
 4826 6736 CLER //
 4827 6737 CLCA //
 4828 6738 CLER //
 4829 6739 CLSA //
 4830 6740 CLER //
 4831 6741 CLCA //
 4832 6742 CLER //
 4833 6743 CLSA //
 4834 6744 CLER //
 4835 6745 CLCA //
 4836 6746 CLER //
 4837 6747 CLSA //
 4838 6748 CLER //
 4839 6749 CLCA //
 4840 6750 CLER //
 4841 6751 CLSA //
 4842 6752 CLER //
 4843 6753 CLCA //
 4844 6754 CLER //
 4845 6755 CLSA //
 4846 6756 CLER //
 4847 6757 CLCA //
 4848 6758 CLER //
 4849 6759 CLSA //
 4850 6760 CLER //
 4851 6761 CLCA //
 4852 6762 CLER //
 4853 6763 CLSA //
 4854 6764 CLER //
 4855 6765 CLCA //
 4856 6766 CLER //
 4857 6767 CLSA //
 4858 6768 CLER //
 4859 6769 CLCA //
 4860 6770 CLER //
 4861 6771 CLSA //
 4862 6772 CLER //
 4863 6773 CLCA //
 4864 6774 CLER //
 4865 6775 CLSA //
 4866 6776 CLER //
 4867 6777 CLCA //
 4868 6778 CLER //
 4869 6779 CLSA //
 4870 6780 CLER //
 4871 6781 CLCA //
 4872 6782 CLER //
 4873 6783 CLSA //
 4874 6784 CLER //
 4875 6785 CLCA //
 4876 6786 CLER //
 4877 6787 CLSA //
 4878 6788 CLER //
 4879 6789 CLCA //
 4880 6790 CLER //
 4881 6791 CLSA //
 4882 6792 CLER //
 4883 6793 CLCA //
 4884 6794 CLER //
 4885 6795 CLSA //
 4886 6796 CLER //
 4887 6797 CLCA //
 4888 6798 CLER //
 4889 6799 CLSA //
 4890 6800 CLER //
 4891 6801 CLCA //
 4892 6802 CLER //
 4893 6803 CLSA //
 4894 6804 CLER //
 4895 6805 CLCA //
 4896 6806 CLER //
 4897 6807 CLSA //
 4898 6808 CLER //
 4899 6809 CLCA //
 4900 6810 CLER //
 4901 6811 CLSA //
 4902 6812 CLER //
 4903 6813 CLCA //
 4904 6814 CLER //
 4905 6815 CLSA //
 4906 6816 CLER //
 4907 6817 CLCA

/ALERT OPERATOR OF PASS COMPLETION
/SUPPRESS PRINTOUT IF RSW 06 = 1

/INCREMENT PASS
/DONUT SKIP
/READ SWITCHES
LAS
AND
K0040
/PICK OUT RSW 06

4324 0111 AND
4325 7604 NOP
/DONT SKIP
/READ SWITCHES
LAS
AND
K0040
/PICK OUT RSW 06

4326 5176 JMP
4327 1044 JMP
4328 3426 TAD
4329 5431 DCA I
4330 3426 DCA I
4331 5431 JMP I
4332 4741 LOGJ,
4333 5432 TS195H
4334 5432 OUTPAs
4335 5432 /60 TYPE ALARM
4336 5432 /GEAT MONITOR
4337 5432 /GET POINTOUT
4338 5432 /YES, NO PRINTOUT
4339 5432 PNTJ
4340 5432 /ERR0R
4341 5432 OUTPAs
4342 5432 /MESSAGE POINTER
4343 5432 TS195H
4344 5432 LOGJ,
4345 5432 TS195H
4346 5432 /RETURN TO LOC 376 FROM ASCII TYPEOUT (MONITOR WILL HANDLE LINK)

5000 #5000

/NON ERROR MONITOR DETERMINES IF OPERATOR WANTS TO LOOP ON NON-EALING TEST

/NON ERROR, 0 /RETURN ADDRESS

TAD NERR0S /GET RETURN ADDRESS

DCA NERR0S /UPDATE RETURN ADDRESS

TAD 1 NERR0S /GET SCOPE LOOP ADDRESS

DCA NERR0S /STORE SCOPE LOOP ADDRESS

TAD 1 NERR0S /UPDAATE DATA

DCA ERR0RS /STORE IT

JMP 1 ERR0RS /EXIT

S2A CLA K0400 /SAVE SR3

LAS AND /READ SHITCHES

S2A CLA /TEST AND CLEAR

JMP 1 ERR0RS /LOOPING

CMA /GET A6-A3

TAD NERR0S /ADD NERR0RS

DCA NERR0S /STORE IN NERR0S

TAD 1 NERR0S /JUMP INDIRECT LOOP

JMP 1 ERR0RS /READ SHITCHES

TAD 1 BELL /RING THE BELL

JMS 1 ASCII /NO TYPE A MESSAGE

SMA CLA /MOVE SR2 INTO ACC0

RDL /IS IT SET

SMA CLA /STORE IN LAST ERROR

DCIA /INVERT IT

L8TERR /GET CURRENT ERROR ADDRESS

TAD 1 ERR0RS /NO, ERROR HALT

SMA CLA /YES INDEX ESCAPE

L8S /READ SHITCHES

TAD 1 ERR0RS /GET SCOPE MODE

SMA CLA /INDEX ESCAPE TO JUMP OUT

TAD 1 ERR0RS /STORE SELECTED ADDRESS

CMA /SUBTRACT ONE FROM ERRORS

TAD /NO SET A687779 (-1)

SRA CLA /YES CONTINUE IN SCOPE LOOP

TAD NERR0S /IS SCOPE MODE SELECTED

SRA CLA /MOVE SR02 TO ACC

TAD ERR0RS /EXIT TO NEXT TEST

DCA ERR0RS /STORE SELECTED ADDRESS

5050 5620 /SUBTRACT ONE FROM ERRORS

5047 3220 /STORE SELECTED ADDRESS

5046 1220 TAD ERR0RS

5045 7040 CMA ERR0RS

5043 5600 JMP 1 ERR0RS

5042 7006 SRA CLA

5041 7604 LAS

5040 3200 TAD 1 ERR0RS

5039 1620 S2200

5038 1520 TAD 1 ERR0RS

5037 2220 S2220

5036 1520 TAD 1 ERR0RS

5035 2220 S2220

5034 7402 HLT ERR0RS

5033 7700 SMA CLA

5032 7604 LAS

5031 2220 S2220

5030 3627 DCIA L8TERR

5029 7043 TAD ERR0RS

5028 1620 ASRCT, TAD ERR0RS

5027 4421 JMS 1 BELL

5026 1620 JMS 1 ASCII

5025 5234 SMA CLA

5024 7705 RAL

5023 7604 SMA CLA

5022 7604 RAL

5021 7604 L8S

5020 3000 /ERR0R PROCES8OR, SCOPE LOOP, HALT, PRINT

5019 5600 JMP 1 ERR0RS

5018 3200 DCA NERR0S

5017 5600 TAD NERR0S

5016 3200 DCA NERR0S

5015 1220 TAD NERR0S

5014 7620 CMA ERR0RS

5013 5620 S2A CLA

5012 7640 K0400

5011 2122 LAS

5010 7604 JMP 1 ERR0RS

5009 5620 S2A CLA

5008 2046 R8CA

5007 3220 DCA ERR0RS

5006 1600 TAD 1 NERR0S

5005 3220 DCA ERR0RS

5004 3200 DCA NERR0S

5003 1220 TAD NERR0S

5002 1220 TAD NERR0S

5001 7307 CLA CLL 1AC RTL

5000 6000 NERR0S, 0 /RETURN ADDRESS

5051	7240	ASCII, CLA CMA	/SET \$ (AC) \$=1	
5052	1620	TAD I ERRORS	/GET MESSAGE ADDRESS STORAGE	
5053	3010	DCA PRINT	/STORE IT IN AUTO INDEX REGISTER	
5054	1220	TAD ERRORS	/GET RETURN ADDRESS	
5055	1627	TAD LSTERR	/SUBTRACT LAST ERROR ADDRESS	
5056	1650	SNA CLA DATYP	/TEST SAME GO TYPE DATA	
5057	5363	JMP DATUM	/GET FIRST CHARACTER	
5060	1410	TAD I PINT	/TEST IT	
5061	3200	DCA ERRORS	/GET IT	
5062	1200	TAD ERRORS	/SAVE IT	
5063	7450	SNA	/NUMBER=EXIT	
5064	5226	JMP ASCRXT	/NUMBER=REEXIT	
5065	7040	CMA	/INVERT IT	
5066	7430	SNA	/NUMBER=EXITA	
5067	5315	JMP DATUM	/TYPE OUT DATA ROUTINE	
5070	7040	CMA	/CHANGE IT BACK	
5072	7012	RTR	/MOVE	
5073	7012	RTR	/TYPE IT	
5074	4300	JMS	TYPECH	
5075	1200	TAD	ERRORS	
5076	4330	JMS	TYPECH	
5077	0001	AND	K0077	
5078	0000	JMP	ASCIICH	
5079	3036	DCA	SPACE	
5080	0113	AND	K0077	
5081	0000	JMP	TYPECH, 0	
5082	3036	DCA	SPACE	
5083	0113	AND	K0077	
5084	0000	SNA CLA	/TEST FOR GO CRLF CODE	
5085	4354	JMS	CRLF	
5086	1056	TAD	SPACE	
5087	1151	TAD	SPACE	
5088	7510	TAD	K0100	
5089	1151	TAD	K240	
5090	7510	TAD	M0040	
5091	1151	TAD	TYPEC	
5092	7510	TAD	TYPEC	
5093	1056	JMS	TYPEC	
5094	4354	JMS	TYPEC	
5095	1056	JMS	TYPEC	
5096	1056	JMS	TYPEC	
5097	1056	JMS	TYPEC	
5098	1056	JMS	TYPEC	
5099	1056	JMS	TYPEC	
5100	1056	JMS	TYPEC	
5101	1056	JMS	TYPEC	
5102	1056	JMS	TYPEC	
5103	1056	JMS	TYPEC	
5104	7550	SNA CLA	/TEST FOR GO CRLF CODE	
5105	4354	JMS	TYPEC	
5106	1056	JMS	TYPEC	
5107	1056	JMS	TYPEC	
5108	1056	JMS	TYPEC	
5109	1056	JMS	TYPEC	
5110	1056	JMS	TYPEC	
5111	1151	TAD	K0100	
5112	1151	TAD	K240	
5113	1151	TAD	M0040	
5114	5700	JMP I	TYPEC	
5115	4465	JMS I	TYPEC	
5116	1151	TAD	K240	
5117	1151	TAD	M0040	
5118	1151	TAD	K240	
5119	1151	TAD	M0040	
5120	1151	TAD	K240	
5121	1151	TAD	M0040	
5122	1151	TAD	K240	
5123	1151	TAD	M0040	
5124	5700	JMP I	TYPEC	

5115	1410	DATAUH	TAD I	PINT	/GET ADDRESS OF REGISTER
3116	3200	DCA	NEROS	S/STORE IN TEMP	
3117	1200	TAD	NEROS	/GET TEMP	
3120	7650	SNA	CLA	/TEST FOR EXIT	
3121	5226	JMP	ASCRXT	/EQUALS 0000 EXIT	
3122	1200	TAD	NEROS	/GET TEMP	
3123	1262	TAD	NEROS	/TEST	
3124	7650	SNA	CLA	/SPECIAL RESTART	
3125	1600	JMP	176	/GET DATA	
3126	5125	JMS	OCTYP	/TYPE NUMERIC DATA	
3127	4333	TAD	DATAUH	/TYPE M	
3128	1217	JMS	I	TYPE IT	
3129	4465	TAD	DATAUH	/SPACE	
3130	3056	DCA	SPACB	/SET UP TALLY	
3131	1213	TAD	K7774	/STORE DATA TO BE PRINTED	
3132	3300	DCA	TYPECH	/RETURN ADDRESS STORAGE	
3133	1242	TAD	TYPECH	/STORE FLAG NUMBER	
3134	3300	RAL	TYPECH	/STORE	
3135	1243	TAD	TYPECH	/GET FLAG NUMBER	
3136	3056	DCA	SPACB	/SET IT	
3137	1230	TAD	K1026	HERE,	
3138	3300	RED0	TYPE	HERE	
3139	1243	TAD	DATAUH	/EXIT	
3140	3304	RED0	TYPE	/END OF LIST	
3141	1241	TAD	DATAUH	/TYPE IT	
3142	7004	RAL	TYPECH	/GET LF	
3143	1243	TAD	TYPECH	/TYPE IT	
3144	7420	SNL	RED0	/GET GR	
3145	1374	TAD	K0215	/RETURN ADDRESS STORAGE	
3146	4465	JMS I	TYPE	/GET IT	
3147	1375	TAD	K0212	/SET TO RUBOUT	
3148	4465	JMS I	TYPE	/TYPE IT	
3149	1115	TAD	K0217	/SET TO RUBOUT	
3150	4465	JMS I	TYPE	/END OF TYPE LIST	
3151	1410	DATAUH	TAD I	PINT	
3152	2056	JMP	1	DATAUH	
3153	5337	JMP	I	DATAUH	
3154	0000	CRLF	0	DATAUH	
3155	5733	JMP	I	OCTYP	
3156	2056	JMS	I	SPACE	
3157	1375	TAD	K0212	/GET LF	
3158	4465	JMS I	TYPE	/TYPE IT	
3159	1115	TAD	K0217	/SET TO RUBOUT	
3160	4465	JMS I	TYPE	/END OF TYPE LIST	
3161	1115	TAD	K0217	/SET TO RUBOUT	
3162	5754	JMS I	TYPE	/TYPE IT	
3163	1410	DATAUH	TAD I	PINT	
3164	7450	JMP	A5CRXT	/BEGINNING OF DATA	
3165	5226	S2A	CLA	/NO	
3166	7040	CHA	CLA	/YES OK RETURN THE TTY CARRIAGE AND LINE FEED	
3167	7640	JMP	DATAUH	/CLEAR AC AND LINK	
3168	5363	JMS	CRLF	/GO TYPE THE DATA	
3169	5315	JMP	DATAUH	/CARRIAGE AND LINE FEED	
3170	7300	CLA	CLA	/CLS	
3171	5315	JMP	DATAUH	/CLS	
3172	7300	JMS	CRLF	/CLS	
3173	5315	JMP	DATAUH	/CLS	
3174	1212	K0212	0212	/CLS	
3175	1212	K0213	0213	/CLS	

5200 5200 0000 BELLS, 0 /RING THE BELL
 5201 7604 LAS
 5202 0114 AND
 5203 7640 AND
 5204 56000 BELLS
 5205 1101 JMP 1 BELLS
 5206 4465 JMS 1 TYPE
 5207 56000 RANDY, 0
 5210 0000 RANDY,
 5211 1240 TAD RNA
 5212 1241 TAD RNB
 5213 1242 TAD RNG
 5214 1140 TAD K5252
 5215 3240 RAL RNA
 5216 7004 RAL RNB
 5217 1240 TAD RNA
 5218 1241 TAD RNB
 5219 1242 TAD RNG
 5220 0000 RANDY,
 5221 1240 TAD RNA
 5222 1241 TAD RNB
 5223 1242 TAD RNG
 5224 1140 TAD K5252
 5225 1240 RAL RNA
 5226 7004 RAL RNB
 5227 1241 DCA RNA
 5228 1242 TAD RNB
 5229 1241 TAD RNG
 5230 1240 TAD RNG
 5231 1242 TAD K5252
 5232 1241 RAL RNA
 5233 1240 TAD RNB
 5234 1241 TAD RNG
 5235 1242 TAD RNA
 5236 1241 TAD RNB
 5237 1242 TAD RNG
 5238 1140 TAD K5252
 5239 1240 RAL RNA
 5240 7004 RAL RNB
 5241 1240 TAD RNA
 5242 1241 TAD RNB
 5243 1242 TAD RNG
 5244 6046 TAD RNA
 5245 6041 TAD RNB
 5246 6042 TAD RNG
 5247 6043 TAD RNA
 5248 7000 TAD RNB
 5249 7001 TAD RNG
 5250 7300 TAD RNA
 5251 5643 TAD RNG
 5252 0000 SETN,
 5253 7500 CLA CELL
 5254 3032 CLA CELL
 5255 3046 PASS
 5256 3047 REGA
 5257 3027 REGB
 5258 3047 DCA SETER
 5259 3046 DCA SETN
 5260 3046 SETN, 0
 5261 5652 JMP 1 SETN
 5262 5652 JMP 1 SETN

/PDP-122 KMD2A CLDCK TEST, MAINDEC 32-BYTEC-L
PAL15 141 25-JUL-70 129 PAGE 77

/TEXT TEST ERROR MESSAGES

/TEST120 CLAB CHANGED AC

四三

EXIT

ESTATE PLANNING

T090

EX-1

19912 CLAB PAILEB

1990
2229

LIX3

ESTATE PLANNING

141
200

/PDP=12 KM12A CLOCK TEST, MAINDEC 12-06CC-6 PAGE 77-8

5426 2504 2504

EX-10.1
42300

/TST128 CLAB <> CLBA FILED

TST129, 00024 TST129, 00024

/PDP-12 K1M2A CLDCK TEST. MAINDEC 32-BYTE=

/POP-12 KMW2A CLOGC TEST1, MAINDEG 12-08CC-06 PAL10 V341 22-JUL-78 2199 PAGE 77-9

Page 6

፭፻፲፭፻፳፷፷፷

PALEO VESTIGIA

፩፻፲፭፻፯፻

KM2A CLOCK TEST, MAINDEG

LAST27 LOAD GNTL FILES TO WORK

/TST28 "LOAD CNT" LOADED IN ERRO

5676	0024	T5T27M.	0024
5677	2324	2324	6267
5678	6267	4042	4067
5702	1417	2702	5702
5703	0104	0003	3703
5704	0114	2624	3704
5705	1114	2340	3705
5706	0601	0601	3706
5707	0602	4240	3707
5710	1114	2340	3710
5711	2340	2340	3711
5712	2417	2417	3712
5713	0042	4042	3713
5714	1722	4042	3714
5715	4200	4200	3715
5716	7777	4200	3716
5717	0053	0053	3717
5720	0000	RXED0	3720
5721	0000	EX1T	3721
5722	0024	T5T28M.	0024
5723	2324	2324	5723
5724	6270	6270	5724
5725	4042	4042	5725
5726	1417	1417	5726
5727	0104	0104	5727
5728	2417	2417	5728
5729	6270	6270	5729
5730	4003	4003	5730
5731	1624	4240	5731
5732	4240	4240	5732
5733	1417	1417	5733
5734	0104	0104	5734
5735	0104	0104	5735
5736	40211	0104	5736
5737	1640	1640	5737
5740	0522	0522	5740
5741	2217	2217	5741
5742	2200	2200	5742
5743	7777	7777	5743
5744	0054	0054	5744
5745	0355	0355	5745

/TST29 "LOAD CNT" LOADED IN ERROR

PAGE 77-6
2129 270 421 210 DECODE MAIN TEST LOGIC CLK/P

/TST38 MODE REG CAUSES "LOAD CNT".

5747	0024	2324	TS129M,
5751	6271	2324	TS129M,
5752	4042	4042	TS129M,
5753	1417	1417	TS129M,
5754	0104	0104	TS129M,
5755	4003	4003	TS129M,
5756	1624	1624	TS129M,
5757	4240	4240	TS129M,
5758	1417	1417	TS129M,
5759	0104	0104	TS129M,
5760	4240	4240	TS129M,
5761	0104	0104	TS129M,
5762	0504	0504	TS129M,
5763	4011	4011	TS129M,
5764	1646	1646	TS129M,
5765	0522	0522	TS129M,
5766	2217	2217	TS129M,
5767	2260	2260	TS129M,
5770	7777	7777	TS129M,
5771	0054	0054	TS129M,
5772	0053	0053	TS129M,
5773	RXCE	RXCE	TS129M,
5774	SENO	SENO	TS129M,
5775	EXITA	EXITA	TS129M,

/TST32 MODE 21 130 CLOCKED CNTR
 6056 0024 T8T32M, 0024
 6060 6362 2324
 6061 4015 4015
 6062 6362 2324
 6057 2324 2324
 6060 6362 2324
 6061 4015 4015
 6062 6362 2324
 /TST32 MODE 21 130 CLOCKED CNTR

6056	0024	T8T32M, 0024	6067	4003
6046	0514	0514	6045	2240
6044	4042	4042	6043	1722
6042	4240	4240	6041	4042
6040	1624	1624	6041	4240
6037	4003	4003	6040	1624
6036	0104	0104	6035	1417
6034	4042	4042	6035	1417
6033	4042	4042	6034	4042
6023	0523	0523	6023	0523
6022	1722	1722	6022	1722
6021	0642	0642	6021	0642
6020	4000	4000	6020	4000
6019	7777	7777	6019	0054
6018	0054	0054	6018	0053
6017	4000	4000	6017	4000
6016	7660	7660	6016	7660
6015	4061	4061	6015	4061
6014	6362	6362	6014	6362
6013	4015	4015	6013	4015
6012	6362	6362	6012	6362
6011	4061	4061	6011	4061
6010	7660	7660	6010	7660
6009	4000	4000	6009	4000
6008	0054	0054	6008	0053
6007	4000	4000	6007	4000
6006	7660	7660	6006	7660
6005	4061	4061	6005	4061
6004	6362	6362	6004	6362
6003	4015	4015	6003	4015
6002	6362	6362	6002	6362
6001	4061	4061	6001	4061
6000	7660	7660	6000	7660
5999	4000	4000	5999	4000
5998	0054	0054	5998	0053
5997	4000	4000	5997	4000
5996	7660	7660	5996	7660
5995	4061	4061	5995	4061
5994	6362	6362	5994	6362
5993	4015	4015	5993	4015
5992	6362	6362	5992	6362
5991	4061	4061	5991	4061
5990	7660	7660	5990	7660
5989	4000	4000	5989	4000
5988	0054	0054	5988	0053
5987	4000	4000	5987	4000
5986	7660	7660	5986	7660
5985	4061	4061	5985	4061
5984	6362	6362	5984	6362
5983	4015	4015	5983	4015
5982	6362	6362	5982	6362
5981	4061	4061	5981	4061
5980	7660	7660	5980	7660
5979	4000	4000	5979	4000
5978	0054	0054	5978	0053
5977	4000	4000	5977	4000
5976	7660	7660	5976	7660
5975	4061	4061	5975	4061
5974	6362	6362	5974	6362
5973	4015	4015	5973	4015
5972	6362	6362	5972	6362
5971	4061	4061	5971	4061
5970	7660	7660	5970	7660
5969	4000	4000	5969	4000
5968	0054	0054	5968	0053
5967	4000	4000	5967	4000
5966	7660	7660	5966	7660
5965	4061	4061	5965	4061
5964	6362	6362	5964	6362
5963	4015	4015	5963	4015
5962	6362	6362	5962	6362
5961	4061	4061	5961	4061
5960	7660	7660	5960	7660
5959	4000	4000	5959	4000
5958	0054	0054	5958	0053
5957	4000	4000	5957	4000
5956	7660	7660	5956	7660
5955	4061	4061	5955	4061
5954	6362	6362	5954	6362
5953	4015	4015	5953	4015
5952	6362	6362	5952	6362
5951	4061	4061	5951	4061
5950	7660	7660	5950	7660
5949	4000	4000	5949	4000
5948	0054	0054	5948	0053
5947	4000	4000	5947	4000
5946	7660	7660	5946	7660
5945	4061	4061	5945	4061
5944	6362	6362	5944	6362
5943	4015	4015	5943	4015
5942	6362	6362	5942	6362
5941	4061	4061	5941	4061
5940	7660	7660	5940	7660
5939	4000	4000	5939	4000
5938	0054	0054	5938	0053
5937	4000	4000	5937	4000
5936	7660	7660	5936	7660
5935	4061	4061	5935	4061
5934	6362	6362	5934	6362
5933	4015	4015	5933	4015
5932	6362	6362	5932	6362
5931	4061	4061	5931	4061
5930	7660	7660	5930	7660
5929	4000	4000	5929	4000
5928	0054	0054	5928	0053
5927	4000	4000	5927	4000
5926	7660	7660	5926	7660
5925	4061	4061	5925	4061
5924	6362	6362	5924	6362
5923	4015	4015	5923	4015
5922	6362	6362	5922	6362
5921	4061	4061	5921	4061
5920	7660	7660	5920	7660
5919	4000	4000	5919	4000
5918	0054	0054	5918	0053
5917	4000	4000	5917	4000
5916	7660	7660	5916	7660
5915	4061	4061	5915	4061
5914	6362	6362	5914	6362
5913	4015	4015	5913	4015
5912	6362	6362	5912	6362
5911	4061	4061	5911	4061
5910	7660	7660	5910	7660
5909	4000	4000	5909	4000
5908	0054	0054	5908	0053
5907	4000	4000	5907	4000
5906	7660	7660	5906	7660
5905	4061	4061	5905	4061
5904	6362	6362	5904	6362
5903	4015	4015	5903	4015
5902	6362	6362	5902	6362
5901	4061	4061	5901	4061
5900	7660	7660	5900	7660
5899	4000	4000	5899	4000
5898	0054	0054	5898	0053
5897	4000	4000	5897	4000
5896	7660	7660	5896	7660
5895	4061	4061	5895	4061
5894	6362	6362	5894	6362
5893	4015	4015	5893	4015
5892	6362	6362	5892	6362
5891	4061	4061	5891	4061
5890	7660	7660	5890	7660
5889	4000	4000	5889	4000
5888	0054	0054	5888	0053
5887	4000	4000	5887	4000
5886	7660	7660	5886	7660
5885	4061	4061	5885	4061
5884	6362	6362	5884	6362
5883	4015	4015	5883	4015
5882	6362	6362	5882	6362
5881	4061	4061	5881	4061
5880	7660	7660	5880	7660
5879	4000	4000	5879	4000
5878	0054	0054	5878	0053
5877	4000	4000	5877	4000
5876	7660	7660	5876	7660
5875	4061	4061	5875	4061
5874	6362	6362	5874	6362
5873	4015	4015	5873	4015
5872	6362	6362	5872	6362
5871	4061	4061	5871	4061
5870	7660	7660	5870	7660
5869	4000	4000	5869	4000
5868	0054	0054	5868	0053
5867	4000	4000	5867	4000
5866	7660	7660	5866	7660
5865	4061	4061	5865	4061
5864	6362	6362	5864	6362
5863	4015	4015	5863	4015
5862	6362	6362	5862	6362
5861	4061	4061	5861	4061
5860	7660	7660	5860	7660
5859	4000	4000	5859	4000
5858	0054	0054	5858	0053
5857	4000	4000	5857	4000
5856	7660	7660	5856	7660
5855	4061	4061	5855	4061
5854	6362	6362	5854	6362
5853	4015	4015	5853	4015
5852	6362	6362	5852	6362
5851	4061	4061	5851	4061
5850	7660	7660	5850	7660
5849	4000	4000	5849	4000
5848	0054	0054	5848	0053
5847	4000	4000	5847	4000
5846	7660	7660	5846	7660
5845	4061	4061	5845	4061
5844	6362	6362	5844	6362
5843	4015	4015	5843	4015
5842	6362	6362	5842	6362
5841	4061	4061	5841	4061
5840	7660	7660	5840	7660
5839	4000	4000	5839	4000
5838	0054	0054	5838	0053
5837	4000	4000	5837	4000
5836	7660	7660	5836	7660
5835	4061	4061	5835	4061
5834	6362	6362	5834	6362
5833	4015	4015	5833	4015
5832	6362	6362	5832	6362
5831	4061	4061	5831	4061
5830	7660	7660	5830	7660
5829	4000	4000	5829	4000
5828	0054	0054	5828	0053
5827	4000	4000	5827	4000
5826	7660	7660	5826	7660
5825	4061	4061	5825	4061
5824	6362	6362	5824	6362
5823	4015	4015	5823	4015
5822	6362	6362	5822	6362
5821	4061	4061	5821	4061
5820	7660	7660	5820	7660
5819	4000	4000	5819	4000
5818	0054	0054	5818	0053
5817	4000	4000	5817	4000
5816	7660	7660	5816	7660
5815	4061	4061	5815	4061
5814	6362	6362	5814	6362
5813	4015	4015	5813	4015
5812	6362	6362	5812	6362
5811	4061	4061	5811	4061
5810	7660	7660	5810	7660
5809	4000	4000	5809	4000
5808	0054	0054	5808	0053
5807	4000	4000	5807	4000
5806	7660			

/T8T34 OFFLO FILED TO SET OFFLO FILE

/TEST39 CLSA FAILED TO GIVE A DPLD FILE

/TST37 ILLIGAL CLOCK INTERRUPT!

/TST38 CLK FILED TO SKIP

/TST39 GLCK INTERRUPT FILED

6257	0024	TST39M.	0024	0922	6267
6256	0000			1624	6266
6255	4000			4011	6265
6254	1120			0313	6264
6253	2313			1917	6263
6252	1740			4003	6262
6251	4024			6371	6261
6250	0504			2324	6260
6247	1114			0024	6257
6246	0601			0024	6256
6245	1348			0024	6255
6244	1423			0003	6254
6243	4003			0024	6253
6242	6370			2324	6252
6241	2324			2324	6251
6240	0024	TST38M.	0024	0000	6250
6237	0505				6259
6236	4100				6260
6235	2024				6261
6234	2225				6262
6233	0522				6263
6232	1624				6264
6231	4011				6265
6230	0313				6266
6227	1417				6267
6226	4003				6268
6225	0114				6269
6224	0507				6270
6223	1414				6271
6222	4011				6272
6221	6367				6273
6220	2324				6274
6217	0024	TST37M.	0024	0000	6275
6216	0000				6276
6215	4000				6277
6214	1722				6278
6213	2222				6279
6212	4005				6280
6211	1116				6281
6210	0440				6282
6207	2005				6283
6206	1120				6284
6205	2313				6285
6204	1340				6286

ESTATE OF ENNABLE MONT MELLRO

TESTFILE FLAG MONIT CLEAR

/TST42 CL0CK INT'R MONT CLEAR

Digitized by srujanika@gmail.com

6435 2024 15746M. 0024

15945 SIT 69 FILED.

5416 0024 TSP45M. 0024

TEST44 EXIT 30 FAILED.

6377 6024 75144M, 0024

/TEST43 BIT 22 FILED.

360 0024 TSP43M. 0024

VPPD-12 KW52A CLOGK TEST, MANDGE 12-B8C0-L PAL12 V242 23-JUL-78

1951 AD / MAY BY PAULEE.

TEST PAGE EDITION 06 FILED.

17545 817 05 FILED.

וְתִשְׁאַל בְּנֵי יִשְׂרָאֵל.

1995 RELEASE UNDER E.O. 14176

1951-2011

1975 BY THE PALM

195136 B11 B3 PALLEO.

1122-ELOGIC TEC91-HAINDAG 2-28-BECAEL DAGC 3129

6213

86

三

ב' יט

130

330

193

2a C

1975 RATE ADJUST FILES

/TS156 RATE 100KC FILES

19154 B17 DS FILED

/T5T56 RATE 100KC FA
/T5T55 RATE 400KC FA

/19ST68 CHAN S INPUT LOGGED OUT

TESTS RATE TESTS FILES

198156 RATE KG FILE

1959 RATE SHEET PAIRS

/PDF KM2A CLOGK TEST, MAINDEC 12-08C00-L PAL10 1189 21-JUL-78 PAGE 77-36

319

၁၇။

1

1

٩٥

19762 CHAN S MONIT TOGGLE

/198762 CHAN S HON YI TOGGLE

/1ST63 CHAN & WON/T TOGGLE

/PDP-112 MM12A CLOCK TEST, MAINDEC 12-BYTE

671

፳፻፲፭

9

1964 CHAN MONT IN

179769 CHAN & INT'L IN GERMANY

7054	3024	7055	2324	7056	6964	7057	4083	7061	1001	7062	1640	7063	4081	7064	1726	7065	4074	7066	4066	7067	1624	7068	2200	7069	0000
7072	0024	7073	2324	7074	6963	7075	4083	7076	1001	7077	1640	7078	2200	7079	1624	7080	4061	7081	1726	7082	2200	7083	4000	7084	0000
7084	2324	7085	2324	7086	6964	7087	4083	7088	1001	7089	1640	7090	2200	7091	1624	7092	4061	7093	1726	7094	2200	7095	4000	7096	0000
7096	2324	7097	6965	7098	4083	7099	1001	7100	1640	7101	2200	7102	1624	7103	4061	7104	1726	7105	4005	7106	2200	7107	1622	7108	4000
7108	2324	7109	6966	7110	4083	7111	1001	7112	1640	7113	2200	7114	1624	7115	4066	7116	2200	7117	1640	7118	2200	7119	4003	7120	0000
7120	2324	7121	6966	7122	4083	7123	1001	7124	1640	7125	2200	7126	1624	7127	4067	7128	2200	7129	1640	7130	2200	7131	4007	7132	0000
7132	2324	7133	6966	7134	4083	7135	1001	7136	1640	7137	2200	7138	1624	7139	4068	7140	2200	7141	1640	7142	2200	7143	4008	7144	0000
7144	2324	7145	6966	7146	4083	7147	1001	7148	1640	7149	2200	7150	1624	7151	4069	7152	2200	7153	1640	7154	2200	7155	4009	7156	0000
7156	2324	7157	6966	7158	4083	7159	1001	7160	1640	7161	2200	7162	1624	7163	4070	7164	2200	7165	1640	7166	2200	7167	4000	7168	0000
7168	2324	7169	6966	7170	4083	7171	1001	7172	1640	7173	2200	7174	1624	7175	4071	7176	2200	7177	1640	7178	2200	7179	4000	7180	0000
7180	2324	7181	6966	7182	4083	7183	1001	7184	1640	7185	2200	7186	1624	7187	4072	7188	2200	7189	1640	7190	2200	7191	4000	7192	0000
7192	2324	7193	6966	7194	4083	7195	1001	7196	1640	7197	2200	7198	1624	7199	4073	7200	2200	7201	1640	7202	2200	7203	4000	7204	0000
7204	2324	7205	6966	7206	4083	7207	1001	7208	1640	7209	2200	7210	1624	7211	4074	7212	2200	7213	1640	7214	2200	7215	4000	7216	0000
7216	2324	7217	6966	7218	4083	7219	1001	7220	1640	7221	2200	7222	1624	7223	4075	7224	2200	7225	1640	7226	2200	7227	4000	7228	0000
7228	2324	7229	6966	7230	4083	7231	1001	7232	1640	7233	2200	7234	1624	7235	4076	7236	2200	7237	1640	7238	2200	7239	4000	7240	0000
7240	2324	7241	6966	7242	4083	7243	1001	7244	1640	7245	2200	7246	1624	7247	4077	7248	2200	7249	1640	7250	2200	7251	4000	7252	0000
7252	2324	7253	6966	7254	4083	7255	1001	7256	1640	7257	2200	7258	1624	7259	4078	7260	2200	7261	1640	7262	2200	7263	4000	7264	0000
7264	2324	7265	6966	7266	4083	7267	1001	7268	1640	7269	2200	7270	1624	7271	4079	7272	2200	7273	1640	7274	2200	7275	4000	7276	0000
7276	2324	7277	6966	7278	4083	7279	1001	7280	1640	7281	2200	7282	1624	7283	4080	7284	2200	7285	1640	7286	2200	7287	4000	7288	0000
7288	2324	7289	6966	7290	4083	7291	1001	7292	1640	7293	2200	7294	1624	7295	4081	7296	2200	7297	1640	7298	2200	7299	4000	7300	0000
7300	2324	7301	6966	7302	4083	7303	1001	7304	1640	7305	2200	7306	1624	7307	4082	7308	2200	7309	1640	7310	2200	7311	4000	7312	0000
7312	2324	7313	6966	7314	4083	7315	1001	7316	1640	7317	2200	7318	1624	7319	4083	7320	2200	7321	1640	7322	2200	7323	4000	7324	0000
7324	2324	7325	6966	7326	4083	7327	1001	7328	1640	7329	2200	7330	1624	7331	4084	7332	2200	7333	1640	7334	2200	7335	4000	7336	0000
7336	2324	7337	6966	7338	4083	7339	1001	7340	1640	7341	2200	7342	1624	7343	4085	7344	2200	7345	1640	7346	2200	7347	4000	7348	0000
7348	2324	7349	6966	7350	4083	7351	1001	7352	1640	7353	2200	7354	1624	7355	4086	7356	2200	7357	1640	7358	2200	7359	4000	7360	0000
7360	2324	7361	6966	7362	4083	7363	1001	7364	1640	7365	2200	7366	1624	7367	4087	7368	2200	7369	1640	7370	2200	7371	4000	7372	0000
7372	2324	7373	6966	7374	4083	7375	1001	7376	1640	7377	2200	7378	1624	7379	4088	7380	2200	7381	1640	7382	2200	7383	4000	7384	0000
7384	2324	7385	6966	7386	4083	7387	1001	7388	1640	7389	2200	7390	1624	7391	4089	7392	2200	7393	1640	7394	2200	7395	4000	7396	0000
7396	2324	7397	6966	7398	4083	7399	1001	7400	1640	7401	2200	7402	1624	7403	4090	7404	2200	7405	1640	7406	2200	7407	4000	7408	0000
7408	2324	7409	6966	7410	4083	7411	1001	7412	1640	7413	2200	7414	1624	7415	4091	7416	2200	7417	1640	7418	2200	7419	4000	7420	0000
7420	2324	7421	6966	7422	4083	7423	1001	7424	1640	7425	2200	7426	1624	7427	4092	7428	2200	7429	1640	7430	2200	7431	4000	7432	0000
7432	2324	7433	6966	7434	4083	7435	1001	7436	1640	7437	2200	7438	1624	7439	4093	7440	2200	7441	1640	7442	2200	7443	4000	7444	0000
7444	2324	7445	6966	7446	4083	7447	1001	7448	1640	7449	2200	7450	1624	7451	4094	7452	2200	7453	1640	7454	2200	7455	4000	7456	0000
7456	2324	7457	6966	7458	4083	7459	1001	7460	1640	7461	2200	7462	1624	7463	4095	7464	2200	7465	1640	7466	2200	7467	4000	7468	0000
7468	2324	7469	6966	7470	4083	7471	1001	7472	1640	7473	2200	7474	1624	7475	4096	7476	2200	7477	1640	7478	2200	7479	4000	7480	0000
7480	2324	7481	6966	7482	4083	7483	1001	7484	1640	7485	2200	7486	1624	7487	4097	7488	2200	7489	1640	7490	2200	7491	4000	7492	0000
7492	2324	7493	6966	7494	4083	7495	1001	7496	1640	7497	2200	7498	1624	7499	4098	7500	2200	7501	1640	7502	2200	7503	4000	7504	0000
7504	2324	7505	6966	7506	4083	7507	1001	7508	1640	7509	2200	7510	1624	7511	4099	7512	2200	7513	1640	7514	2200	7515	4000	7516	0000
7516	2324	7517	6966	7518	4083	7519	1001	7520	1640	7521	2200	7522	1624	7523	4100	7524	2200	7525	1640	7526	2200	7527	4000	7528	0000
7528	2324	7529	6966	7530	4083	7531	1001	7532	1640	7533	2200	7534	1624	7535	4101	7536	2200	7537	1640	7538	2200	7539	4000	7540	0000
7540	2324	7541	6966	7542	4083	7543	1001	7544	1640	7545	2200	7546	1624	7547	4102	7548	2200	7549	1640	7550	2200	7551	4000	7552	0000
7552	2324	7553	6966	7554	4083	7555	1001	7556	1640	7557	2200	7558	1624	7559	4103	7560	2200	7561	1640	7562	2200	7563	4000	7564	0000
7564	2324	7565	6966	7566	4083	7567	1001	7568	1640	7569	2200	7570	1624	7571	4104	7572	2200	7573	1640	7574	2200	7575	4000	7576	0000
7576	2324	7577	6966	7578	4083	7579	1001	7580	1640	7581	2200	7582	1624	7583	4105	7584	2200	7585	1640	7586	2200	7587	4000	7588	0000
7588	2324	7589	6966	7590	4083	7591	1001	7592	1640	7593	2200	7594	1624	7595	4106	7596	2200	7597	1640	7598	2200	7599	4000	7600	0000
7600	2324	7601	6966	7602	4083	7603	1001	7604	1640	7605	2200	7606	1624	7607	4107	7608	2200	7609	1640	7610	2200	7611	4000	7612	0000
7612	2324	7613	6966	7614	4083	7615	1001	7616	1640	7617	2200	7618	1624	7619	4108	7620	2200	7621	1640	7622	2200	7623	4000	7624	0000
7624	2324	7625	6966	7626	4083	7627	1001	7628	1640	7629	2200	7630	1624	7631	4109	7632	2200	7633	1640	7634	2200	7635	4000	7636	0000
7636	2324	7637	6966	7638	4083	7639	1001	7640	1640	7641	2200	7642	1624	7643	4110	7644	2200	7645	1640	7646	2200	7647	4000	7648	0000
7648	2324	7649	6966	7650	4083	7651	1001	7652	1640	7653	2200	7654	1624	7655	4111	7656	2200	7657	1640	7658	2200	7659	4000	7660	0000
7660	2324																								

TS765M,	0024
TS766M,	0024
EX1T	
40000	
1722	
2222	
40005	
1116	
22240	
1624	
40111	
4011	
1640	
10081	
40093	
6665	
2324	
4024	
EX1T	
22200	
1624	
4011	
4724	
1726	
4027	
4062	
1640	
10081	
40093	
6664	
2324	
4024	

/TGT67 CHAN 2 INTL IN ERROR

1976B CHAN S MON/T INT'L.

/T9T69 CHAN 3 INT'L IN ERROR

/PDP-12 K152A CLOCK TEST, MAINDEC 12-BYTEC PAGE 77-129

EX-13 6666 7211

TS170M, 0024 /TS170 CHAN 3 INPUT LINE PREQ FILED

19872M, 0024 /19871 CHAN & INPUT LINE FREQ FAILED

/1S772 CHAN 3 INPUT LINE FREQ FILED

© 1998 www.brentgordon.com

/P00-012 XW12A CLOG TEST. MAINDEC 12-D00C-L PAGE 77-24

/19176 MODES 2.1 INMBIT FAST SAM

/T5T80 I/O PRESET MONIT STOP CLOCK
/T5T80 I/O PRESET MONIT STOP CLOCK

/T5T81 I/O PRESET MONIT CLEAR OFIFO

7457	0024	T5T79M, 0024	7456	0000	7532
7446	0124	0124	7455	5100	7531
7447	0540	0540	7454	4062	7530
7448	0211	0211	7453	4046	7529
7449	2423	2423	7452	4061	7528
7450	0211	0211	7451	4062	7527
7451	0223	0223	7450	2240	7526
7452	0211	0211	7449	2248	7525
7453	4061	4061	7448	0301	7524
7454	4046	4046	7447	0314	7523
7455	4062	4062	7446	0314	7522
7456	0000	0000	7445	1747	7521
7457	0000	0000	7444	2440	7520
7458	0000	0000	7443	2440	7519
7459	0000	0000	7442	2440	7518
7460	0000	0000	7441	2440	7517
7461	0000	0000	7440	2440	7516
7462	4021	4021	7439	2440	7515
7463	3427	3427	7438	2440	7514
7464	4020	4020	7437	2440	7513
7465	2205	2205	7436	2440	7512
7466	2305	2305	7435	2440	7511
7467	2440	2440	7434	2440	7510
7468	2727	2727	7433	2440	7509
7469	2324	2324	7432	2440	7508
7470	2727	2727	7431	2440	7507
7471	1647	1647	7430	2440	7506
7472	2440	2440	7429	2440	7505
7473	2324	2324	7428	2440	7504
7474	1720	1720	7427	2440	7503
7475	4003	4003	7426	2440	7502
7476	1417	1417	7425	2440	7501
7477	0313	0313	7424	2440	7500
7478	4000	4000	7423	2440	7509
7479	0313	0313	7422	2440	7508
7480	4000	4000	7421	2440	7507
7481	6034	6034	7420	2440	7506
7482	4000	4000	7419	2440	7505
7483	0313	0313	7418	2440	7504
7484	0313	0313	7417	2440	7503
7485	4003	4003	7416	2440	7502
7486	1417	1417	7415	2440	7501
7487	0313	0313	7414	2440	7500
7488	4000	4000	7413	2440	7509
7489	0313	0313	7412	2440	7508
7490	4000	4000	7411	2440	7507
7491	0313	0313	7410	2440	7506
7492	4000	4000	7409	2440	7505
7493	0313	0313	7408	2440	7504
7494	4000	4000	7407	2440	7503
7495	0313	0313	7406	2440	7502
7496	4000	4000	7405	2440	7501
7497	0313	0313	7404	2440	7500
7498	4000	4000	7403	2440	7509
7499	0313	0313	7402	2440	7508
7500	4000	4000	7401	2440	7507
7501	0313	0313	7400	2440	7506
7502	4000	4000	7409	2440	7505
7503	0313	0313	7408	2440	7504
7504	4000	4000	7407	2440	7503
7505	0313	0313	7406	2440	7502
7506	4000	4000	7405	2440	7501
7507	0313	0313	7404	2440	7500
7508	4000	4000	7403	2440	7509
7509	0313	0313	7402	2440	7508
7510	4000	4000	7401	2440	7507
7511	0324	0324	7510	2440	7506
7512	2324	2324	7509	2440	7505
7513	7061	7061	7508	2440	7504
7514	4021	4021	7507	2440	7503
7515	3411	3411	7506	2440	7502
7516	4020	4020	7505	2440	7501
7517	3417	3417	7504	2440	7500
7518	4020	4020	7503	2440	7509
7519	0324	0324	7502	2440	7508
7520	4000	4000	7501	2440	7507
7521	0324	0324	7500	2440	7506
7522	2717	2717	7509	2440	7505
7523	1647	1647	7508	2440	7504
7524	2440	2440	7507	2440	7503
7525	2323	2323	7506	2440	7502
7526	2205	2205	7505	2440	7501
7527	2240	2240	7504	2440	7500
7528	2240	2240	7503	2440	7509
7529	2240	2240	7502	2440	7508
7530	2305	2305	7501	2440	7507
7531	3414	3414	7500	2440	7506
7532	2440	2440	7509	2440	7505
7533	2323	2323	7508	2440	7504
7534	2205	2205	7507	2440	7503
7535	2240	2240	7506	2440	7502
7536	2240	2240	7505	2440	7501
7537	2240	2240	7504	2440	7500
7538	2240	2240	7503	2440	7509
7539	2240	2240	7502	2440	7508
7540	2240	2240	7501	2440	7507
7541	2240	2240	7500	2440	7506
7542	2240	2240	7509	2440	7505
7543	2240	2240	7508	2440	7504
7544	2240	2240	7507	2440	7503
7545	2240	2240	7506	2440	7502
7546	2240	2240	7505	2440	7501
7547	2240	2240	7504	2440	7500
7548	2240	2240	7503	2440	7509
7549	2240	2240	7502	2440	7508
7550	2240	2240	7501	2440	7507
7551	2240	2240	7500	2440	7506
7552	2240	2240	7509	2440	7505
7553	2240	2240	7508	2440	7504
7554	2240	2240	7507	2440	7503
7555	2240	2240	7506	2440	7502
7556	2240	2240	7505	2440	7501
7557	2240	2240	7504	2440	7500
7558	2240	2240	7503	2440	7509
7559	2240	2240	7502	2440	7508
7560	2240	2240	7501	2440	7507
7561	2240	2240	7500	2440	7506
7562	2240	2240	7509	2440	7505
7563	2240	2240	7508	2440	7504
7564	2240	2240	7507	2440	7503
7565	2240	2240	7506	2440	7502
7566	2240	2240	7505	2440	7501
7567	2240	2240	7504	2440	7500
7568	2240	2240	7503	2440	7509
7569	2240	2240	7502	2440	7508
7570	2240	2240	7501	2440	7507
7571	2240	2240	7500	2440	7506
7572	2240	2240	7509	2440	7505
7573	2240	2240	7508	2440	7504
7574	2240	2240	7507	2440	7503
7575	2240	2240	7506	2440	7502
7576	2240	2240	7505	2440	7501
7577	2240	2240	7504	2440	7500
7578	2240	2240	7503	2440	7509
7579	2240	2240	7502	2440	7508
7580	2240	2240	7501	2440	7507
7581	2240	2240	7500	2440	7506
7582	2240	2240	7509	2440	7505
7583	2240	2240	7508	2440	7504
7584	2240	2240	7507	2440	7503
7585	2240	2240	7506	2440	7502
7586	2240	2240	7505	2440	7501
7587	2240	2240	7504	2440	7500
7588	2240	2240	7503	2440	7509
7589	2240	2240	7502	2440	7508
7590	2240	2240	7501	2440	7507
7591	2240	2240	7500	2440	7506
7592	2240	2240	7509	2440	7505
7593	2240	2240	7508	2440	7504
7594	2240	2240	7507	2440	7503
7595	2240	2240	7506	2440	7502
7596	2240	2240	7505	2440	7501
7597	2240	2240	7504	2440	7500
7598	2240	2240	7503	2440	7509
7599	2240	2240	7502	2440	7508
7600	2240	2240	7501	2440	7507
7601	2240	2240	7500	2440	7506
7602	2240	2240	7509	2440	7505
7603	2240	2240	7508	2440	7504
7604	2240	2240	7507	2440	7503
7605	2240	2240	7506	2440	7502
7606	2240	2240	7505	2440	7501
7607	2240	2240	7504	2440	7500
7608	2240	2240	7503	2440	7509
7609	2240	2240	7502	2440	7508
7610	2240	2240	7501	2440	7507
7611	2240	2240	7500	2440	7506
7612	2240	2240	7509	2440	7505
7613	2240	2240	7508	2440	7504
7614	2240	2240	7507	2440	7503
7615	2240	2240	7506	2440	7502
7616	2240	2240	7505	2440	7501
7617	2240	2240	7504	2440	7500
7618	2240	2240	7503	2440	7509
7619	2240	2240	7502	2440	7508
7620	2240	2240	7501	2440	7507
7621	2240	2240	7500	2440	7506
7622	2240	2240	7509	2440	7505
7623	2240	2240	7508	2440	7504
7624	2240	2240	7507	2440	7503
7625	2240	2240	7506	2440	7502
7626	2240	2240	7505	2440	7501
7627	2240	2240	7504	2440	7500
7628	2240	2240	7503	2440	7509
7629	2240	2240	7502	2440	7508
7630	2240	2240	7501	2440	7507
7631	2240	2240	7500	2440	7506
7632	2240	2240	7509	2440	7505
7633	2240	2240	7508	2440	7504
7634	2240	2240	7507	2440	7503
7635	2240	2240	7506	2440	7502
7636	2240	2240	7505	2440	7501
7637	2240	2240	7504	2440	7500
7638	2240	2240	7503	2440	7509

/T8189 I/O PRESENT MONIT CLEAR MODE 0

/T8186 FAST SAM NOT CLEARED

4446	7777	EX1TA
4445	04000	04000
4444	2205	2205
4443	H501	0501
4442	D314	0314
4441	2440	0314
4440	2440	0314
4437	1540	1540
4436	2440	2440
4435	2440	2440
4434	0123	0123
4433	4006	4006
4432	7066	7066
4431	2324	2324
4430	0024	0024
4429	T8186M, 0024	T8186M, 0024
4428	0000	EX1T
4427	7777	EX1TA
4426	40000	40000
4425	4060	4060
4424	0405	0405
4423	1517	1517
4422	2240	2240
4421	0501	0501
4420	0501	0501
4419	0314	0314
4418	2440	2440
4417	1647	1647
4416	2440	2440
4415	1647	2717
4414	2440	2440
4413	2305	2305
4412	2205	2205
4411	4020	4020
4410	4020	4020
4409	3417	3417
4408	4011	4011
4407	4011	4011
4406	7065	7065
4405	2324	2324
4404	0024	0024
4403	T8185H, 0024	T8185H, 0024
4402	0000	EX1T
4401	40000	40000
4400	4062	4062
4400	0405	0405
4377	1517	1517
4376	2240	2240
4375	0501	0501
4374	0301	0301
4373	0314	0314
4372	2440	2440
4371	1647	2717
4370	2717	1647
4367	2440	2440
4366	2305	2305
4365	2205	2205
4364	4020	4020
4363	3417	3417
4362	4011	4011

/T5T87 CHAN 1 MON1 TRANS GNT TO BUf

T5T87M, 0024 0024

/T5T88 CHAN 2 MON1 TRANS GNT TO BUf

T5T88M, 0024 0024

/T5T89 CHAN 3 MON1 TRANS GNT TO BUf

T5T89M, 0024 0024

/TEST90 CHAN 2 MONIT TRANS CNT TO BUF

/TS192 CHAN 2 MONIT TRANS GNT TO BUF

/T9T92 CHAN 3 MONIT TRANS GNT TO BUF

/T9T93 CHAN 3 INPUT FILED TO CLR CNT

4620	4002	4002	4622	2506	2506	4622	4000	4000	4623	0000	4624	0120	K0300	4625	0000	4626	0001	4627	2324	2324	4628	0002	0002	4629	0003	0003	4630	7162	7162	4631	4003	4003	4632	1640	1640	4633	6340	6340	4634	2727	2727	4635	1647	1647	4636	2440	2440	4637	2422	2422	4638	0116	0116	4639	2340	2340	4640	0316	0316	4641	2440	2440	4642	4002	4002	4643	2306	2306	4644	4000	4000	4645	7177	7177	4646	0120	K0300	4647	0000	4648	0001	4649	2324	2324	4650	4003	4003	4651	1640	1640	4652	6340	6340	4653	1116	1116	4654	2025	2025	4655	2440	2440	4656	0601	0601	4657	1114	1114	4658	0504	0504	4659	1740	1740	4660	4024	4024	4661	1740	1740	4662	4024	4024	4663	0314	0314	4664	2240	2240	4665	8316	8316	4666	2400	2400	4667	7777	7777	4668	0053	RXED	4669	0000	EXIT	4700	T5T94M, 0024	2324	4701	TS793M, 0024	2324	4702	TS793M, 0024	2324
------	------	------	------	------	------	------	------	------	------	------	------	------	-------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	-------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	--------------	------	------	--------------	------	------	--------------	------

4704 7364
4705 4005
4706 0317
4707 4005
0317
4708 4005
4709 4005
4710 1561
4711 6255
4712 6060
4713 6063
4714 6440
4715 1223
4716 4005
1224
4717 1225
4718 1226
4719 2240
1617
2440
2724
4720 1722
4721 2722
4722 1722
4723 2440
1617
2240
4724 2724
4725 2243
1226
4726 0740
0727
4727 1722
4728 4016
1724
4729 1722
4730 4016
1724
4731 1623
1624
4732 2401
1623
4733 1623
1624
4734 1623
1625
4735 2401
1623
4736 1414
0504
4737 1504
0504
4738 2401
1623
4739 1623
1624
4740 0000
4741 0000
4742 0000
4743 2001
6240
4744 2001
2001
2323
5555
5555
7777
0032
4444
4750 0032
4751 4444
/KML2 PASS==PASS)
TS195M, 0013
/KML2 PASS==PASS)
/EXIT & CAUSES A RETURN TO 0177
S
EX1TB
EX1TA
PAS5
EX1TA
5555
2323
2001
6240
2761
2761
0013
0013
4741
4742
4743
4744
4745
4746
4747
4748
4749
4750
4751

7700
7698

7500
7400
7300
7200
7100
7000

6900
6800
6700
6600
6500
6400
6300
6200
6100
6000

5700
5600
5500
5400
5300
5200
5100
5000

4700
4600
4500
4400
4300
4200
4100
4000

/PDP-12 LA CLOCK TEST, MAINDEC 12=09CC=6

22500L=70

PAL10

V241

1/29

PAGE 79-39

/PDP=12 KMH2A CLOCK TEGT; MAINDEC 12=08000=L PAL10 V141 260DUL=70 1129 PAGE 79=31

MAINDEC 32-DBCC-L PAL10 V442 22-JUL-70 1139 PAGE 77 = 32

PALIO V.41 22=JUL=70

7a

1

170

it

6

25

TST48M	6473	TST49M	2897	TST50M	2120	TST50M	6531	TST51M	2161	TST51M	6532	TST52M	2222	TST52M	65367	TST53M	2263	TST53M	6606	TST54M	2364	TST54M	6644	TST55M	2365	TST55M	6625	TST56M	2412	TST56M	6661	TST57M	2437	TST57M	6676	TST58M	2471	TST58M	6713	TST58M	2508	TST59M	6727	TST59M	6743	TST60M	2565	TST60M	6761	TST61M	2604	TST61M	6766	TST62M	2635	TST62M	7010	TST63M	2666	TST63M	7032	TST64M	2721	TST64M	7112	TST65M	2741	TST65M	7274	TST66M	2764	TST66M	7312	TST66N	0060	TST66N	73167
TST49M	6474	TST50M	2900	TST51M	2162	TST51M	6533	TST52M	2163	TST52M	6534	TST53M	2223	TST53M	6535	TST54M	2363	TST54M	6605	TST55M	2364	TST55M	6626	TST56M	2413	TST56M	6662	TST57M	2438	TST57M	6677	TST58M	2472	TST58M	6714	TST58M	2509	TST59M	6728	TST59M	6744	TST60M	2566	TST60M	6762	TST61M	2605	TST61M	6767	TST62M	2636	TST62M	7011	TST63M	2667	TST63M	7033	TST64M	2722	TST64M	7113	TST65M	2742	TST65M	7275	TST66M	2765	TST66M	7313	TST66N	0061	TST66N	73168				
TST50M	6530	TST51M	2163	TST51M	6534	TST52M	2164	TST52M	6535	TST53M	2224	TST53M	6536	TST54M	2364	TST54M	6606	TST55M	2365	TST55M	6626	TST56M	2414	TST56M	6663	TST57M	2439	TST57M	6678	TST58M	2473	TST58M	6715	TST58M	2510	TST59M	6729	TST59M	6745	TST60M	2567	TST60M	6763	TST61M	2606	TST61M	6768	TST62M	2637	TST62M	7012	TST63M	2668	TST63M	7034	TST64M	2723	TST64M	7114	TST65M	2743	TST65M	7276	TST66M	2766	TST66M	7314	TST66N	0062	TST66N	73169						
TST51M	6531	TST52M	2164	TST52M	6535	TST53M	2225	TST53M	6536	TST54M	2365	TST54M	6607	TST55M	2366	TST55M	6627	TST56M	2415	TST56M	6664	TST57M	2439	TST57M	6679	TST58M	2474	TST58M	6716	TST58M	2511	TST59M	6729	TST59M	6746	TST60M	2568	TST60M	6764	TST61M	2607	TST61M	6769	TST62M	2638	TST62M	7013	TST63M	2669	TST63M	7035	TST64M	2724	TST64M	7115	TST65M	2744	TST65M	7277	TST66M	2767	TST66M	7315	TST66N	0063	TST66N	73170										
TST52M	6532	TST53M	2165	TST53M	6536	TST54M	2226	TST54M	6537	TST55M	2366	TST55M	6608	TST56M	2416	TST56M	6665	TST57M	2440	TST57M	6680	TST58M	2475	TST58M	6717	TST58M	2512	TST59M	6730	TST59M	6747	TST60M	2570	TST60M	6765	TST61M	2608	TST61M	6770	TST62M	2641	TST62M	7014	TST63M	2671	TST63M	7036	TST64M	2731	TST64M	7116	TST65M	2751	TST65M	7278	TST66M	2771	TST66M	7316	TST66N	0064	TST66N	73171														
TST53M	6533	TST54M	2166	TST54M	6537	TST55M	2227	TST55M	6538	TST56M	2367	TST56M	6609	TST57M	2417	TST57M	6666	TST58M	2441	TST58M	6681	TST58M	2476	TST58M	6718	TST58M	2513	TST59M	6731	TST59M	6748	TST60M	2571	TST60M	6766	TST61M	2609	TST61M	6771	TST62M	2642	TST62M	7015	TST63M	2672	TST63M	7037	TST64M	2732	TST64M	7117	TST65M	2752	TST65M	7279	TST66M	2772	TST66M	7317	TST66N	0065	TST66N	73172														
TST54M	6534	TST55M	2167	TST55M	6538	TST56M	2228	TST56M	6539	TST57M	2368	TST57M	6610	TST58M	2418	TST58M	6667	TST58M	2442	TST58M	6682	TST58M	2477	TST58M	6719	TST58M	2514	TST59M	6732	TST59M	6750	TST60M	2572	TST60M	6767	TST61M	2610	TST61M	6772	TST62M	2643	TST62M	7016	TST63M	2673	TST63M	7038	TST64M	2733	TST64M	7118	TST65M	2753	TST65M	7280	TST66M	2773	TST66M	7318	TST66N	0066	TST66N	73173														
TST55M	6535	TST56M	2168	TST56M	6539	TST57M	2229	TST57M	6540	TST58M	2369	TST58M	6611	TST58M	2419	TST58M	6668	TST58M	2443	TST58M	6683	TST58M	2478	TST58M	6720	TST58M	2515	TST59M	6733	TST59M	6751	TST60M	2573	TST60M	6768	TST61M	2611	TST61M	6773	TST62M	2644	TST62M	7017	TST63M	2674	TST63M	7039	TST64M	2734	TST64M	7119	TST65M	2754	TST65M	7281	TST66M	2774	TST66M	7319	TST66N	0067	TST66N	73174														
TST56M	6536	TST57M	2169	TST57M	6540	TST58M	2230	TST58M	6541	TST59M	2370	TST59M	6612	TST59M	2420	TST59M	6669	TST59M	2444	TST59M	6684	TST59M	2479	TST59M	6721	TST59M	2516	TST59M	6734	TST60M	2574	TST60M	6769	TST61M	2612	TST61M	6774	TST62M	2645	TST62M	7018	TST63M	2675	TST63M	7040	TST64M	2735	TST64M	7120	TST65M	2755	TST65M	7282	TST66M	2775	TST66M	7320	TST66N	0068	TST66N	73175																
TST57M	6537	TST58M	2170	TST58M	6541	TST59M	2231	TST59M	6542	TST59M	2371	TST59M	6613	TST59M	2421	TST59M	6670	TST59M	2445	TST59M	6685	TST59M	2480	TST59M	6722	TST59M	2517	TST59M	6735	TST60M	2575	TST60M	6770	TST61M	2613	TST61M	6775	TST62M	2646	TST62M	7019	TST63M	2676	TST63M	7041	TST64M	2736	TST64M	7121	TST65M	2756	TST65M	7283	TST66M	2776	TST66M	7321	TST66N	0069	TST66N	73176																
TST58M	6538	TST59M	2171	TST59M	6542	TST59M	2372	TST59M	6614	TST59M	2422	TST59M	6671	TST59M	2451	TST59M	6686	TST59M	2481	TST59M	6723	TST59M	2518	TST59M	6736	TST60M	2576	TST60M	6771	TST61M	2614	TST61M	6776	TST62M	2647	TST62M	7020	TST63M	2677	TST63M	7042	TST64M	2737	TST64M	7122	TST65M	2757	TST65M	7284	TST66M	2777	TST66M	7322	TST66N	0070	TST66N	73177																				
TST59M	6539	TST60M	2172	TST60M	6543	TST60M	2373	TST60M	6615	TST60M	2423	TST60M	6672	TST60M	2452	TST60M	6687	TST60M	2482	TST60M	6724	TST60M	2519	TST60M	6737	TST60M	2577	TST60M	6772	TST61M	2615	TST61M	6777	TST62M	2648	TST62M	7021	TST63M	2678	TST63M	7043	TST64M	2738	TST64M	7123	TST65M	2758	TST65M	7285	TST66M	2778	TST66M	7323	TST66N	0071	TST66N	73178																				
TST60M	6540	TST61M	2173	TST61M	6544	TST61M	2374	TST61M	6616	TST61M	2424	TST61M	6673	TST61M	2453	TST61M	6688	TST61M	2483	TST61M	6725	TST61M	2520	TST61M	6738	TST61M	2578	TST61M	6773	TST62M	2616	TST62M	6778	TST62M	2649	TST62M	7022	TST63M	2679	TST63M	7044	TST64M	2739	TST64M	7124	TST65M	2759	TST65M	7286	TST66M	2779	TST66M	7324	TST66N	0072	TST66N	73179																				
TST61M	6541	TST62M	2174	TST62M	6545	TST62M	2375	TST62M	6617	TST62M	2425	TST62M	6674	TST62M	2454	TST62M	6689	TST62M	2484	TST62M	6726	TST62M	2521	TST62M	6739	TST62M	2579	TST62M	6774	TST63M	2617	TST63M	6779	TST63M	2650	TST63M	7023	TST64M	2680	TST64M	7045	TST65M	2760	TST65M	7287	TST66M	2780	TST66M	7325	TST66N	0073	TST66N	73180																								
TST62M	6542	TST63M	2175	TST63M	6546	TST63M	2376	TST63M	6618	TST63M	2426	TST63M	6675	TST63M	2455	TST63M	6690	TST63M	2485	TST63M	6727	TST63M	2522	TST63M	6740	TST63M	2580	TST63M	6775	TST64M	2618	TST64M	6780	TST64M	2651	TST64M	7024	TST65M	2681	TST65M	7046	TST65M	2761	TST65M	7288	TST66M	2781	TST66M	7326	TST66N	0074	TST66N	73181																								
TST63M	6543	TST64M	2176	TST64M	6547	TST64M	2377	TST64M	6619	TST64M	2427	TST64M	6676	TST64M	2456	TST64M	6691	TST64M	2486	TST64M	6728	TST64M	2523	TST64M	6741	TST64M	2581	TST64M	6776	TST65M	2619	TST65M	6781	TST65M	2652	TST65M	7025	TST66M	2682	TST66M	7047	TST66M	2762	TST66M	7289	TST66N	0075	TST66N	73182																												
TST64M	6544	TST65M	2177	TST65M	6548	TST65M	2378	TST65M	6620	TST65M	2428	TST65M	6677	TST65M	2457	TST65M	6692	TST65M	2487	TST65M	6729	TST65M	2524	TST65M	6742	TST65M	2582	TST65M	6777	TST66M	2620	TST66M	6782	TST66M	2763	TST66M	7290	TST66N	0076	TST66N	73183																																				
TST65M	6545	TST66M	2178	TST66M	6549	TST66M	2379	TST66M	6621	TST66M	2429	TST66M	6678	TST66M	2458	TST66M	6693	TST66M	2488	TST66M	6730	TST66M	2525	TST66M	6743	TST66M	2583	TST66M	6778	TST67M	2621	TST67M	6783	TST67M	2764	TST67M	7291	TST67M	0077	TST67M	73184																																				
TST66M	6546	TST67M	2179	TST67M	6550	TST67M	2380	TST67M	6622	TST67M	2430	TST67M	6679	TST67M	2459	TST67M	6694	TST67M	2489	TST67M	6731	TST67M	2526	TST67M	6744	TST67M	2584	TST67M	6779	TST68M	2622	TST68M	6784	TST68M	2765	TST68M	7292	TST68M	0078	TST68M	73185																																				
TST67M	6547	TST68M	2180	TST68M	6551	TST68M	2381	TST68M	6623	TST68M	2431	TST68M	6680	TST68M	2460	TST68M	6695	TST68M	2490	TST68M	6732	TST68M	2527	TST68M	6745	TST68M	2585	TST68M	6780	TST69M	2623	TST69M	6785	TST69M	2766	TST69M	7293	TST69M	0079	TST69M	73186																																				
TST68M	6548	TST69M	2181	TST69M	6552	TST69M	2382	TST69M	6624	TST69M	2432	TST69M	6681	TST69M	2461	TST69M	6696	TST69M	2491	TST69M	6733	TST69M	2528	TST69M	6746	TST69M	2586	TST69M	6781	TST70M	2624	TST70M	6786	TST70M	2767	TST70M	7294	TST70M	0080	TST70M	73187																																				
TST69M	6549	TST70M	2182	TST70M	6553	TST70M	2383	TST70M	6625	TST70M	2433	TST70M	6682	TST70M	2462	TST70M	6697	TST70M	2492	TST70M	6734	TST70M	2529	TST70M	6747	TST70M	2587	TST70M	6782	TST71M	2625	TST71M	6787	TST71M	2768	TST71M	7295	TST71M	0081	TST71M	73188																																				
TST70M	6550	TST71M	2183	TST71M																																																																									

